

USER MANUAL



BERNINA 770 QE PRO

BERNINA
made to create

We take pride in providing you the perfect sewing experience!



BERNINA has represented exceptional quality since 1893. As a traditional Swiss company, we use high quality materials to manufacture our products and have them extensively tested, ensuring high performance and a long life. Over the years, we have always remained true to our company philosophy - we are personally committed to offering our customers an exceptional sewing experience.

Every BERNINA is characterized by state-of-the-art technology paired with innovations in both hardware and software. This is because we truly want you to enjoy the creative process to the fullest - after all, creativity is turning your ideas into something that makes you and others happy.

With this in mind, I wish you many joyous moments with your BERNINA 770 QE PRO.

A handwritten signature in black ink that reads "H. P. Ueltschi". The signature is written in a cursive style with a large, sweeping flourish at the end.

Sincerely, yours
Hanspeter Ueltschi
Owner, BERNINA

IMPORTANT SAFETY INSTRUCTIONS	5	6 Prepare and Edit Stitch Pattern.....	55
General Information	8	6.1 Load Stitch Pattern.....	55
My BERNINA		6.2 Stitch Pattern Editing	55
1 Welcome to the World of BERNINA	10	6.3 Buttonholes	57
2 Introduction	11	6.4 Darning Program	60
2.1 Machine	11	6.5 Stitch Pattern Management	61
2.2 Accessories	15	6.6 Stitch Pattern Combination	61
2.3 User Interface Overview	19	7 Securing	64
2.4 Help and Consultant	21	8 Free-motion Quilting with Stitch Regulation .	65
3 Set up the Machine.....	23	8.1 Stitch Regulation.....	65
3.1 Prior to Machine's First Use.....	23	9 Sewing Techniques	67
3.2 Working Area	23	Embroidery	
3.3 Connecting the Machine and Switching it On ...	23	10 General Embroidery Information.....	68
3.4 Preparing the Machine for Sewing	23	11 Embroidery Screen.....	70
3.5 Preparing the Machine for Embroidery.....	23	11.1 Status Bar	71
3.6 Foot Control	24	11.2 Layer Bar.....	72
3.7 Storing Accessories	24	11.3 Embroidery Design Selection	72
3.8 Slide-on Table.....	25	12 Prepare and Edit Embroidery Designs.....	74
3.9 Knee Lifter / Free Hand System	26	12.1 Loading the Embroidery Design.....	74
3.10 Stitch Plate	27	12.2 Embroidery Design Editing	74
3.11 Needle	27	12.3 Lettering	79
3.12 Upper Thread	30	12.4 Saving Embroidery Designs	80
3.13 Bobbin Thread	33	13 Embroidering the Embroidery Design.....	81
3.14 Presser Foot	35	13.1 Stitchout Summary	81
3.15 Fabric Feed	37	13.2 Stitchout.....	82
3.16 Embroidery Module	38	Maintenance	
3.17 Machine Settings	39	14 Care and Maintenance.....	83
3.18 Personal Settings	40	14.1 Software	83
3.19 Sewing Settings	40	14.2 Machine	83
3.20 Embroidery Settings.....	43	15 Storage and Disposal.....	89
Sewing		15.1 Storing the Machine	89
4 Sewing Screen.....	45	15.2 Dispose of the Machine	89
4.1 Status Bar	46	16 Error messages	90
4.2 Stitch Selection	46	17 Troubleshooting.....	95
5 Stitch Overview	48	18 Technical Data	101
5.1 Practical Stitches	48		
5.2 Decorative Stitches	51		
5.3 Alphabets	51		
5.4 Buttonholes	52		
5.5 Quilt Stitches	54		

Appendix

19 Stitch Patterns.....	102
19.1 Practical Stitches.....	102
19.2 Decorative Stitches.....	102
19.3 Buttonholes.....	106
19.4 Quilting Stitches.....	106
19.5 BSR Stitches.....	106
20 Embroidery Designs.....	107
20.1 Projects.....	107
20.2 Quilting.....	109
20.3 Children.....	119
20.4 Embellishment.....	123
20.5 Flowers.....	127
20.6 Frames.....	130
20.7 Seasons.....	132
20.8 Hobbies.....	137
20.9 Animals.....	139
20.10 Mini.....	141
20.11 Lace.....	144
20.12 Modern Monograms.....	147
Index.....	151

Please be aware of the following basic safety instructions when using your machine. Before using this machine, read instruction manual carefully.

DANGER

To protect against electric shock, the following instructions must be observed:

- ▶ Never leave the machine unattended when it is connected to the power supply. Immediately after use and before cleaning, switch off the machine and disconnect the power cable from the outlet.

In order to protect against injury, the following instructions must be adhered to:

- ▶ Do not look directly into the laser beam or view it with optical instruments (e.g. magnifying glasses).
If the laser is damaged or defective, have the laser checked or repaired by your local BERNINA dealer.
- ▶ Do not look directly into the LED lamp with optical instruments (e.g. magnifying glass).
If the LED lamp is damaged or defective, have the LED lamp checked or repaired at your local BERNINA dealer.
- ▶ Switch off the machine before working in the needle area.
- ▶ Before starting the machine, close all covers.

WARNING

To reduce the risk of burns, fire, electric shock or personal injury, the following instructions must be observed.

General Facts

- ▶ This machine may only be used for the purpose described in this instruction manual.

Working Environment

- ▶ Do not use the machine outdoors.
- ▶ Only use the machine in dry rooms.
- ▶ Do not use the machine in a humid area.
- ▶ Do not use the machine in rooms where aerosol products (sprays) are being used.
- ▶ Do not use the machine in rooms where oxygen is dispensed.

Technical Condition

- ▶ Never use the machine when it is damp.
- ▶ Do not use the machine if it is not working properly.
- ▶ Do not use the machine if a cable or the plug is damaged.
- ▶ Do not use the machine if it has been dropped, damaged or has fallen into water.
- ▶ If the machine is damaged or does not work properly, have the machine checked or repaired by your local BERNINA dealer.
- ▶ Keep all ventilation openings of the machine and the foot control free of lint, dust and loose cloth.
Do not use the machine if the ventilation openings are blocked.

Accessories and Supplies

- ▶ Only use the accessories recommended by the manufacturer.

IMPORTANT SAFETY INSTRUCTIONS

- ▶ Always use an original BERNINA Stitch Plate.
An incorrect stitch plate can result in needle breakage.
- ▶ Use only straight needles of good quality. Bent or damaged needles can cause needle breakage.
- ▶ The machine is double-insulated. Only use original spare parts. See instructions for servicing of double-insulated products.
- ▶ To lubricate the machine, only use oil recommended by BERNINA.

Appropriate Use

- ▶ The machine may be used, cleaned and maintained by children older than eight or by people with reduced physical, sensory or mental capabilities or if there is a lack of experience and knowledge.
Furthermore, these persons must be supervised while working with the machine, or they must know the safe operation of the machine and be aware of resulting hazards.
- ▶ Children are not allowed to play with the machine.
Special care should be taken when the machine is operated by or in the presence of children.
- ▶ Only use the machine with the supplied power cable.
USA and Canada only: Do not connect power plug NEMA 1-15 to circuits exceeding 150 volt-to-ground.
If the machine is to be used in a country other than the country of origin, obtain a power cable suitable for this country from a BERNINA dealer.
- ▶ Only use this machine with the supplied foot control of type LV-1.

- ▶ Do not insert any objects into the openings of the machine.
- ▶ Do not place any objects on the foot control.
- ▶ While sewing, guide the fabric gently. Pulling and pushing the fabric can cause needle breakage.
- ▶ Keep fingers away from all moving parts. Special care is required in the needle area.
- ▶ Only lift the machine by the handle.
- ▶ For activities in the needle area – such as threading the needle, changing the needle, threading the looper or changing the presser foot – switch off the machine. To switch off, set the power switch to «0».
- ▶ When protective covers are removed, when the machine is oiled or when other cleaning and maintenance operations mentioned in this instruction manual are carried out, switch off the machine and disconnect the power plug from the outlet.
- ▶ Pull the plug out of the outlet by pulling on the plug. Do not pull on the cable.

SAVE THESE INSTRUCTIONS

Safety Signs on the Machine

Sign

Purpose



Attention: Close the doors, lids and covers before operating the machine.

Caution; moving parts. To reduce the risk of injury, switch off the machine before maintenance work. Attach the covers.

FCC Declaration of Conformity

(For USA and Canada)

Responsible Company: BERNINA International AG,
Seestrasse 161, 8266 Steckborn, SCHWEIZ

Product Name: BERNINA 770 QE PRO

This device satisfies the provisions of Section 15 of the guidelines of the American Federal Communications Commission (FCC). Operation of this device is subject to the following conditions: (1) This device must not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device has been tested and, according to the specifications in Paragraph 15 of the FCC regulations, is compliant with the limit values for a digital Class B device. These specifications define appropriate protection against such interference in closed rooms. This device can generate, use and radiate HF energy. Therefore, if not installed and used properly, it may cause harmful interference to radio communications. There is, however, no guarantee that interference will not occur in certain situations. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user should try to correct the interference by one or more of the following measures:

- Reorient the antenna or set it up at a different location.
- Increase the spacing between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Contact your BERNINA dealer or an experienced radio/television technician.

Any change or modification to the device that has not been expressly approved by BERNINA can invalidate the electromagnetic compatibility (EMC) and result in the revocation of the operating license for this device.

Availability of the Instruction Manual

The instruction manual is supplied with the machine.

- Keep the instruction manual safe at a suitable place near the machine to have it at hand in case that you need to look up something.
- If you pass the machine to a third party, always include the instruction manual.
- The latest version of the instruction manual can be downloaded at www.bernina.com/770qe-pro-support.

Equipment and Scope of Delivery

Example images are used in these instructions for the purposes of illustration. The machines and the accessories shown in the images therefore do not always match the actual items included with your machine. The supplied accessory can vary depending on the country of delivery. Accessories mentioned or shown, which are not included in the scope of delivery, can be purchased as optional accessories from a BERNINA dealer. Further accessories can be found at www.bernina.com/770qe-pro#!accessories.

For technical reasons and in order to improve the product, changes may be made to the equipment of the machine and the scope of delivery at any time and without prior notice.

BERNINA Quality Control

All BERNINA machines are assembled with utmost care and are subjected to an extensive functionality test. The integrated stitch counter therefore indicates that the machine has already sewn stitches, which were performed exclusively for test purposes and quality control. The subsequent thorough cleaning does not exclude the possibility that thread remnants may still be found in the machine.

Servicing of Double-insulated Products

In a double-insulated product two systems of insulation are provided instead of grounding. No grounding means is provided on a double-insulated product nor should a means for grounded be added to the product. Servicing a double-insulated product requires extreme care and knowledge of the system and should only be done by qualified service personnel. Replacement parts

for a double-insulated product must be identical to the original parts in the product. A double-insulated product is marked with the words: *Double-Insulation* or *double-insulated*.

- ☐ The symbol may also be marked on the product.

Environmental Protection

BERNINA International AG is committed to environmental protection. We strive to minimize the environmental impact of our products by continuously improving product design and our manufacturing technology.



The machine is labeled with the symbol of the crossed-out wastebin. This means that the machine should not be disposed of in household waste when it is no longer needed. Improper disposal can result in dangerous substances getting into the groundwater and thus into our food chain, damaging our health.

The machine must be returned free of charge to a nearby collection point for electrical waste and electronic equipment or to a collection point for the reuse of the machine. Information on collection points can be obtained from your local administration. When purchasing a new machine, the dealer is obliged to take back the old machine free of charge and dispose of it properly.

If the machine contains personal data, you are responsible for deleting the data yourself before returning the machine.

Explanation of Symbols

DANGER

Designates a danger with a high risk which can lead to serious injuries or even death unless it is avoided.

WARNING

Designates a medium-risk hazard which can lead to serious injuries if not avoided.

CAUTION

Designates a low-risk hazard which can lead to minor or moderate injuries if not avoided.

NOTICE

Designates a hazard which can lead to material damage if not avoided.

With your BERNINA 770 QE PRO you can sew, embroider and quilt. Fine silk or satin fabrics as well as heavy linen, fleece and denim fabrics can be easily processed with this machine. Numerous practical as well as decorative stitches, buttonholes and embroidery designs are at your disposal.

Further Information



In addition to your BERNINA 770 QE PRO, further information products are also enclosed.

The current version of your manual as well as further information about the machine and the accessories can be found on our website.

bernina.com

"Made to Create" is the BERNINA slogan. Not only do our machines support you as you make your ideas a reality, we offer additional suggestions and instructions for projects and the opportunity to exchange ideas with other sewing, quilting and embroidery enthusiasts. We hope you have a great pleasure in doing so.

BERNINA YouTube Channel



On YouTube we offer a wide range of how-to videos and support concerning the most important functions of our machines. You can also find detailed explanations of presser feet and accessories that make your projects successful.

youtube.com/BerninaInternational

Available in English and German.

"inspiration" – the Creative Sewing Magazine and Online Store with Sewing Patterns



Are you looking for ideas, sewing patterns and instructions for great sewing projects? If so, the

BERNINA magazine "inspiration" is just the right thing for you. Three times a year, "inspiration" offers you great sewing and embroidery ideas. From seasonal fashion trends to trendy accessories and practical tips to original decorations for your home or cute sewing ideas for children.

The magazine is available in English, German, Dutch, and French.

In our online shop you can purchase "inspiration" as an e-magazine or as a print version, either as individual issues or as a subscription. Furthermore, there are many individual downloadable patterns to discover! Why not take a look at:

inspiration.bernina.com

And follow us on Instagram (@inspiration.sewing.magazine).

BERNINA Blog



Sophisticated instructions, free sewing patterns and embroidery designs as well as many new ideas can be found weekly on our BERNINA Blog. Our experts give useful tips and step by step instructions to achieve your desired results. In the community you can upload your own projects and exchange experiences and ideas with other sewing and embroidering enthusiasts.

bernina.com/blog

Available in English, German, Dutch and French.

BERNINA Social Media



Follow on social networks to learn more about events, exciting projects and tips and tricks all about sewing, quilting and embroidering. We will keep you informed and are looking forward to sharing highlights from the world of BERNINA.

bernina.com/social-media

BERNINA Stitchout App



WiFi enabled BERNINA embroidery machines can be used together with the BERNINA Stitchout App. Once the machine is connected to the app, the embroidery process can be tracked and monitored via the smartphone. The app shows how far the embroidery design has progressed, which color will be next and how long the embroidery process will take in total. Furthermore, messages are displayed for the case that the thread is broken or the embroidery is finished. The app is available in the Apple App Store and the Google Play Store.

bernina.com/stitchout-app


2.1 Machine

Front




1 Embroidery Module Connection 2 Bobbin Cover 3 Needle Area 4 Thread Cutter 5 Thread Take-up Lever Cover 6 Connection for Slide-on Table 7 Knee Lifter Connection

Needle Area




1 Needle Threader 2 Lighting 3 Needle Holder 4 Needle 5 Presser Foot 6 Connection for Sewing Accessories 7 Stitch Plate 8 Feed Dog

Bobbin Area




1 Bobbin Case 2 Release Lever 3 Hook 4 Thread Cutter 5 Bobbin Cover 6 Fastening Bracket 7 Bobbin Thread Indicator

Back



1 Air Vents 2 Connection for Multiple Spool Holder 3 Spool Pin, Horizontal 4 Bobbin Winding Unit with Thread Cutter 5 Carry Handle 6 Thread Guide, Winder 7 Thread Guide, Rear 8 Connection for Accessory 9 BSR Connection 10 BERNINA Dual Feed 11 Connection for Darning Hoop

Right Side




1 Feed Dog Up/Down 2 Magnetic Holder for Touchscreen Pen 3 Handwheel 4 Spool Holder Vertical 5 Power Switch 6 Connection for Power Cable 7 Air Vents 8 USB Port, Type A 9 Service Connection 10 Connection for Foot Control

Controls



1 External Buttons above the Needle 2 Left Controls 3 Display 4 Right Controls

Function Buttons above the Needle



1 Start/Stop 2 Presser Foot Up/Down 3 Thread Cutter 4 Quick Reverse

Start/Stop

You can use the **Start/Stop**  button to start or stop the machine.

- Lights up green when the machine is ready.
- Lights up red when the machine is not ready.
- Does not light up when the machine is sewing or embroidering.

Presser Foot Up/Down

You can use the **Presser Foot Up/Down**  button to raise or lower the presser foot.

Depending on the starting position, the presser foot is either raised all the way up or lowered to the hover position.

You can define the hover position height in the Settings.

Thread Cutter

You can use the **Thread Cutter**  button to cut the upper thread and the bobbin thread automatically.

If necessary, the machine is stopped, the needle and presser foot are lowered, the upper thread and lower thread are cut.

TIP

In the Sewing Settings **External Buttons** , you can assign additional functions to the button.

Quick Reverse


You can use the **Quick Reverse**  button to sew in reverse while the button is pressed.

In the Settings, you can program whether the **Reverse** option or the **Backstep** option should be executed.

In the following applications, you can program the length by pressing the **Quick Reverse** ↕ button:

- Buttonhole Programs
- Darning Programs
- Tapering Stitches
- Stitch Counter Program
- Stitches with Securing Program

Left Controls



1 Needle Position Up/Down 2 Automatic Needle Threader 3 Tie-Off 4 Pattern End 5 Speed Control

Needle Position Up/Down

Use the **Needle Position Up/Down** ↕ button to raise or lower the needle.

The needle is raised or lowered depending on its starting position. The presser foot is lowered before the needle is lowered.

Tie-Off

You can use the **Tie-Off** ↻ button to sew a programmable number of securing stitches.

If you press the button before sewing, securing stitches will be sewn at the beginning of the seam.

If you press the button during sewing, securing stitches will be sewn immediately and the machine will stop.

TIP

In the Sewing Settings **External Buttons** ⚙️, you can assign additional functions to the button.

Automatic Needle Threader

You can use the **Automatic Needle Threader** ↕ button to thread the needle automatically.

The **Start/Stop** ○● button is deactivated and lights up red. The upper thread is threaded into the needle.

If the needle is in the incorrect position, the needle will first be moved to the correct position.

Pattern End

You can use the **Pattern End** ▲ button to stop the machine automatically at the end of a stitch pattern or a stitch pattern combination.

If you press the button before sewing, the button is activated and the **Stop** ⏹ icon is displayed in the stitch preview.

If you press the button during sewing, the machine will stop at the end of the pattern. If the machine is stopped in the middle of a pattern the pattern will complete when sewing is resumed. If **Repeat** ▲↺ has been set, the machine will stop at the end of the set repeat.

TIP


In the Sewing Settings **External Buttons** ⚙️, you can assign additional functions to the button.

Speed Control

You can regulate the sewing and embroidery speed with the speed control.

For better control while sewing or embroidering, you can set the maximum sewing or embroidery speed in the settings.

Right Controls



1 Upper Multi-function Knob 2 Lower Multi-function Knob 3 Needle Position Left/Right

Upper Multi-function Knob

You can use the Upper Multi-function Knob for setting the Stitch Width and the values of a function.

Lower Multi-function Knob

You can use the Lower Multi-function Knob for setting the Stitch Length and the values of a function.

Needle Position Left/Right

You can use the **Needle Position Left/Right** buttons to move the needle to the left or to the right.

The needle position is shown on the sewing screen. Negative values indicate a movement to the left, positive values a move to the right.

2.2 Accessories

Further information and application notes on the supplied and optional accessories can be found under: www.bernina.com/770qe-pro#!accessories

Included Accessories

Accessories	Purpose
Dust Cover 	To protect the machine from dust and contamination.
BERNINA Accessories Box 	To store supplied and optional accessories.
Power Cable 	To connect the machine with the power supply.
Foot Control 	To start and stop the machine. To control the sewing speed.

Accessories	Purpose
Slide-on Table 	To increase the sewing surface.
Knee Lever/Free Hand System (FHS) 	For raising and lowering the presser foot free hand.
Touchscreen Pen 	For precise operation of the touchscreen.
Spool Cap D12 	Secures the thread spool in place and allows it to unwind consistently while sewing.
Spool Cap D27 	Secures the thread spool in place and allows it to unwind consistently while sewing.
Spool Cap D43 	Secures the thread spool in place and allows it to unwind consistently while sewing.

2 Introduction

Accessories

Purpose

2x Foam Pad



The foam pad prevents the thread from slipping, tangling or breaking on the spool pin.

5x Bobbin for B9/
BERNINA Hook



To wind the bobbin thread.

Height Compens-
ation Tool



To level an angled position of the presser foot sole when sewing over thick seams.

Seam Ripper

To undo seams and to cut buttonholes open.



Right Seam Guide

To align even seam distances.



Accessories

Purpose

Needle Assortment

For the most common sewing applications.



Brush

To clean the feed dog and the bobbin area.



Screwdriver, red,
slot

To loosen and tighten slotted screws.



Screwdriver, gray,
Torx

To change the needle.



Angular Wrench,
Torx

To open the head cover.



2 Introduction

Accessories	Purpose
-------------	---------

Sewing Machine Oil



To oil the machine.

Sewing Thread Set



For sewing.

Included Presser Feet

Presser Foot	Purpose
--------------	---------

Reverse Pattern Foot #1C



For practical and decorative stitches. To sew forward and in reverse.

For materials such as corduroy, denim or wool.

Reverse Pattern Foot #1D



For practical and decorative stitches. To sew forward and in reverse.

For materials such as corduroy, denim or wool.

Use only with the BERNINA Dual Feed.

Presser Foot	Purpose
--------------	---------

Buttonhole Foot with Slide #3A



For automatic buttonholes with a maximum length of 30 mm, with or without cord.

Zipper Foot #4D



For sewing in zippers, topstitching next to raised seams.

For sewing on braids, piping and hook and loop fastener.

Use only with the BERNINA Dual Feed.

Open Embroidery Foot #20C



For decorative sewing applications and stitch patterns.

BERNINA Stitch Regulator (BSR) #42



Regulates the stitch length while free-motion quilting, thread painting and free-motion embroidery on all fabrics.

Patchwork Foot #97D



For patchwork and other precise work.

Use only with the BERNINA Dual Feed.

2 Introduction

Embroidery Module



1 Embroidery Arm 2 Coupling for Securing the Hoop
3 Guide Rails 4 Connection to the Machine

Included Embroidery Accessories

Accessories	Purpose
Embroidery Foot #26L	For embroidering, darning and free hand quilting.



Large Oval Embroidery Hoop (incl. embroidery template)	For embroidering designs and design combinations. Max. Embroidery Area: 145 x 255 mm (5.7 x 10.0 in)
--	---



Medium Embroidery Hoop (incl. embroidery template)	For embroidering designs and design combinations. Max. Embroidery Area: 100 x 130 mm (3.9 x 5.1 in)
--	--



Accessories	Purpose
Small Embroidery Hoop (incl. embroidery template)	To embroider small embroidery designs. For free arm embroidering with closed sewing projects such as sleeves, trouser legs or socks. Max. Embroidery Area: 72 x 50 mm (2.8 x 2.0 in)



2x Template Holder	To fix the template in the embroidery hoop.
--------------------	---



Embroidery Needle Assortment	For embroidering.
------------------------------	-------------------



Thread Spool Net	To regulate threads that unwind too quickly from the spool, e.g. nylon, rayon, silk or metallics.
------------------	---



Embroidery Thread Set	For embroidering.
-----------------------	-------------------



2.3 User Interface Overview

Manipulation

The software can be operated with the touch-sensitive screen using touch gestures or the included touch-screen pen.

Operation with Touch Gestures

Gestures with One Finger	Application
Tap 	<ul style="list-style-type: none"> Select functions, stitch pattern or embroidery design
Drag 	<ul style="list-style-type: none"> Scrolling in Menus, Windows and Bars Move or delete selected stitches in Combi Mode Move selected layers in the embroidery screen Delete layers from the layer bar in Embroidery Mode

Navigation

In the modes **Sewing** and **Embroidery**, in the settings and in the consultant, the navigation path  to the current content is displayed, which you can use to go back to a specific level in the path.

Activating/Deactivating Functions

You can switch functions on and off as follows:

- Tap the Switch
 - 
 - Green: Function is switched on.
 - Red: Function is switched off.
- Tap Icons
 - Outlined in white: Function is switched on.
 - Gray: Function is not available.
 - Outlined in yellow: Function or value deviates from the default value.

Setting Values

You can set values as follows:

- Slider



Set the value with the slider control or reset the value to the default by tapping the small bullet.

- Plus and Minus Icons




Modified values are marked in yellow. You can reset a modified value to the default value by tapping the field outlined in yellow.



Home Screen

Home Screen 



1 Sewing 2 Embroidery

Modes

The main modes give you quick access to the most important functions of your machine.


Sewing

In **Sewing**  mode, you will find the functions you need for practical and creative sewing. [▶ see page 45]

Embroidery

In **Embroidery** mode, you will find functions for creative machine embroidery and computerized quilting. [▶ see page 70]

Function Keys on the Screen



Home Screen

By pressing the button **Home Screen** , you can call up the start page. [▶ see page 19]

Settings

By pressing the button **Settings** , you can call up the settings. [▶ see page 39]

Tutorial

By pressing the button **Tutorial** , you can call up the tutorials. [▶ see page 22]

Consultant

By pressing the button **Consultant** , you can call up the function **Consultant** . [▶ see page 21]

Quick Help

By pressing the button **Quick Help** , you can tap any screen element and will receive help on it. [▶ see page 21]

eco-mode

By pressing the button **eco-mode** , you can lock the screen, the sewing and embroidery functions and the motor.

1. Press the button **eco-mode**  to lock the machine.
2. To unlock the machine, press the button **eco-mode**  again.

Clear

By pressing the button **Clear CLR**, you can reset the following settings to the default values:

Sewing Mode

- Stitch Length and Stitch Width of the Selected Stitch
- Needle Position
- Mirroring
- Long Stitch
- Pattern Repeat
- Balance
- Stitch Density
- Upper Thread Tension
- Programmed Buttonhole Length
- Darning Program Settings
- Backstepping
- Stitches with Stitch Counter
- Presser Foot Selection
- Continuous Reverse

Embroidery Mode

- Design Position
- Rotation
- Scaling
- Mirroring
- Presser Foot Selection

File Management


You can administer your own stitch patterns in the folder **Personal Folder**  and on a USB stick. You can save, load or delete your own stitch patterns. You can administer the stitch patterns in predefined folders.

USB Storage Space

The display **USB Storage Space** shows how much free memory capacity is available.

2.4 Help and Consultant


Quick Help



By pressing the button **Quick Help ?**, you can call up brief help for many screen elements, such as icons, buttons or entire screen areas.

1. Tap the icon **Quick Help ?**.
2. Tap the screen element for which help is required.
 - ⇒ The Quick Help for the screen element appears.

Consultant



With the function **Consultant** , you can obtain recommendations for various sewing, embroidery and quilting techniques on how to prepare and set the machine. Depending on the selected technique and fabric, different recommendations are displayed.

Sewing Mode

Icon	Recommended
	Stitch
	Needle
	Thread
	Presser Foot

Icon	Recommended
	Feed Dog Up/Down
	Stabilizer(s)

Depending on the selected technique, you must prepare the machine manually according to the recommendations:

- Fit the needle and presser foot.
- Thread the thread.
- Set the feed dog.
- Reinforce the fabric.
- Reinforce buttonhole beads with yarn inlays.

If you confirm the manual preparations using the icon **Apply Settings**  various settings are set automatically, e.g. **Stitch Width**, **Stitch Length** or **Needle Position**.

Embroidery Mode


Icon	Recommended
	Needle
	Upper Thread
	Presser Foot
	Bobbin Thread
	Upper Stabilizer
	Lower Stabilizer
	Adhesive
	Starch
	Hoop
	Basting
	Use yarn/cord

Depending on the selected technique, you must prepare the machine manually according to the recommendations:

- Fit the needle and presser foot.
- Thread the upper and bobbin thread.
- Reinforce fabric with the upper/lower stabilizer.
- Use spray adhesive or spray starch.
- Hoop the fabric in the embroidery hoop.
- Attach the hoop.

If you confirm the manual preparations using the icon **Apply Settings** ✓ various settings are set automatically, e.g. **Upper Thread Tension**.

Tutorial



With the **Tutorial** function, you can obtain information and explanations on various sewing and embroidery techniques, areas of the machine and troubleshooting.

3.1 Prior to Machine's First Use

TIP

BERNINA recommends lubricating the hook before using the machine for the first time or after a longer period of non-use. [▶ see page 87]

Lubricating the hook keeps the machine running smoothly and quietly.

3.2 Working Area

A stable table with a secure stand is a good prerequisite for optimal sewing results. Ergonomics of the sewing table is important to protect the muscles and joints of the back, shoulder, arms and hands. The recommendation for optimal ergonomics includes matching the table height with the body posture. Avoid remaining in the same position for long periods.

The machine can also be operated when standing.

Correct Sitting Position

With the arms bent (90°), the fingertips can touch the stitch plate in a comfortable sitting position.

3.3 Connecting the Machine and Switching it On

1. Insert the cable into the machine.



2. Insert the power plug of the power cable into the socket.
3. Switch on the machine using the power switch.

3.4 Preparing the Machine for Sewing

For your sewing project, you must prepare and set the machine accordingly.

Prerequisite:

- The machine is switched on.
 - The sewing settings have been made. [▶ see page 40]
 - The foot control is connected. [▶ see page 24]
1. When the embroidery module is connected and is not to be removed, move the embroidery arm to the sewing position. [▶ see page 39]
 2. Raise the feed dog if necessary.
 3. Attach the Slide-on Table if required. [▶ see page 25]
 4. Attach the Knee Lifter. [▶ see page 26]
 5. Select the sewing mode via the start page. [▶ see page 19]
 - ⇒ The Sewing Screen appears. [▶ see page 45]
 6. Use a suitable stitch plate. [▶ see page 27]
 7. Use a suitable sewing needle. [▶ see page 29]
 8. Fit the appropriate presser foot. [▶ see page 36]
 9. Prepare and edit stitch pattern. [▶ see page 55]
 10. Thread a suitable bobbin thread. [▶ see page 34]
 11. Thread a suitable upper thread. [▶ see page 30]

TIP

The consultant will recommend a presser foot, needles, materials and sewing settings for special sewing techniques and fabrics. [▶ see page 21]

3.5 Preparing the Machine for Embroidery

For your embroidery project you must prepare and set the machine accordingly.

Prerequisite:

- The machine is switched on.
 - The embroidery settings have been made. [▶ see page 43]
1. Select embroidery mode via the start page. [▶ see page 19]
 - ⇒ The Embroidery Screen appears. [▶ see page 70]
 2. Lower the feed dog if necessary.
 3. Remove the Knee Lifter.

3 Set up the Machine

4. Insert the Straight Stitch Plate. [▶ see page 27]
5. Insert a suitable embroidery needle. [▶ see page 29]
6. Attach and select a suitable embroidery foot. [▶ see page 36]
7. Attach the Embroidery Module. [▶ see page 38]
8. Attach the suitable hoop. [▶ see page 38]
9. Prepare and edit embroidery designs. [▶ see page 74]
10. Thread a suitable bobbin thread. For a higher bobbin thread tension, use a bobbin case with a high thread tension. [▶ see page 34]
11. Thread a suitable upper thread. [▶ see page 30]

TIP

For special embroidery techniques and fabrics, the Consultant will recommend an embroidery foot, stitch plate and needles as well as fabrics and embroidery settings. [▶ see page 21]

3.6 Foot Control

You can operate the front foot control with the ball of your foot and the rear foot control with your heel. With the ball pressure, you can start and stop the machine. Depending on the force you apply to the foot control, you can regulate the sewing speed. With the heel pressure, you can raise or lower the needle.

TIP

You can perform additional functions via the heel pressure. You can configure the functions in the Sewing Settings. [▶ see page 42]

Connecting the Foot Control


1. Unwind the cable of the foot control to the desired length.
2. Insert the plug of the cable into the foot control socket of the machine.



3. Place the Foot Control on the floor in a comfortable position for sewing.
4. If the cable is too long, roll up excess length.

3.7 Storing Accessories

The accessories box provides tidy storage for your accessories.



- 1** Holder for Needle Sets **2** Holder for Presser Feet without Lens **3** Bobbin Holder with Spring Button **4** Compartment for Buttonhole Foot with Slide #3A **5** Holder for Presser Feet with Lens **6** Drawer, Small **7** Drawer, Large

1. Unfold the feet and stand up the accessories box.

3 Set up the Machine

- Open the doors.



- If necessary, insert the holders into the grooves in the accessories box.

NOTICE

Incorrect storing of the bobbin


Scratched or dirty sensor surfaces on the bobbins can cause malfunctions of the lower thread indicator.

- ▶ Always position the bobbins in the bobbin holder with the silver sensor surface to the right.

- Place your accessories in the appropriate holders and compartments.
- To remove a bobbin, press the spring button down.
- Store small parts in the drawers.

3.8 Slide-on Table

The slide-on table allows you to enlarge the sewing area. This makes it easier to position and work on your sewing project. The viewing window allows for visual access to the bobbin area while changing the bobbin without having to remove the table. The table has a printed ruler in both centimeters and inches to aide in aligning various projects. The zero center is aligned with the center needle position when attached.



- 1 Viewing Window 2 Ruler 3 Release Button

Using the Slide-on Table

The Slide-on Frearm Extension Table, attached to the freearm, enables the available sewing area to be extended.

Prerequisite:

- Raise the needle.
- Raise the presser foot.
- Push the Slide-on Frearm Extension Table from the left to the right over the freearm until it engages.



- To remove the Slide-on Frearm Extension Table, press the button at the table down and pull the slide-on table over the free arm to the left.



Using the Seam Guide

The Seam Guide for the Slide-on Table allows you to sew along the guide for uniform seams.



1 Release Button


Prerequisite:

- The Slide-on Table is attached.
1. To attach the Seam Guide, press the release button and engage the Seam Guide from the front to the back on the Slide-on Table.
 2. Press the release button down once attached and position in place as desired.
 3. To remove the Seam Guide, press the release button and pull the Seam Guide away to the front.

3.9 Knee Lifter / Free Hand System

With the Knee Lifter, you can raise and lower the presser foot without taking your hands away from your sewing project.

If the presser foot is raised, you can also lower the presser foot using the Knee Lifter.



Working with the Knee Lifter offers the following advantages:

- When the presser foot is raised with the Knee Lifter, the feed dog is lowered at the same time and the thread tension is released, enabling you to easily move or remove your sewing project.
- When the presser foot is lowered using the knee lever, the feed dog is raised after the first stitch and, if necessary, the thread tension is activated so that you can continue sewing quickly and easily.

Using the Knee Lifter

Attaching the Knee Lifter of the Free Hand System



1. Insert the Knee Lifter into the Knee Lifter Connection as far as it will go.
2. Adjust the sitting height so that the Knee Lifter can be comfortably operated with the knee.

TIP

The lateral position of the lever can be adjusted by your local BERNINA dealer if required.

Raising the Presser Foot

1. Push the Knee Lifter to the right and hold it there with your knee.
 - ⇒ The presser foot is raised and the feed dog is lowered.
2. Release the Knee Lifter slowly to lower the presser foot.
 - ⇒ The presser foot is lowered and the feed dog is raised.

Lower the Presser Foot


- ▶ When the presser foot is raised, push the Knee Lifter all the way to the right and slowly release it.
 - ⇒ The presser foot is lowered, the feed dog is raised and the thread tension is activated.

3.10 Stitch Plate

The supplied 9 mm Stitch Plate is suitable for most sewing applications. For specific applications, e.g. PunchWork, special stitch plates are used. The special stitch plates are marked with a color code.

- Without color code: 9 mm Stitch Plate
- Yellow: PunchWork Stitch Plate
- Orange: Straight and CutWork Stitch Plate
- Purple: 9 mm Stitch Plate with 5.5 mm Stitch Hole

Vertical lines are engraved on each stitch plate, which you can use as a ruler for guiding the fabric in a straight line. You can use the diagonal lines to align the fabric at a precise 45° angle. You can use the horizontal lines to lay the fabric at the specified distance from the needle.




- 1 Pressure Point for Release 2 Fabric Placement
 3 Needle Position 4 Ruler in cm 5 Ruler in inches
 6 Color Code

Changing the Stitch Plate

Prerequisite:

- The needle and the presser foot are raised.
1. Lock the screen.
 2. Remove the needle and presser foot.

3. Press the stitch plate down at the pressure point for release on the right until it tips.



4. Remove the stitch plate.
5. Place the openings of the new stitch plate above the corresponding guide pins and press the stitch plate down until it clicks into place.



6. Unlock the screen.
7. Tap the status icon **Stitch Plate and Sewing Needle** and select the fitted stitch plate in the **Stitch Plate Overview** section. [▶ see page 30]
 - ⇒ The machine checks the compatibility of the stitch plate with the attached needle and the selected stitch. If the stitch cannot be sewn with the attached stitch plate, the stitch is shown in red in the stitch preview and the machine will not start.


3.11 Needle

Only use needles from the 130/705 system for your machine. Select a needle thickness that is suitable for the selected fabric: Fine needles for fine fabrics, thick needles for heavy fabrics.

- Needle sizes 70, 75: Lightweight fabrics
- Needle sizes 80, 90: Medium fabrics
- Needle sizes 100, 110 and 120: Heavyweight fabrics

3 Set up the Machine

There are different needle types for different sewing projects. You can identify the needle type and needle size by the needle name, e.g. **130/705 H-S/70**:



1 705 = shank **2 130** = shank length **3 H** = groove
4 S = Point Type **5 70** = Needle Size



Detailed information on needles and their applications can be found in the BERNINA Needle Brochure.

Needles become worn over time. Needles should be replaced regularly, as a clean stitch can only be made with a sharp tip.

Needle/Thread Combination



The needle/thread combination is correct if the thread is guided exactly into the long groove and through the eye of the needle.






If the thread is too thin for the needle, it will have too much room to move in the long groove and in the eye of the needle. This can result in the thread breaking or skipping stitches.





If the thread is too thick for the needle, it will be difficult to guide it through the eye of the needle and it may rub along the edge of the long groove. This can result in the thread breaking and sticking in the needle.

Needle Overview

Needle	Purpose
Universal Needle 130/705 H 60/8 – 120/19   With a slightly rounded point.	For woven fabrics (light, medium, heavy-weight), knitwear, leather, vinyl, jeans/denim. For natural and synthetic fabrics. For general sewing, sewing on buttons and buttonholes, zippers, hems and topstitching, decorative sewing, embroidery, patchwork, quilting.
Stretch Needle 130/705 H-S 75/11 – 90/14   With a medium ball point.	For knitwear (jersey, tricot, knit and stretch material). For general sewing, sewing on buttons and buttonholes, zippers, hems and topstitching, decorative sewing, embroidery.
Jersey/Embroidery Needle 130/705 H SUK 80/12   With a medium ball point.	For woven fabrics (light, medium, heavy-weight), knitwear. For general sewing, sewing on buttons and buttonholes, zippers, hems and topstitching, decorative sewing, embroidery.
Jeans Needle 130/705 H-J 80/12 – 110/18   With a slim sharp point.	For woven fabrics (light, medium, heavy), leather, jeans/denim, foils and oilcloth. For general sewing, sewing on buttons and buttonholes, zippers, hems and topstitching, decorative sewing, embroidery, patchwork, quilting.
Leather Needle 130/705 H LR 90/14, 100/16   With cutting tip.	For leather, imitation leather and similar materials. For zippers, hems and topstitching, materials that tend to stick.


3 Set up the Machine

Needle	Purpose
Microtex Needle 130/705 H-M 60/8 – 110/18    With a very slim sharp point.	For woven fabrics (light, medium, heavy), plastics, materials that are difficult to glide such as silk, microfiber fabrics, vinyl, coated materials. For general sewing, sewing on buttons and buttonholes, zips, hems and topstitching and decorative sewing. For straight stitches when topstitching edges.
Quilting Needle 130/705 H-Q 75/11 – 90/14    With a very slim, slightly rounded point.	For woven fabrics (light, medium and heavy-weight). Decorative sewing, patchwork, quilting. For stitching/topstitching tasks, such as quilting and patchwork.
Embroidery Needle 130/705 H-E 75/11 – 90/14    With a light ball point and a particularly wide eye and wide groove.	For woven fabrics (light, medium, heavy-weight), knitwear. For thicker threads. For general sewing, sewing on buttons and buttonholes, zippers, hems and topstitching, decorative sewing, embroidery.
Fine Fabrics Needle 130/705 H SES 70/10 – 90/14    With a light ball point.	For fine, delicate materials, such as velvet. For general sewing, sewing on buttons and buttonholes, zippers, hems and topstitching, decorative sewing, embroidery, patchwork, quilting.
Metafil Needle 130/705 H METAFIL L 80/12    With medium ball point and long eye (2 mm).	For woven fabrics (light, medium, heavy-weight), knitwear. For sewing with special effects and fancy threads, especially metallic threads. For embroidery with metallic thread. For hems and topstitching, decorative sewing and embroidery.


Needle	Purpose
Topstitch Needle 130/705 H-N 80/12 – 100/16    With medium ball point and long eye (2 mm).	For woven fabrics (light, medium and heavy-weight). For hems and topstitching, decorative sewing and embroidery. For decorative and quilting work with several sewing threads and also for embroidery.
Felting Needle PUNCH   With small barbs.	For woven fabrics (light, medium, heavy-weight), jeans/denim. For felting a variety of yarns and threads into base fabrics.

Changing the Needle

1. Lock the screen.
2. Remove the presser foot.




3. Raise the needle.
4. Loosen the screw on the needle and pull the needle downwards.



5. Insert and push the new needle with the flat side to the back as far up as it will go into the needle holder and hold it in place.

3 Set up the Machine


6. Tighten the screw.



7. Unlock the screen.
8. In the Status Bar, tap **Stitch Plate and Sewing Needle**  and select the fitted needle in the **Needle Overview** section. [▶ see page 30]

Stitch Plate and Sewing Needle

Sewing  ▶ **Stitch Plate and Sewing Needle** 



- 1 Selected Stitch Plate 2 Recommended 3 Stitch Plate Overview 4 Needle Overview 5 Needle Minder

The stitch plates and needles compatible with the machine are displayed in the **Stitch Plate Overview** and **Needle Overview** sections.

Recommended stitch plates and needles are shown with the **Recommended** ★ icon.

To enable the machine to check the compatibility of the stitch, needle and stitch plate, you must select the fitted needle and stitch plate in the and area **Needle Overview** and **Stitch Plate Overview**. The selected needle is outlined in white in the area **Needle Overview** and displayed in the status bar. The selected stitch plate is outlined in white in the area **Stitch Plate Overview**.

If the selected needle cannot be used with the stitch plate or the presser foot, an error message is displayed.

Needle Minder

With the **Needle Minder**  function you can note the needle type and needle size of the attached needle. If you have forgotten which needle is attached, you can look it up at any time.

Needle Position

You can adjust the position of the needle in various ways:

- Button **Needle Position Up/Down** : Raise or lower the needle.
- Buttons **Needle Position Left/Right** : Move the needle five positions to the left or to the right of the center.
- Icon **Needle Stop** : To set the needle position up or down when stopping the machine in sewing mode.

3.12 Upper Thread

The quality, thickness and material of the thread must be suitable for the selected fabric. To achieve the best results, BERNINA recommends purchasing high-quality threads.

- Cotton threads are particularly suitable for sewing decorative projects on cotton fabric, such as quilts. As cotton threads are not particularly tear-resistant, they can also be used for basted seams that are later undone. They should not, however, be used for seams that need to be particularly hard-wearing.
- Mercerized cotton threads have a slight sheen that remains even after washing.
- Polyester threads have a high tensile strength and are particularly colorfast. Polyester threads are more flexible and are recommended where a strong and elastic seam is required.
- Rayon/viscose threads are characterized by their bright sheen. Rayon threads are suitable for decorative stitches and create a more beautiful effect.

Threading the Single Needle


For a proper seam and to avoid “thread tangles”, you must thread the upper thread correctly.

The thread path for threading is marked on the machine with drawn-through arrows.


1. Place a foam pad on the horizontal spool pin.

3 Set up the Machine


2. Raise the presser foot so that the thread tension discs are open and the thread can slide easily between them.
3. Raise the needle so that the thread can be easily inserted into the thread take-up lever.
4. Lock the screen.
5. Place the thread spool on the spool pin.
6. Select a spool cap with the same diameter as the spool and place it on the spool pin. The spool should not rotate. The thread should unwind properly.




7. For slippery threads put a spool net over the spool as an additional measure.
8. Guide the thread directly to the rear thread guide.
9. Hold the thread with your right hand and, with your left hand, pull the thread taut under and through the thread guide to the front of the machine.
10. Guide the thread on the right downward past the thread tension disc.



11. Guide the lower thread upward around the thread take-up lever cover.



12. Guide the thread through the thread take-up lever and guide it downward. Make sure that the thread is guided under the left side panel.



13. Guide the thread from the right to the left behind the first thread guide in the needle area.



3 Set up the Machine

14. Guide the thread from the right to the left behind the second thread guide in the needle area.



15. Pull the thread to the left and slightly backwards.

NOTICE


Damage to the Automatic Needle Threader or the Needle

Thin needles can break when using the automatic needle threader.

The threading hook of the automatic needle threader can be damaged.

- ▶ Only use the automatic needle threader with needles of size 70 and above.
- ▶ Always thread size 60 needles by hand.

16. Guide the thread from back to front around the thread cutter and trim the thread.



17. Unlock the screen.

18. Press the **Automatic Needle Threader**  button.
⇒ The thread is threaded into the needle.

Notes on the Automatic Needle Threader

- The Automatic Needle Threader is only suitable for threading a single needle. Always thread twin needles and triple needles by hand.
- The Automatic Needle Threader is suitable for needles of size 70 and above. Thread thinner needles by hand.
- The Automatic Needle Threader is not compatible with the following presser feet. If you are using one of these presser feet, thread the needle by hand.
 - Punch Tool #45
 - Walking Foot #50
 - Leather Roller Foot #55
 - Adjustable Ruler Foot #72
 - Binder Attachment #85
 - Ruffler #86
 - Foot for Cut 'n' Sew Attachment #90

Threading the Twin Needle

To thread a twin needle, thread both threads one after the other according to the instructions for the single needle. Start with the left needle. [▶ see page 30]



Note the following differences:

1. Place one foam pad each on the vertical and the horizontal spool pin.
2. Place the spool for the left needle on the vertical spool pin and the spool for the right needle on the horizontal spool pin.
3. Guide the thread of the vertical spool pin from right to left through the thread guide eyelet.
4. Guide both upper threads up to the thread tension disc in the same way as threading the single needle.
5. At the thread tension disc, guide the thread for the left needle down the left and the thread for the right needle down the right of the thread tension disc.

3 Set up the Machine

6. Guide the threads up to the needle in the same way as threading the single needle.
7. Thread both needles by hand.


Threading the Triple Needle

To thread a triple needle, thread the three threads one after the other according to the instructions for the single needle. Start with the left needle. [▶ see page 30]



Note the following differences:

1. Place a foam plate, a spool and a matching spool disc on the horizontal spool pin.
2. Place a foam pad, a filled bobbin and a spool on the vertical spool pin in the opposite direction to the bobbin.
3. Guide the threads of the vertical spool pin from right to left through the thread guide eyelet.
4. Guide all upper threads up to the thread tension disc in the same way as threading the single needle.
5. Guide the threads of the vertical spool pin on the left-hand side past the thread tension disc and the thread of the horizontal spool pin on the right-hand side past the thread tension disc down.
6. Guide the threads up to the needle in the same way as threading the single needle.
7. Thread each a thread of the vertical spool pin into the left and right needle by hand.
8. Thread the thread of the horizontal spool pin into the center needle by hand.



3.13 Bobbin Thread

For general sewing, we recommend using the same thread for the upper thread and the lower thread. Consult the Creative Consultant for thread recommendations with various applications and fabrics.


Bobbin Winding

The thread path for winding the bobbin thread is marked with arrows on the machine.

1. Place an empty bobbin on the bobbin winder so that the silver sensor surface is facing downward.



2. Fold up the vertical spool pin.




3 Set up the Machine


3. Place a foam pad and the spool on the vertical spool pin.



4. Guide the thread to the left into the rear thread guide.
5. Guide the thread around the bobbin winder pre-tension in the direction of the arrow.



6. Wind the thread 2 – 3 times around the bobbin in the direction of the arrow and cut it using the thread cutter on the engaging lever.




7. Push the engaging lever toward the bobbin.




⇒ The winding will stop automatically when the bobbin is full.

8. To interrupt the winding process before it is complete, push the switch-on lever to the right.
9. Remove the bobbin and cut the thread using the thread cutter.



Threading the Bobbin Thread

1. Raise the needle.
2. Raise the presser foot.
3. Lock the screen.
4. Open the bobbin cover.
5. Press the latch on the right of the bobbin case and remove the bobbin case.



6. Remove the bobbin from the bobbin case.

3 Set up the Machine

7. Insert the new bobbin so that the silver sensor surface lies inside the bobbin case.
8. Guide the thread through the slot to the left.




9. Pull the thread through under the spring and under the two thread guides.



10. When inserting the bobbin case, hold the bobbin case so that the wire of the thread guide points upward.
11. Insert the bobbin case. Press the left side of the bobbin case until the bobbin case engages.



12. Pull the thread over the thread cutter and cut.



13. Close the bobbin cover.
14. Unlock the screen.


TIP

By tapping the icon **Bobbin Thread**  instructions are displayed on how to insert the bobbin thread bobbin into the bobbin case.

3.14 Presser Foot

Changing the Presser Foot


1. Raise the needle.
2. Raise the presser foot.
3. Lock the screen.
4. Press the clamping lever up and pull the presser foot downward to the side.



5. Guide the new presser foot into the holder from below and press the clamping lever down.
6. Unlock the screen.

Attach the BERNINA Stitch Regulator (BSR)

1. Lock the screen.
2. Attach the BSR Presser Foot.



3. Insert the cable of the presser foot into the BSR connection.



4. Unlock the screen.
 - ⇒ The **BSR Mode** function is switched on and the BSR Settings are displayed.

Presser Foot Pressure

Sewing ► Presser Foot Pressure


The presser foot pressure has a default setting for working with medium fabrics. When working with thick fabrics, a reduced presser foot pressure enables the fabric to be moved more easily beneath the presser foot. When working with thin fabrics, a higher presser foot pressure prevents the fabric from slipping easily.

We recommend testing the setting before you start. If the fabric moves with some resistance, you can reduce the presser foot pressure. If the fabric slips easily beneath the presser foot, you can increase the presser foot pressure.

Recommendations for setting the presser foot pressure for different types of fabric and sewing techniques can be found in the consultant. ► see page 21]

Presser Foot Selection

Sewing ► Presser Foot



1 Recommended Presser Foot 2 Presser Foot Overview 3 Recommended 4 Search

Presser Foot Selection in the Status Bar recommends the appropriate Presser Foot based on the currently selected stitch pattern or embroidery design.

The presser feet compatible with the machine are displayed in the **Presser Foot Overview** section.

Recommended presser feet are marked with the **Recommended** ★ icon.

In order for the machine to check the compatibility of the stitch, presser foot, needle and stitch plate, you must select the attached presser foot in the **Presser Foot Overview** section. The selected presser foot is displayed in the status bar.

If the stitch pattern or the embroidery design is not compatible with the selected presser foot, this can lead to collisions - an error message will appear, the stitch in the stitch preview is shown in red and the machine does not start.

Search

With the **Search** function, you can search for the attached presser foot by entering the presser foot number.

Recommended

With the **Recommended** ★ function, you can filter the overview by recommended presser feet.

3.15 Fabric Feed

Feed Dog

Sewing  ► Feed Dog 

The feed dog moves the fabric under the presser foot. To ensure that the fabric is fed evenly, the presser foot must be positioned horizontally. To compensate for the seam height, you can place one or more height compensation plates behind or in front of the needle under the presser foot as required.

The feed dog can be lowered for applications in which the fabric is to be guided freely.

1. To lower the feed dog, press the button **Feed Dog Up/Down**.



2. To raise the feed dog, unlock the button **Feed Dog Up/Down**.

⇒ The feed dog is fully raised after sewing the first stitch.



TIP

Tapping the icon **Feed Dog**  displays instructions on how to lower or raise the feed dog.

Dual Feed

The BERNINA Dual Feed feeds the upper fabric while the feed dog controls the bottom layer. This ensures a more even feed for many applications, including:

- Sewing seams and zippers
- Managing difficult fabrics such as: velvet, satins
- Matching pattern repeats, stripes and checks
- Knits and Fleece
- Patchwork: Accurate piecing, quilting and binding

Note: The BERNINA Dual Feed can only be used with presser feet with the designation D.

Switching On/Off the BERNINA Dual Feed


Engaging the BERNINA Dual Feed

1. Raise the presser foot.
2. Attach a D presser foot.
3. Push the dual feed down until it engages.



Disengaging the BERNINA Dual Feed

1. Raise the presser foot.
2. Pull the dual feed downward and let it slide backward and up.



3.16 Embroidery Module

Connecting and Removing the Embroidery Module

Connecting the Embroidery Module

Prerequisite:

- The work area is large enough and has sufficient load-bearing capacity for the machine and the embroidery module.
- There is enough space for the embroidery arm to move freely.

1. Lift the embroidery module on the left side.
2. Push and lower the embroidery module carefully from left to right into the embroidery module connection of the machine.



NOTICE

Lifting or moving the machine when the Embroidery Module is connected

Damage to the embroidery module connection and machine.

- ▶ Before lifting or moving the machine, detach the embroidery module.

Removing the Embroidery Module


- ▶ Lift the embroidery module on the left side and carefully pull it to the left.

Preparing the Embroidery Hoop

Prepare the embroidery hoop according to the hoop instructions. You can download the instructions for embroidery hoops at www.bernina.com.

Attaching and Removing the Hoop

Attaching the Hoop



1 Attaching Mechanism 2 Hoop


1. Raise the needle.
2. Raise the presser foot.
3. Hold the hoop with the right side of the fabric up with the attaching mechanism to the left.
4. Position the hoop below the presser foot.
5. Squeeze both attaching mechanisms of the hoop towards each other.
6. Position the embroidery hoop above the bracket of the embroidery arm.
7. Press the hoop down until it clicks in position.
8. Release the attaching mechanism.
9. Select the embroidery hoop on the machine. [▶ see page 39]
10. Before using the embroidery hoop for the first time or if the needle position and the center of the embroidery hoop are not aligned, calibrate the embroidery hoop on the machine. [▶ see page 43]

Removing the Embroidery Hoop

1. Squeeze both attaching mechanisms of the hoop towards each other.
2. Remove the hoop.

Hoop Overview

Embroidery ► Hoop



- 1 Attached Embroidery Hoop 2 Hoop Relocation
3 Hoop Selection

Attached Embroidery Hoop

The attached embroidery hoop is recognized automatically by the machine. The name of the recognized embroidery hoop is displayed in yellow in the status bar.

If no embroidery hoop has been attached, an embroidery hoop matching the size of the embroidery design is preselected in the **Hoop Selection** section. The selected embroidery hoop is displayed in the status bar.

Hoop Relocation

In the **Hoop Relocation** area, you can move the attached hoop to certain positions.

- **Centered** : To thread the needle more easily.
- **At the Rear** : To facilitate access to the hook area.
- **Sewing Position** : For sewing without having to remove the embroidery module. If a hoop is attached, you will be prompted to remove the hoop.

Hoop Selection

The hoops compatible with the machine are displayed in the **Hoop Selection** section.

To prepare the embroidery design, you can select a suitable embroidery hoop before attaching the hoop.

3.17 Machine Settings

Language

Settings ► Machine ► Language

With the **Language** setting, you can set the language of the user interface.

Lighting

Settings ► Machine ► Display and Lighting
► Lighting

Use the settings **Lighting** to switch the sewing light on and off and adjust the brightness of the sewing light.

Display Brightness

Settings ► Machine ► Display and Lighting
► Display Brightness

With the **Display Brightness** setting, you can adjust the brightness of the screen.

Identification

Settings ► Machine ► Information ► Identification

You can display network information about the machine in the **Identification** area.

With the **Machine Name** setting, you can enter the name under which the machine is displayed in a WiFi network.

My Dealer Information

Settings ► Machine ► Information ► My Dealer Information

With the **My Dealer Information** setting, you can enter the address of your BERNINA dealer for quick reference at any time.

Data Usage

Settings ► Machine ► Information ► Data Usage

With the setting **Data Usage** you can agree or object to the use of anonymized usage data by BERNINA for product improvement.

WiFi Connection

Settings  ► Machine  ► WiFi Connection 

You can connect the machine to a WiFi network. This allows you to transfer embroidery designs from the BERNINA embroidery software to the machine or follow the embroidery process on the BERNINA Stitchout App. With the **WiFi**  setting, you can switch the WiFi connection on and off. The machine indicates the network to which it is connected.

All available networks are displayed in the **Available Networks (2.4 GHz)**  list. You can connect the machine to any available network. In the case of protected networks, you must sign in with a password. Once you have set up the WiFi connection, you can switch the WiFi connection on and off via the status bar.

Sound

Settings  ► Machine  ► Sound 

With the setting **Sound** , you can generally activate and deactivate the acoustic signals.

If acoustic signals are activated in general, you can make the following adjustments:

- **File Selection** : To select different acoustic signals and to switch the acoustic signal on and off.
- **Functions and Icons** : To select different acoustic signals and activate and deactivate the acoustic signal.
- **Stitch Regulation** : Activate and deactivate the acoustic signal.

Monitoring Functions

Settings  ► Monitoring Functions 

The machine has monitoring sensors, which issue a warning if the upper thread or lower thread is broken or has run out. With the **Monitoring Functions**  setting, you can switch the Upper Thread Indicator and the Bobbin Thread Indicator on or off.

Machine Data

Settings  ► Machine  ► Information 
► Machine Data 

In the area **Machine Data** , the firmware and machine data are displayed.

3.18 Personal Settings

Welcome Message

Settings  ► Personal  ► Welcome Message

With the **Welcome Message** setting, you can enter a text to be displayed when the machine is switched on.

Background Color

Settings  ► Personal  ► Background Color

With the **Background Color** setting, you can select a color scheme for your screen.

Background Pattern

Settings  ► Personal  ► Background Pattern

With the setting **Background Pattern** you can select a color scheme for your screen.

3.19 Sewing Settings

Upper Thread Tension

Settings  ► Sewing  ► Upper Thread Tension 

The upper thread tension is set optimally at the BERNINA factory. Mettler Metrosene/Serlon thread size 100/2 is used for the upper and bobbin thread.

If you use different types of sewing threads, the upper thread tension may vary. You can override the default setting based on thread and fabric you are using in the Upper Thread Tension in the Sewing Settings. This modification is made to all sewing patterns and kept until changed again in the Settings, even after a machine restart.

The higher the upper thread tension is set, the tighter the upper thread is tensioned, and the bobbin thread is pulled deeper into the fabric. The lower the setting the lower the upper thread is tensioned, and the bobbin thread is pulled less deeply into the fabric.



Perfect Stitch Formation

The thread knotting is in the center of the fabric.



Upper thread tension too tight

This pulls the bobbin thread more strongly into the fabric.



Upper thread tension too loose

This pulls the upper thread more strongly into the fabric.

TIP

If the sewing test shows that the upper thread tension is not optimal for a stitch pattern, you can modify the upper thread tension for the selected stitch pattern using the **Upper Thread Tension**  function in the Status Bar.

Sewing Speed

Settings  ► Sewing  ► Sewing Speed 

With the **Sewing Speed**  function, you can limit the maximum sewing speed. The setting is saved when the machine is switched off.

The sewing speed is specified in stitches per minute. The maximum sewing speed is 1000 stitches per minute.

Securing Stitches

Settings  ► Sewing  ► Securing Stitches 

With the **Securing Stitches**  function, you can set whether securing stitches should be sewn automatically upon starting sewing.

External Buttons

Settings  ► Sewing  ► External Buttons 

With the **External Buttons**  function, you can program additional functions for the following buttons:

- **Presser Foot Up/Down** 
- **Thread Cutter** 
- **Quick Reverse** 
- **Tie-Off** 
- **Needle Stop** 
- **Pattern End** 

Presser Foot Up/Down

Settings  ► Sewing  ► External Buttons 
► **Presser Foot Up/Down** 

With the **Presser Foot Height** function, you can set the height to which the presser foot is raised when the **Presser Foot Up/Down**  button is pressed. Depending on the material thickness, you can raise the presser foot to 0 – 7 mm.

Thread Cutter

Settings  ► Sewing  ► External Buttons 
► **Thread Cutter** 

With the **Thread Cutter**  setting, you can specify whether additional securing stitches are sewn when the button **Thread Cutter**  is pressed.

Tie-Off

With the **Tie-Off**  function, you can switch the sewing of securing stitches on and off.

Securing Stitches

If the function **Tie-Off**  is activated, you can define the way how the securing stitches are sewn. The following options are available:

- **Secure in Place** : The securing stitches are sewn on the spot.
- **Running Stitches** : Short securing stitches are sewn one after the other.
If you have selected the **Running Stitches**  setting, you can set the count of securing stitches.

Quick Reverse

Settings  ► Sewing  ► External Buttons  ► **Quick Reverse** 

With the **Quick Reverse**  function, you can set how the machine sews in reverse when the **Quick Reverse**  button is pressed. The following functions are available:

- **Reverse** : The machine sews in reverse.
- **Backstep** : The machine sews the stitch pattern in reverse stitch by stitch according to the stitches sewn. This setting is particularly suitable for decorative stitches.

Tie-Off

Settings  ▶ Sewing  ▶ External Buttons  ▶ Tie-Off 

With the **Tie-Off**  function, you can set which function is carried out when the **Tie-Off**  button is pressed. The following functions are available:

- **Secure in Place** : The securing stitches are sewn on the spot.
- **Running Stitches** : Short securing stitches are sewn one after the other.
If you have selected the **Running Stitches**  setting, you can set the count of securing stitches.

Presser Foot Hover Position

Settings  ▶ Sewing  ▶ External Buttons  ▶ Needle Stop 

With the **Presser Foot Hover Position** function, you can set how high the presser foot is raised when the machine stops with the needle position down. The following options are available:

- **Low**: The presser foot remains lowered.
- **Medium**: The presser foot is raised to medium height.
- **High**: The presser foot is raised.

Pattern End

Settings  ▶ Sewing  ▶ External Buttons  ▶ Pattern End 

With the setting **Pattern End** , you can specify which additional functions are performed when the button **Pattern End**  is pressed. The following functions are available:

- **Tie-Off** 
- **Cut Upper and Lower Thread** 
- **Raise Presser Foot** 

You can combine the functions with each other.

Tie-Off

With the **Tie-Off**  function, you can switch the sewing of securing stitches on and off.

Securing Stitches

If the function **Tie-Off**  is activated, you can define the way how the securing stitches are sewn. The following options are available:

- **Secure in Place** : The securing stitches are sewn on the spot.
- **Running Stitches** : Short securing stitches are sewn one after the other.

If you have selected the **Running Stitches**  setting, you can set the count of securing stitches.

Cut Upper and Lower Thread

With the **Cut Upper and Lower Thread**  function, you can switch the thread cut on and off.

Raise Presser Foot

With the **Raise Presser Foot**  function, you can switch the raising of the presser foot on and off.

Foot Control

Settings  ▶ Sewing  ▶ Foot Control 

The default setting **Needle Up/Down**  is set for the back kick on the foot control. You can switch the standard function off and on or switch on and set a combination of the following functions:

Tie-Off

With the **Tie-Off**  function, you can switch the sewing of securing stitches on and off.

Securing Stitches

If the function **Tie-Off**  is activated, you can define the way how the securing stitches are sewn. The following options are available:

- **Secure in Place** : The securing stitches are sewn on the spot.
- **Running Stitches** : Short securing stitches are sewn one after the other.
If you have selected the **Running Stitches**  setting, you can set the count of securing stitches.

Cut Upper and Lower Thread

With the **Cut Upper and Lower Thread**  function, you can switch the thread cut on and off.

Raise Presser Foot

With the **Raise Presser Foot**  function, you can switch the raising of the presser foot on and off.

3.20 Embroidery Settings

Upper Thread Tension

Settings  ► Embroidery  ► Upper Thread Tension 

The upper thread tension is set optimally at the BERNINA factory. Mettler Metrosene/Serlon thread size 100/2 is used for the upper and bobbin thread.

If you use different types of sewing threads, the upper thread tension may vary. You can override the default setting in the Embroidery Settings. This modification is made to all embroidery designs and kept until changed again in the Settings, even after a machine restart.

The higher the upper thread tension is set, the tighter the upper thread is tensioned, and the bobbin thread is pulled deeper into the fabric. The lower the setting the lower the upper thread is tensioned, and the bobbin thread is pulled less deeply into the fabric.

TIP

If the embroidery test shows that the upper thread tension is not optimal for an embroidery design, you can modify the upper thread tension for the selected embroidery design using the **Upper Thread Tension**  function in the Status Bar.

For a higher bobbin thread tension, use a bobbin case with a high thread tension (HTTBC).

Embroidery Speed

Settings  ► Embroidery  ► Embroidery Speed 

The embroidery speed is specified in stitches per minute. The maximum embroidery speed is 1000 stitches per minute.

With the **Embroidery Speed**  setting, you can limit the maximum embroidery speed. The setting is saved when the machine is switched off.

TIP

You can also modify the embroidery speed during stitching using the foot control or the slide speed control. You can switch on the maximum embroidery speed for the current embroidery design while embroidering using the function **High Speed** .

Thread Cutting

Settings  ► Embroidery  ► Thread Cutting 

With the **Thread Cutting**  function, you can activate and deactivate the thread cut. The following options are available:

- **On Jump Stitch** : The thread is cut automatically with connecting stitches.
When this option is activated, you can specify at what connecting stitch length the thread should be cut.
- **On Thread Change** : The thread is cut automatically each time the thread is changed.
- **Thread Cut After Start** : When this function is activated, the machine stops after a few stitches and you can cut the thread end manually.

Thread Away

Settings  ► Embroidery  ► Thread Away 

With the **Thread Away**  function, you can set cut threads to be pulled to the rear of the fabric for cleaner embroidery on the top.

For embroidery designs with long stitches, it is recommended to switch off the function because the presser foot could get caught in the long stitches due to the rapid movement of the embroidery arm. The same risk applies when working with appliqué, water-soluble non-woven materials or other raised decorations such as buttons.

The **Thread Away**  function should not be used if the **Thread Cutting**  function is switched off.

Calibrating the Hoop

Settings  ► Embroidery  ► Hoop Calibration 

Hoops must be calibrated when new and after every machine firmware update.

With the **Hoop Calibration**  function, you can calibrate all hoops.

1. Hoop the fabric with non-woven material.
2. Place the template in the inner hoop onto the fabric.
3. Attach the hoop.
 - ⇒ The machine recognizes the attached embroidery hoop and displays it in the Status Bar.
4. Activate the **Hoop Calibration**  function.
5. Activate the function **Laser** .
 - ⇒ The laser indicates the exact position of the needle.

6. If the needle is not positioned exactly at the center of the template, center the needle using the arrow buttons.
7. Confirm the hoop calibration.

The setting is saved when the machine is switched off. With the **Reset Calibration**  function, you can delete an existing calibration.

Quilt Settings

Settings  ► Embroidery  ► Quilt Settings 

With the **Quilt Settings**  setting, you can set the stitch length for Customizable Quilt Designs in stitches per inch (SPI).

Unit of Measurement

Settings  ► Embroidery  ► Unit of Measurement 

With the **Unit of Measurement**  function, you can set the preferred measurement, either mm or inches. The embroidery size is shown in the selected measurement unit. The setting is saved when the machine is switched off.

Fabric Thickness

Settings  ► Embroidery  ► Fabric Thickness 

With the **Fabric Thickness**  function, you can set the thickness of the fabric. The set value affects the embroidery speed. The higher the value, the slower the machine embroiders so that the needle does not get stuck in thicker fabrics.

Securing Stitches

Settings  ► Embroidery  ► Securing Stitches 

Secure at Beginning

With the **Secure at Beginning**  function, you can switch the sewing of securing stitches at the beginning of the embroidery design on and off.

If an embroidery design has programmed securing stitches, the programmed securing stitches are sewn.

Secure at End

With the **Secure at End**  function, you can switch the securing stitches at the end of the embroidery design.

If an embroidery design has programmed securing stitches, the programmed securing stitches are sewn.

Design Position


Settings  ► Embroidery  ► Design Position 

With the **Design Position**  setting, you can set the standard positioning of the embroidery design in the hoop.

You can position the embroidery designs as follows:

- Function deactivated: The embroidery design is positioned in the center of the hoop.
- Function activated: The embroidery design is positioned at the stored position. The saved position corresponds either to the position of the embroidery design when saved in your Personal Folder or to the position saved in BERNINA Embroidery Software. The setting is saved when the machine is switched off.

Sewing



1 Status Bar 2 Needle Stop 3 Stitch Length 4 Stitch Width 5 Needle Position 6 Stitch Preview 7 Edit 8 Stitch Selection 9 View 10 Combi Mode

Needle Stop

The **Needle Stop**  icon shows the needle position when the machine is stopped.

-  : Needle Stop Up.
-  : Needle Stop Down.

You can set the needle position to stop up or down by toggling the icon.

Stitch Length

With the **Stitch Length** function, you can adjust the length of the current stitch. [▶ see page 55]

Stitch Width

With the **Stitch Width** function, you can adjust the width of the current stitch. [▶ see page 55]

Needle Position

If the needle has been moved to the left or right, the value of the needle position is displayed. You can move the needle position back to the middle position by tapping the icon **Needle Position** .

Stitch Preview

A preview of the current stitch or stitch pattern combination is displayed in the stitch preview. In combination mode, you can select the individual stitches in the stitch preview.

Edit

With the **Edit**  function, you can open the stitch pattern editing functions. [▶ see page 55]

View

With the **View**  function, you can adjust the view of the stitch pattern to the size of the display and to hide the virtual presser foot.

Combi Mode

With the **Combi Mode**  you can switch the Combi-mode on and off. [▶ see page 61]

4.1 Status Bar

The Status Bar displays the state of various functions. You can set or activate some functions directly via the respective icon. For other functions, you can call up additional settings via the icon.

The color of the icon shows the current state of the function.

- White: Default setting
- Yellow: Modified setting

WiFi

The icon **WiFi**  shows the strength of the WiFi connection.

In the Settings, you can switch the WiFi connection on or off or set up the WiFi connection. [▶ see page 40]

Upper Thread Tension

The **Upper Thread Tension**  icon shows the recommended upper thread tension for the selected stitch.

You can modify the upper thread tension for the selected stitch by tapping the **Upper Thread Tension**  icon. [▶ see page 40]

Presser Foot

The **Presser Foot**  status shows the recommended or selected presser foot.

You can open presser foot selection by tapping the icon. You can select the mounted presser foot in the presser foot selection. [▶ see page 36]

Presser Foot Pressure

The **Presser Foot Pressure**  icon shows the presser foot pressure.

You can open and change the presser foot selection by tapping the **Presser Foot Pressure**  icon. [▶ see page 36]

Stitch Plate and Sewing Needle

The icon **Stitch Plate and Sewing Needle**  indicates the selected needle and the selected stitch plate.

By tapping the icon, you can call up the needle and stitch plate overview and select the fitted needle and the fitted stitch plate. [▶ see page 30]

The icon **Stitch Plate and Sewing Needle**  turns yellow if a needle other than the standard needle has been selected. The name of the icon **Stitch Plate and Sewing Needle**  turns yellow if a stitch plate other than the standard stitch plate is selected.

Feed Dog

The **Feed Dog**  status shows the position of the feed dog.

- **Feed Dog**  (white): Feed Dog is up.
- **Feed Dog**  (yellow): Feed Dog is down.

Tapping the icon **Feed Dog**  displays an animation showing how the feed dog can be lowered/lifted.

Bobbin Thread

The **Bobbin Thread**  status shows the fill capacity of the lower thread bobbin.

- White: Fill level of the bobbin thread is sufficient.

As soon as the fill level of the bobbin thread falls below a certain value, a fill level indicator is also displayed.

- Fill level indicator flashes red: bobbin thread quantity is low.

By tapping the icon **Bobbin Thread** , an animation on how to thread the bobbin thread is displayed.

Laser


The **Laser**  icon shows the status of the laser.

- White: Laser off.
- Yellow: Laser on.

By tapping the icon, you can switch the laser on and off.

The laser indicates the next stitch point in sewing mode and the exact needle position in embroidery mode. Depending on the presser foot and needle position, the entry point may be concealed by the presser foot. To avoid the deflection of the laser with transparent presser feet, you can lower the presser foot before the sewing start, e.g. with the Knee Lifter.

4.2 Stitch Selection



- 1 Fullscreen
- 2 Navigation Bar
- 3 Selection Area
- 4 Quick Access Bar

Navigation Bar

The Navigation Bar shows the path to the selected stitch pattern.

Search

With the **Search**  function, you can search for stitch patterns by stitch number.

Selection Area

In the Selection Area, you can navigate through the folders and load a stitch pattern. Each stitch pattern is displayed with a preview image.

When you tap the desired stitch pattern in the preview, it is loaded.

Fullscreen

With the **Fullscreen**  function, you can enlarge the selection area to the full screen width.

Quick Access Bar

Via the quick access bar, you can directly access the various folders of the stitch categories and your own folder as well as display the history.

Practical Stitches

In the **Practical Stitches**  folder, you will find all practical stitches. [[▶ see page 48](#)]

Decorative Stitches

In the **Decorative Stitches**  folder, you will find all decorative stitches collated into folders by categories. [[▶ see page 51](#)]

Alphabets

In the **Alphabets**  folder, you will find all sewing alphabets. [[▶ see page 51](#)]

Buttonholes

In the **Buttonholes**  folder, you will find all buttonholes, eyelets and the Button Sew-on Program. [[▶ see page 52](#)]

Quilt Stitches

In the **Quilt Stitches**  folder, you will find all quilt stitches. [[▶ see page 54](#)]

Personal Folder


In the folder **Personal Folder** , you can save and load your own stitch pattern. You can organize the stitch patterns in folders.

History

With the **History**  function, you can display and choose the most recently sewn stitch patterns. The History is retained after restarting the machine.

5.1 Practical Stitches

Sewing  ► Practical Stitches 



Stitch patterns	Stitch number	Name	Purpose
	1	Straight Stitch	For joining seams, for topstitching and basting.
	2	Zigzag	For finishing, sewing knit seams, sewing on lace inserts and elastic bands.
	3	Vari-Overlock	For finishing edges, sewing together and finishing knit fabrics.
	4	Running Stitch	For darning and reinforcing fabric edges or attaching lace or elastic tape.
	5	Securing Program	For automatic securing at the start of the seam with forward and reverse stitches.
	6	Triple Straight Stitch	For reinforced seams on heavy fabrics, topstitching and decorative effects.
	7	Triple Zigzag	For durable seams on strong fabrics, visible hems and decorative seams.
	8	Honeycomb Stitch	For visible and decorative seams on knits and wovens.
	9	Blind Stitch	For blind hems on most fabric types and for shell edging on soft jerseys and fine fabric.
	10	Double Overlock	For sewing together and finishing knit fabrics.
	11	Superstretch Stitch	For very stretchy open seams.
	12	Gathering Stitch	For gathering with heavier threads and for flat joining seams on medium-weight fabrics.

Stitch patterns	Stitch number	Name	Purpose
	13	Stretch Overlock	For sewing together and finishing knit fabrics as well as for flat joining seams.
	14	Tricot Stitch	For visible hems and seams in lingerie and sweaters and for mending tricot fabric.
	15	Universal Stitch	For flat joining seams, visible hems and decorative seams in heavy fabrics such as felt and leather and for attaching elastic tape.
	16	Stitched Zigzag	For finishing and reinforcing fabric edges, for sewing on elastic tape and for decorative seams.
	17	Lycra Stitch	For flat joining seams, visible hems on lycra fabric and for stitching over seams in undergarments.
	18	Stretch Stitch	For stretchy seams and hems in woven and knit fabrics.
	19	Reinforced Overlock	For overlock seams or flat joining seams on medium-weight knit fabrics and toweling.
	20	Knit Overlock	For stretchy seams and hems in woven and knit fabrics.
	21	Basting Stitch	For tacking seams, hems and for quilting projects.
	22	Simple Darning Program	For automatic darning in fine to heavy fabrics.
	23	Reinforced Darning Program	For automatic darning in heavy materials.
	24	Bartack Program	For reinforcing pocket openings, buttonholes and sewing belt loops.
	25	Bartack Program	For reinforcing pocket openings and securing seam ends.
	26	Large Fly Stitch	For reinforcing pocket openings, zippers and slits in medium-weight to heavy fabrics.
	27	Small Fly Stitch	For reinforcing pocket openings, zippers and slits in fine to medium-weight fabrics.
	29	Narrow Blind Stitch	For blind hems and shell edging in fine and soft fabrics.

Stitch patterns	Stitch number	Name	Purpose
	31	Triple Straight Stitch with Long Stitch	For durable seams in heavy fabrics, e.g. visible and decorative seams.
	32	Single Straight Stitch	As a connecting stitch in a combination of one straight stitch.
	33	Three Single Straight Stitches	As connecting stitches in a combination of three individual straight stitches.
	34	Darning Stitch	For darning.
	35	Open Overlock Stitch	For sewing together and finishing knit fabrics with a reinforced edge.
	36	Overlock	For medium-weight knit fabrics.
	37	Reinforced Overlock Stitch	For sewing together and finishing knit fabrics.
	38	Chain Stitch	For decorative and reinforcing stitches on most woven fabrics.
	39	Cover Stitch Effect	To sew decorative seams and hems in heavy knits and woven fabrics.
	40	Cover Stitch Effect	To sew decorative seams and hems in heavy knits and woven fabrics.

5.2 Decorative Stitches

Sewing  ► Decorative Stitches 



Category	Name
100 	Nature
300 	Cross Stitches
400 	Satin
600 	Geometric
700 	Heirloom
900 	Children
1100 	Special
1700 	International
2000 	Seasons

Category	Name
2200 	Sport and Hobbies

5.3 Alphabets


Sewing  ► Alphabets **A**



Stitch Patterns	Name
ABCabc	Block
ABCabc	Comic
あいう	Hiragana
アイウ	Katakana
АБВабв	Cyrillic
<i>АБВ абв</i>	Cyrillic Italic
ABC abc	Quilt
<i>ABC abc</i>	Script Italic
ABCabc	Double Block

5.4 Buttonholes

Sewing  ► Buttonholes 



Stitch patterns	Stitch number	Name	Purpose
	51	Standard Buttonhole	For light to medium-weight fabrics. e.g. blouses, dresses and bed linen.
	52	Narrow Standard Buttonhole	For light to medium-weight fabrics, e.g. blouses, dresses, children's and baby clothes, crafts.
	53	Stretch Buttonhole	For all knit fabrics.
	54	Round Buttonhole with Normal Bartack	For medium-weight to heavy fabrics. e.g. dresses, jackets, coats and rainwear.
	55	Round Buttonhole with Horizontal Bartack	For medium-weight to heavy fabrics, with a reinforced bar, e.g. dresses, jackets, coats and rainwear.
	56	Keyhole Buttonhole	For heavy woven fabrics, e.g. jackets, coats and leisure wear.
	57	Keyhole Buttonhole with Pointed Bartack	For stronger, woven fabrics, e.g. jackets, jeans coats and leisurewear.
	58	Keyhole Buttonhole with Horizontal Bartack	For heavy woven fabrics, e.g. jackets, coats and leisurewear.
	59	Straight Stitch Buttonhole	For staystitching and reinforcing buttonholes and as buttonhole edging, especially for buttonholes in leather and imitation leather.
	63	Heirloom Buttonhole	For handlook stitching effects on clothes and handicrafts on light to medium-weight fabrics.
	64	Double-rounded Buttonhole	For medium-weight to heavy fabrics.

Stitch patterns	Stitch number	Name	Purpose
	65	Double-rounded Heirloom Buttonhole	For light to medium-weight, woven fabrics. e.g. blouses, dresses and bed linens.
	67	Round Buttonhole with Bartack	For medium-weight woven fabrics, e.g. blouses, dresses and jackets.
	68	Decorative Keyhole Buttonhole with Horizontal Bartack	For stronger, woven fabrics, e.g. jackets, coats and leisurewear.
	69	Decorative Buttonhole with Double Pointed Bartack	For decorative buttonholes in firmer woven fabrics.
	70	Decorative Stretch Buttonhole	For decorative buttonholes in light to medium-weight knit fabrics.
	60	Button Sew-on Program	Sews buttons with 2 or 4 holes.
	61	Small Zigzag Eyelet	Openings for cords or narrow ribbons and for decorative work.
	62	Straight Stitch Eyelet	Openings for cords or narrow ribbons and for decorative work.


5.5 Quilt Stitches

Sewing  ► Quilt Stitches 



Stitch	Number	Name	Purpose
	No. 1301	Quilting, Securing Program	To secure at the sewing start and end with short stitches forward.
	No. 1302	Quilting, Straight Stitch	For machine quilting using a straight stitch with a 3 mm stitch length.
	No. 1303	Piecing Stitch/Straight Stitch	For piecing quilt blocks together using a straight stitch with a 2 mm stitch length.
	No. 1304 – 1308	Hand-look Quilt Stitches	For imitating the look of hand quilting with monofilament thread.
	No. 1309 – 1312	Blanket Stitch	For appliqué.
	No. 1313 – 1314	Blanket Stitch	For sewing on the edge between two areas in crazy patchwork.
	No. 1315	Satin Stitch	For appliqué with more distinct seams.
	No. 1316	Narrow Blind Stitch	For edging and appliqué with minimally visible seams.
	No. 1317 – 1330	Decorative Quilting Stitches	For quilting, crazy patchwork, embellishing and finishing.
	No. 1331	Stippling Stitch	For quilting, crazy patchwork, embellishing and finishing.
	No. 1332 – 1338	Feather Stitch	For quilting, crazy patchwork, embellishing and finishing.
	No. 1339 – 1346	Decorative Quilting Stitches	For quilting, crazy patchwork, embellishing and finishing.
	No. 1363 – 1394	Decorative Quilting Stitches	For quilting, crazy patchwork, embellishing and finishing.

6.1 Load Stitch Pattern



1 Selection Area 2 Quick Access Bar

1. Tap the stitch category in the Quick Access Bar.
2. Find and select the desired stitch pattern in the selection area.
 - ⇒ The stitch pattern is displayed in the stitch preview.

Further information on the selection area can be found in the stitch selection. [▶ see page 46]

6.2 Stitch Pattern Editing

Stitch Width



The recommended stitch width is indicated for each stitch. You can modify the stitch width for most stitches, alphabets and buttonholes. The stitch width depends on the needle used, the presser foot and the stitch plate.

The machine checks the compatibility between the needle, stitch plate and stitch. To do this, the attached stitch plate and needle must be selected in the Status Bar with the **Stitch Plate and Sewing Needle** icon. If the stitch cannot be sewn with the fitted needle and the fitted stitch plate, the stitch is displayed in red.

TIP

You can also modify the stitch width during sewing with the Upper Multi-function Knob.

Stitch Length



The recommended stitch length is indicated for each stitch. You can modify the stitch length for most stitches, alphabets and buttonholes.

With decorative stitches, alphabets and stitch pattern combinations, the pattern length is displayed instead of the stitch length.



TIP

You can also modify the stitch length during sewing with the Lower Multi-function Knob.

Editing Functions

Sewing  ► Edit 



With the **Edit**  function, you can view the editing functions for the selected stitch.

Repeat

Sewing  ► Edit  ► Repeat 

With the **Repeat**  function, you can set the number of repeats of a stitch pattern after which the machine should stop. You can set up to 99 repeats. The number of repeats still to be sewn is displayed on the Sewing Screen.

If you tap and hold the **Repeat**  button, the function is switched off.

Mirror Left/Right

Sewing  ► Edit  ► Mirror Left/Right 

With the **Mirror Left/Right**  function, you can mirror a stitch pattern along the vertical axis.

Mirror Up/Down

Sewing  ► Edit  ► Mirror Up/Down 

With the **Mirror Up/Down**  function, you can mirror a stitch pattern along the horizontal axis.

Stitch Counter

Sewing  ► Edit  ► Stitch Counter 


With the **Stitch Counter**  function, you can save the length of a seam for some stitch patterns based on the count of stitches sewn. The number of stitches counted is displayed on the Sewing Screen and saved until the machine is switched off. [► see page 57]

Balance

Sewing  ► Edit  ► Balance 

With the **Balance**  function, you can fine tune any stitch patterns that are not sewn correctly due to the selected fabric.

Compare a sewn sample with the display in the **Stitch Preview** section and adjust the balance so that the preview corresponds to the incorrectly sewn stitch pattern.



Stitch Pattern Length

Sewing  ► Edit ► Stitch Pattern Length

With the **Stitch Pattern Length**  function, you can enlarge or decrease the size of the stitch pattern.

TIP

To adjust satin stitches so that they can be sewn larger, also change the stitch density. [► see page 56]

Stitch Density

Sewing  ► Edit ► Stitch Pattern Length ► Stitch Density

You can use the **Stitch Density**  function to change the stitch density for some decorative satin stitches (e.g.) by adjusting the stitch distance.

- If you increase the stitch spacing, the stitch density is reduced and the threads are further away.
- If you reduce the stitch spacing, the stitch density increases and the threads are closer together.

The length of the stitch pattern is not affected.

Triple Stitch

Sewing  ► Edit ► Triple Stitch

With the **Triple Stitch**  function, triple stitches are sewn three times (forward-backward-forward) for more pronounced or reinforced stitching. Not applicable with satin and some decorative stitches.

TIP

This function is particularly suitable for topstitching with decorative seams if you do not have a thicker thread available. If you are using a thick thread in a contrasting color, this will produce a striking, decorative seam.

Long Stitch

Sewing ► Edit ► Long Stitch

With the **Long Stitch** function, the machine only sews every second stitch.

You can use the **Long Stitch** function to create new stitch patterns. Satin stitches are not changed. If you combine the **Long Stitch** function with the straight stitch, you can easily create basted seams. At a stitch length of 6 mm, the machine sews 12 mm long basting stitches.

Alphabet Font Size

Sewing ► Edit ► Alphabet Font Size

You can use the **Alphabet Font Size** function to set the font size of selected alphabets.

Reverse

Sewing ► Edit ► Reverse

With the **Reverse** function, you can sew in reverse without pressing and holding the **Quick Reverse** button.

Backstep

Sewing ► Edit ► Backstep

With the **Backstep** function, you can perform precise backwards stitching. The machine ensures that the stitches sewn in reverse are sewn precisely over the stitches sewn forward. This allows you to secure decorative stitches or make individual stitch patterns bolder by sewing over them several times.

New Default

Sewing ► Edit ► New Default

With the **New Default** function, you can save a modified stitch pattern as the new standard setting. Each time you select the stitch pattern in the selection area, it will be opened with the new settings.

Back to Default

Sewing ► Edit ► Back to Default

If you load a stitch with new default settings, the changed settings and the **Edit** icon are displayed in yellow on the sewing screen.

With the **Back to Default** function, you can reset the settings of the stitch pattern to the factory default.

Using the Stitch Counter

Sewing ► Edit ► Stitch Counter

Prerequisite:

- A stitch pattern is selected.

1. Tap the **Stitch Counter**

⇒ In the info bar the **Stitch Counter** and **Repeat** icons are shown and the **Quick Reverse** icon flashes.



2. Sew the desired length.

3. Press the button **Quick Reverse** .

⇒ The **Stitch Counter** display changes to **AUTO** and shows the length of the saved seam.

⇒ As soon as the stitch pattern is sewn again, the machine stops after the saved stitch number.

⇒ The stitch count is saved until it is overwritten or cleared.


4. To access the saved stitch count after deactivating the function, tap the **Stitch Counter** icon twice, until **AUTO** appears.



6.3 Buttonholes

For buttonholes, you can set the buttonhole length and width. As soon as a buttonhole stitch is loaded, the buttonhole options are displayed in the editing functions.

The selected mode or the programmed buttonhole length is displayed on the sewing screen.



Buttonhole Length

Sewing ► Edit *i*



To set the buttonhole length, the following modes are available:

- **Record mm** ^{mm}REC : Program the buttonhole length in mm. [► see page 58]
- **Auto Length** ^{19.0}: Adjust the buttonhole length to the button size. [► see page 58]
- **Stitch Counter** ¹²³REC : Program the buttonhole length with the stitch counter. [► see page 58]
- **Sew Manually** ^{man}: Sew the buttonhole manually. [► see page 59]

Record the Buttonhole Length in mm

Sewing ► Edit *i* ► Record mm ^{mm}REC

In the mode **Record mm** ^{mm}REC, the machine measures the sewn length of the first bead and saves it. The machine finishes the buttonhole automatically.

Prerequisite:

- A buttonhole is loaded.
- Buttonhole Foot #3A is attached.


1. Tap the **Record mm** ^{mm}REC icon.
 - ⇒ The **Reverse** icon flashes on the Sewing Screen.

2. Sew the first bead and press the **Quick Reverse** button at the desired length.
 - ⇒ The machine will complete the buttonhole.
 - ⇒ The machine switches to **Button Size** ^{19.0} mode and all additional buttonholes are automatically sewn to the displayed length in mm.
 - ⇒ The buttonhole length remains saved until it is overwritten, cleared or the machine is switched off.

Adjusting the Buttonhole Length to the Button Size

Sewing ► Edit *i* ► Auto Length ^{19.0}

In the mode **Auto Length** ^{19.0}, you can measure the diameter of the button. The machine automatically adjusts the length of the buttonhole to the size of the button.



Prerequisite:

- A buttonhole is loaded.
- Buttonhole Foot #3A is attached.

1. Tap the **Auto Length** ^{19.0} icon.
2. Place the button in the measuring circle on the screen and adjust the size of the measuring circle to the size of the button.
 - ⇒ The measured buttonhole length is displayed in the Sewing Screen.
3. Sew the buttonhole.
 - ⇒ The buttonhole length remains saved until it is overwritten, cleared or the machine is switched off.

Programming the Buttonhole Length with the Stitch Counter

Sewing ► Edit *i* ► Stitch Counter ¹²³REC

Using the Buttonhole Foot #3, you can program the buttonhole length in mode **Stitch Counter** ¹²³REC. The machine sews the left bead forward, the lower bartack, the right bead in reverse and finally the upper bartack.

The length of the right bead is not automatically adjusted to the length of the left bead, but must be separately programmed.


Prerequisite:

- A buttonhole is loaded.
 - Buttonhole Foot #3 is attached.
1. Tap the **Stitch Counter**  icon.
 2. Sew the left bead and stop at the desired length.
 - ⇒ The **Reverse**  icon flashes on the Sewing Screen.
 3. Press the **Quick Reverse**  button.
 - ⇒ The machine sews the lower bartack and starts to sew the right bead in reverse.
 - ⇒ The **Reverse**  icon flashes on the Sewing Screen.
 4. Stop the left bead at the height of the first stitch and press the **Quick Reverse**  button.
 - ⇒ The machine sews the upper bartack.
 - ⇒ The lengths of the beads are saved.
 - ⇒ All additional buttonholes are sewn with the saved count of stitches.
 - ⇒ The buttonhole length remains saved until it is overwritten, cleared or the machine is switched off.

Sewing a Buttonhole Manually

Sewing  ► Edit  ► Sew Manually 

In the mode **Sew Manually** , you can sew buttonholes segment by segment. The individual segments of the buttonhole are displayed in the Buttonhole bar. Every time you have sewn a segment, you can move to the next segment by pressing the **Quick Reverse**  button.



1 Buttonhole Bar

Prerequisite:


- A buttonhole is loaded.
- Buttonhole Foot #3 is attached.

1. Tap the **Sew Manually**  icon.
 - ⇒ The individual segments are displayed in the Buttonhole bar.
 - ⇒ Segment 1 is active.
2. Sew the left buttonhole bead and stop the machine at the desired length.
 - ⇒ Segment 2 is active during sewing.
3. To switch to the next segment, tap the **Quick Reverse**  button or stop the machine and select the next segment in the buttonhole bar.
4. Finish sewing the buttonhole segment by segment.

Slit Width

Sewing  ► Edit  ► Slit Width 

With the **Slit Width**  function, you can set the width of the slit between 0.1 and 2.0 mm. If you make a significant change to the slit width, you may also have to adjust the stitch width and the stitch length.




TIP

Set a wide slit width for thick buttons on heavy fabrics. To reinforce the buttonhole, increase the stitch width and shorten the stitch length.

Set a narrow slit width for thin buttons on light fabrics. To make the buttonhole lighter, reduce the stitch width and increase the stitch length.

6.4 Darning Program

You can set the darning length in the darning program. As soon as a darning stitch is selected, the modes for the darning length are displayed in the editing menu. The selected mode or the programmed darning length is displayed on the sewing screen.



Darning Length

Sewing ► Edit

To set the darning length, the following modes are available:

For Simple Darning Program No. 22:

- **Stitch Counter** ¹²³/_{REC} : Program the darning length with the stitch counter. [► see page 60]

For Reinforced Darning Program No. 23:

- **Record mm** ^{mm}/_{REC} : Program the darning length in mm. [► see page 60]
- **Auto Length** ^{20.0}/_{REC} : Set the auto darning length. [► see page 60]

Sewing the Darning Length with the Stitch Counter

Sewing ► Edit ► **Stitch Counter** ¹²³/_{REC}

In the mode **Stitch Counter** ¹²³/_{REC}, the machine counts the stitches of the first-sewn length and saves it. The machine finishes the darning program automatically.

Prerequisite:

- The Darning Program No. 22 is loaded.
- Presser foot #1 is attached.

1. Tap the **Stitch Counter** ¹²³/_{REC} icon.
 - ⇒ The **Reverse** icon flashes on the Sewing Screen.

2. Sew the first row and press the **Quick Reverse** button at the desired length.
 - ⇒ The machine will complete the darning program.
 - ⇒ The darning length remains saved until it is overwritten, cleared or the machine is switched off.

Record the Darning Length in mm

Sewing ► Edit ► **Record mm** ^{mm}/_{REC}

In the mode **Record mm** ^{mm}/_{REC}, the machine measures the sewn length and saves it. The machine finishes the darning program automatically.

Prerequisite:

- The Darning Program No. 23 is loaded.
- Buttonhole Foot #3A is attached.

1. Tap the **Record mm** ^{mm}/_{REC} icon.
 - ⇒ The **Reverse** icon flashes on the Sewing Screen.
2. Sew the first row and press the **Quick Reverse** button at the desired length.
 - ⇒ The machine will complete the darning program.
 - ⇒ The darning length remains saved until it is overwritten, cleared or the machine is switched off.

Sew the Darning Length Automatically

Sewing ► Edit ► **Auto Length** ^{20.0}/_{REC}

In the mode **Auto Length** ^{20.0}/_{REC}, you can set the darning length in millimeters. The machine automatically finishes the darning program with the set darning length.

Prerequisite:

- The Darning Program No. 23 is loaded.
- Buttonhole Foot #3A is attached.

1. Tap the **Auto Length** ^{20.0}/_{REC} icon.
 - ⇒ The **Reverse** icon flashes on the Sewing Screen.
2. Sew the first row and press the **Quick Reverse** button at the desired length.
 - ⇒ The machine will complete the darning program.
 - ⇒ The darning length remains saved until it is overwritten, cleared or the machine is switched off.

6.5 Stitch Pattern Management

Load Stitch Pattern

Sewing  ► Personal Folder  ► Load Stitch Pattern 

With the function **Load Stitch Pattern**  you can upload your own stitch patterns from the folder **Personal Folder** .

Save Stitch Pattern

Sewing  ► Personal Folder  ► Save Stitch Pattern 

With the function **Save Stitch Pattern** , you can save modified stitch patterns as your own stitch patterns in the folder **Personal Folder** . To do this, you must select the folder in which the stitch pattern is to be saved.

Deleting Stitch Pattern


Sewing  ► Personal Folder  ► Deleting Stitch Pattern 

With the function **Deleting Stitch Pattern** , you can delete stitch patterns in the folder **Personal Folder** .

6.6 Stitch Pattern Combination

Combi Mode

In combination mode, you can combine stitch patterns and letters to create stitch pattern combinations or lettering. Stitch pattern combinations can be saved and sewn out as one stitch pattern.



1 Combi Mode 2 Combination Bar

In the full-screen view, you can select the alphabet stitches specifically via the icons (upper and lower case letters and special characters), navigate between the individual stitch patterns and delete them.



Creating Stitch Pattern Combinations

Sewing  ► Combi Mode 

1. Tap the **Combi Mode**  icon in the Sewing Screen.
2. Combine the desired stitch patterns or letters from the selection area one after another to form a combination.
 - ⇒ The stitch patterns are inserted in the combination bar, after the stitch selected, and displayed in the Stitch Preview.
 - ⇒ The combination can be sewn and/or saved.

Editing Functions

Sewing  ► Combi Mode  ► Edit 



With the **Edit**  function, you can edit individual stitch patterns or whole stitch pattern combinations.

By tapping the function **Combi Mode** , the additional functions in the menu editing functions are activated to edit individual stitch patterns, several stitch patterns or the complete stitch pattern combination.

Delete

Sewing  ► Combi Mode  ► Edit  ► Delete 

You can use the function **Delete**  to remove the selected stitch pattern from the combination.

TIP

You can also drag and drop selected stitch patterns out of the combination bar to the left to remove them.

Editing a Stitch Pattern Combination

Sewing  ► Combi Mode  ► Edit  ► Editing a Stitch Pattern Combination 

With the **Editing a Stitch Pattern Combination** function, you can edit complete stitch pattern combinations.

Unify Length

Sewing  ► Combi Mode  ► Edit  ► Editing a Stitch Pattern Combination  ► Stitch Length  ► Unify Length 

With the **Unify Length**  function, you can set the length of all stitch patterns in the combination to match the longest stitch pattern. The **Unify Length**  function is only available if the entire combination is selected.

Unify Width

Sewing  ► Combi Mode  ► Edit  ► Editing a Stitch Pattern Combination  ► Stitch Width  ► Unify Width 

With the **Unify Width**  function, you can set the width of all stitch patterns in the combination to match the widest stitch pattern. The **Unify Width**  function is only available if the entire combination is selected.

Edit Combination at Cursor Position

Sewing  ► Combi Mode  ► Edit  ► Edit Combination at Cursor Position 

With the **Edit Combination at Cursor Position**  function, you can define the position of the cursor after which stitch pattern section one of the following functions is to be inserted:

- Subdivide
- Interrupt
- Tie-Off

Editing a Stitch Pattern Combination



Repeat

Sewing  ► Combi Mode  ► Edit  ► Editing a Stitch Pattern Combination  ► Repeat 

With the function **Repeat** , you can set the number of repeats of a stitch pattern combination after which the machine should stop. You can set up to 9 repeats. The number of repeats still to be sewn is displayed on the Sewing Screen.

Mirror Left/Right

Sewing  ► Combi Mode  ► Edit  ► Editing a Stitch Pattern Combination  ► Mirror Left/Right 

You can use the function **Mirror Left/Right**  to mirror a stitch pattern combination along the vertical axis.

Delete


Sewing  ► Combi Mode  ► Edit  ► Editing a Stitch Pattern Combination  ► Delete 

You can use the function **Delete**  to delete the complete stitch pattern combination.

TIP

To delete the stitch pattern combination, you can also drag the stitch pattern combination to the left out of the combination bar.

Edit Combination at Cursor Position



Combination Subdivider

Sewing  ▶ Combi Mode  ▶ Edit *i* ▶ Edit Combination at Cursor Position  ▶ Combination Subdivider 

With the **Combination Subdivider**  function, you can subdivide the stitch pattern combination at various positions. The subdivision is inserted below the cursor. Only the section of the stitch pattern combination in which the cursor is located is sewn. To sew the next section, the cursor must be placed in this section.

Combination Interruption

Sewing  ▶ Combi Mode  ▶ Edit *i* ▶ Edit Combination at Cursor Position  ▶ Combination Interruption 

With the **Combination Interruption**  function, you can stop the machine automatically after any stitch pattern in the combination. This function is well suited when writing addresses or verses, creating name lists or clothing labels, among other purposes.

Tie-Off

Sewing  ▶ Combi Mode  ▶ Edit *i* ▶ Edit Combination at Cursor Position  ▶ Tie-Off 

With the **Tie-Off**  function, you can automatically insert securing stitches after any stitch pattern in the combination.

Loading a Stitch Pattern Combination

Sewing  ▶ Personal Folder  ▶ Loading a Stitch Pattern Combination 

With the function **Loading a Stitch Pattern Combination**  you can upload a stitch pattern combination from the folder **Personal Folder** .

Saving a Stitch Pattern Combination

Sewing  ▶ Personal Folder  ▶ Saving a Stitch Pattern Combination 

With the function **Saving a Stitch Pattern Combination**  you can save a stitch pattern combination in the folder **Personal Folder** .

Deleting a Stitch Pattern Combination

Sewing  ▶ Personal Folder  ▶ Deleting a Stitch Pattern Combination 

With the function **Deleting a Stitch Pattern Combination**  you can delete a stitch pattern combination in the folder **Personal Folder** .

The machine offers various options for securing the thread at the beginning and end of the seam.

At the Beginning of the Seam

- Thread with the needle threader or press the button **Thread Cutter**  .
If the **Securing Stitches** function is switched on in the sewing settings, the machine secures.
- Manually sew a few stitches forward, then backward, then forward again.
- Press the **Tie-Off**  button before starting to sew.
- With a back-kick on the foot control, if the **Tie-Off**  function is switched on for the back-kick.

At the End of the Seam


- Manually sew a few stitches backward, then forward again.
- Press the **Tie-Off**  button when securing is to be carried out.
- Press the **Pattern End**  button. The **Stop**  icon appears in the stitch preview.
If the button for the **Tie-Off**  function is activated in sewing settings, the machine stops and secures at the end of the pattern.
- Press the **Thread Cutter**  button.
If the button for the **Tie-Off**  function is activated in sewing settings, the machine secures when the button is pressed and cuts the thread.
- With a back-kick on the foot control, if the **Tie-Off**  function is switched on for the back-kick.

Free-motion quilting often results in varying stitch lengths due to freely guiding the fabric. The stitch regulation compensates for these differences in stitch length.

The faster you guide the fabric, the faster the machine sews. If you move the fabric more slowly, the machine will sew equally slowly. This ensures that all stitches are sewn to equal length, resulting in regular stitch formation.

To make use of the stitch regulation, you need BERNINA Stitch Regulator (BSR) #42.

8.1 Stitch Regulation



1 KickStart 2 Stitch Regulation On/Off 3 Stitch
4 Sound 5 Mode

Stitch Regulation On/Off

With the **Stitch Regulation On/Off** BSR function, you can switch the stitch regulation on or off. If the function is switched off, the stitch length will not be corrected, even if presser foot is connected.

The BERNINA Stitch Regulator (BSR) must be attached in order to use the **BSR Mode** function [▶ see page 36]

Sound

With the **Sound** (🔊) function, you can activate an audible warning. The warning tone sounds if you feed the fabric too quickly and the machine reaches the maximum speed and therefore is no longer able to correct the stitch length.

Stitch

In BSR mode, you can choose between straight stitch and zigzag options.

The straight stitch option is suitable for free-motion quilting, embroidery and thread painting.

The zigzag option can be used in free-motion embroidery or thread painting.

Mode

In the **Mode** area, you can select the desired BSR mode:

- **BSR 1:** The needle continues sewing on the spot, even if the fabric is not moved. [▶ see page 65]
- **BSR 2:** The needle stops when the fabric is no longer being moved. [▶ see page 65]
- **BSR 3:** Basting Mode [▶ see page 65]

KickStart

With the **KickStart** (👉) function, you can quilt without continuously pressing down the foot control. [▶ see page 66]

BSR Mode 1

In this mode, the machine runs continuously at a low speed once you press the foot control or the **Start/Stop** (⏻) button. As you move the fabric, the machine speeds up or slows down in order to keep to the set stitch length.

This mode is well-suited to quilt designs with many points or with micro-stippling, where the fabric stops briefly with each change in direction. If the machine continues sewing slowly when doing so, quilting feels smoother. Sewing in place also enables you to secure the thread without pressing an additional button.

BSR Mode 2

In this mode, the machine starts sewing as soon as you press the foot control and move the fabric. The machine stops as soon as you are no longer moving the fabric or no longer pressing the foot control.

To secure the thread, you can move the fabric back and forth in place or press the **Tie-Off** (🔗) button.

BSR Mode 3

This mode is intended for basting. You can choose between two basting stitch lengths. To ensure that the stitches are sewn correctly, move the quilt more slowly when basting.


Using KickStart

With the **KickStart**  function, you can quilt without continuously pressing down the foot control.

1. Tap the **KickStart**  icon.
 - ⇒ The **KickStart** screen will appear.
2. To start the machine, press the foot control with your heel.
 - ⇒ Once the fabric is moved, the machine starts sewing with the selected settings.
3. To stop the machine, press the foot control with your heel.
 - ⇒ The machine will stop, but the **KickStart**  function will remain active.
4. To end the **KickStart**  function, tap the screen or press the foot control with the ball of your foot.
 - ⇒ The **KickStart** screen will disappear.

Please Note

- As long as the **KickStart**  function is active, the function programmed for the back-kick will be deactivated. In this case, the back-kick is instead used to start and stop the machine.
- If no sewing is being carried out in the BSR modes 2 and 3, the machine will switch to standby mode after 7 seconds. This means that the machine will not start sewing automatically if the fabric is moved. You can end standby mode with another back-kick.
- The **KickStart**  function is automatically stopped in the following cases:
 - If the active monitoring function reports an error, e.g. thread break or bobbin empty.
 - If the foot control cable is removed.
 - If no sewing takes place for 60 seconds.



Sewing Fabrics Together

A seam is formed when two fabrics are joined together with a single line of stitching. Seams are an essential element to every garment and sewn projects.



<https://www.bernina.com/foot-1C>




Sewing a Buttonhole

With the Automatic Buttonhole Foot with Slide #3A, several identical buttonholes can be sewn as often as required.



<https://www.bernina.com/foot-3A>



Sewing in Zippers

A centered zipper is one in which the slit edges of the opening meet over the middle of the zipper and hide it.



<https://www.bernina.com/foot-4D>



Appliqué

Appliqué is an embellishment made by sewing fabric shapes onto a background fabric. Use a satin or decorative stitch to cover the raw edges.



<https://www.bernina.com/foot-20C>



Free-motion Quilting

Free-motion quilting is a quilting technique in which the feed dogs are lowered therefore requiring the fabric to be manually moved to create stitches. The fabric can be moved in any direction to create patterns.



<https://www.bernina.com/BSR>

Embroidery File Format

Your machine can read embroidery designs that have been created using the BERNINA Embroidery Software and exported as EXP files. When they are exported, a BMP file and an INF file are created alongside the actual embroidery file. The BMP file provides a preview of the embroidery design and the INF file provides the information on the thread colors. If the INF file is missing, the embroidery design cannot be displayed in the correct thread colors and will instead be displayed in default colors. You can set the colors manually in the editing functions.

In addition to the BERNINA embroidery file format, your machine can also read the following embroidery file formats: BQM, SEW, PES, PEC, XXX, PCS, JEF and DST. BERNINA International AG cannot guarantee that embroidery designs that have not been created or converted using the BERNINA Embroidery Software will be correctly read and embroidered.

Design Size

You can increase or decrease the size of embroidery designs by up to 20 % without loss of quality on the machine or on a PC using the BERNINA embroidery software.

Customizable quilt designs (BQM) are vector-based embroidery designs. You can adjust the size of such quilt designs in almost any way. The stitch length set in the embroidery settings remains when the pattern size is adjusted.

Upper Thread

Select high-quality embroidery threads for the upper thread, as these have an even thickness and are less prone to breaking. Embroidery created with glossy, fine

embroidery thread is particularly beautiful. Thread manufacturers offer a comprehensive range of thread types and colors.

- Polyester with a sheen is durable, break-resistant and colorfast. Polyester with a sheen is suitable for all types of embroidery.
- Rayon is a fine, silk-like fiber with a glossy effect. Rayon is suitable for fine embroidery that is not subject to heavy stress.
- Metallic thread is a glossy thread available in fine to medium thicknesses, and is suitable for special effects in embroidery.

When using metallic threads, switch off the automatic thread cutter and reduce the embroidery speed and upper thread tension.

To reduce thread breakage, you can use the Thread Lubrication Unit.

Bobbin Thread

Special bobbin thread for embroidery is usually only available as black or white thread. If both sides of the embroidery will be visible, you can also use the upper thread in the same color or another normal embroidery thread as the bobbin thread.

- Embroidery bobbin thread is an especially soft and light polyester thread which is suited to be used as bobbin thread. This special bobbin thread ensures a steady thread tension and an optimal intertwining of the upper and bobbin thread.

Stabilizers

Use a stabilizer to stabilize the fabric during stitching. Light weight and knit fabrics are difficult to hoop and tend to deform. A stabilizer prevents the fabric moving or puckering during stitching.

There are various types of stabilizers for various applications.

Stabilizer	Scope of Application	Fabric/Application
Cut-away Stabilizer	Knit fabrics Woven fabrics	<ul style="list-style-type: none"> ■ Jersey, sweater, knitwear, stretch fleece ■ Embroidery designs with high embroidery density
Tear-away Stabilizer	Woven fabrics	<ul style="list-style-type: none"> ■ Denim, cotton, linen, felt, wool, silk
Water-soluble Stabilizer	Washable fabrics Projects where there must not be any visible stabilizer residue	<ul style="list-style-type: none"> ■ Organza, net, chiffon ■ Freestanding embroidery
Topping	Fabrics with a pile or texture	<ul style="list-style-type: none"> ■ Velvet, fleece, plush, knit fabrics, corduroy, broadcloth

Stabilizer	Scope of Application	Fabric/Application
Adhesive Stabilizer	Fabrics or projects that cannot be hooped	<ul style="list-style-type: none"> ■ Leather, imitation leather, cork, velvet, velour, neoprene, fur, corduroy ■ Collar corners, pockets, cuffs
Hydro Stabilizer	For most embroidery applications	<ul style="list-style-type: none"> ■ Leather, imitation leather, cork, velvet, velour, neoprene, fur, corduroy ■ Collar corners, pockets, cuffs
Iron-on Stabilizer	Iron-on fabrics	<ul style="list-style-type: none"> ■ Appliqués and patches


Stabilizers can be fixed onto the fabric with adhesive spray or starch spray before hooping. Starch spray can be used to stiffen the fabric before embroidering.

Embroidery Test

For important projects, it is advisable to test embroider the design on the same or a similar fabric using the same stabilizer, threads and needle.

- An embroidery test enables you to recognize potential errors or difficulties in advance so that you can make appropriate adjustments.
- The embroidery test enables you to check the selected embroidery threads and colors appear on the fabric and adjust as needed.
- The embroidery test enables you to determine the ideal stitch density and apply the correct settings.

Embroidery 0



1 Status Bar 2 Info Box 3 Zoom In/Zoom Out 4 Design Preview 5 Edit 6 Layer Bar 7 File 8 Edit 9 Colors 10 Stitchout

Info Box

In the Info Box, you can find the following information about the embroidery design:

- **Embroidery Time** ⌚ : Estimated time for embroidering the selected layers.
- **Embroidery Size** 📏 : Total width and height of the selected levels.

Zoom In/Zoom Out

With the **Zoom In/Zoom Out** 🔍🔍 function, you can enlarge and reduce the view of the embroidery design on the embroidery screen.

Move View

Embroidery 0 ▶ Zoom In/Zoom Out 🔍 ▶ Move View 🖱️

With the **Move View** 🖱️ function, you can move the embroidery design preview without changing the embroidery position.

Move

Embroidery 0 ▶ Zoom In/Zoom Out 🔍 ▶ Move 🔄

With the **Move** 🔄 function, you can move the selected layers.

Design Preview

The Design Preview shows a preview of the current embroidery designs in the attached or selected hoop.

Edit

With the **Edit** ⓘ function, you can show editing functions for the embroidery designs. [▶ see page 74]

File

Use the tab **File** 📁 to load embroidery designs from the selection area. You can save or delete embroidery designs in the folder **Personal Folder** ❤️ or on the USB stick. [▶ see page 72]

- **New Design** 📁 : To load a new embroidery design from the selection area.
- **Add Design** ➕ : To add an embroidery design from the selection area.
- **Save** 💾 : To save an embroidery design in the folder **Personal Folder** ❤️ or on the USB stick.
- **Delete personal embroidery designs** 🗑️ : To delete an embroidery design in the folder **Personal Folder** ❤️ or on the USB stick.

Edit

Use the tab **Edit**  to call up the embroidery screen and edit the embroidery design. [▶ see page 74]

Colors

Use the tab **Colors**  to display and change the colors and thread brands of the whole layer.

Tap the icon **Number of Colors**  to display the number of colors used for the whole layer.

The following functions enable you to edit the thread brand and the color:

- **Change Color** : To change the color and thread brand of the selected color. [▶ see page 76]
- **Change Brand** : Apply the thread brand for the selected color to all colors. [▶ see page 76]

Stitchout

Via the tab **Stitchout** , you can call up the window **Stitchout Summary** and the embroidering. [▶ see page 81]

11.1 Status Bar

The Status Bar displays the state of various functions. You can set or activate some functions directly via the respective icon. For other functions, you can call up additional settings via the icon.

The color of the icon shows the current state of the function.

- White: Default setting
- Yellow: Modified setting

WiFi

The icon **WiFi**  shows the strength of the WiFi connection.

In the Settings, you can switch the WiFi connection on or off or set up the WiFi connection. [▶ see page 40]

Upper Thread Tension

The **Upper Thread Tension**  status shows the recommended upper thread tension for the selected embroidery design.

You can change the upper thread tension by tapping the icon. [▶ see page 43]

Presser Foot

The **Presser Foot**  status shows the recommended or selected presser foot.

You can open presser foot selection by tapping the icon. You can select the mounted presser foot in the presser foot selection. [▶ see page 36]

Hoop

The **Hoop**  status displays the attached hoop. If no hoop has been attached, the status shows the recommended hoop for the selected embroidery design.

- White: Standard or selected embroidery hoop.
- Yellow: Attached and recognized hoop.

You can select the attached hoop and display details for the hoop by tapping the status. [▶ see page 39]

Stitch Plate and Sewing Needle

The icon **Stitch Plate and Sewing Needle**  indicates the selected needle and the selected stitch plate.

By tapping the icon, you can call up the needle and stitch plate overview and select the fitted needle and the fitted stitch plate. [▶ see page 30]

The icon **Stitch Plate and Sewing Needle**  turns yellow if a needle other than the standard needle has been selected. The name of the icon **Stitch Plate and Sewing Needle**  turns yellow if a stitch plate other than the standard stitch plate is selected.

Feed Dog

The **Feed Dog**  status shows the position of the feed dog. The feed dog must be lowered in the **Embroidery** mode. Wenn Sie den Modus **Embroidery**  wählen, wird Ihnen eine Animation angezeigt, wie der Transporteur gesenkt werden kann.

Bobbin Thread

The **Bobbin Thread**  status shows the fill capacity of the lower thread bobbin.

- White: Fill level of the bobbin thread is sufficient.

As soon as the fill level of the bobbin thread falls below a certain value, a fill level indicator is also displayed.

- Fill level indicator flashes red: bobbin thread quantity is low.

By tapping the icon **Bobbin Thread** , an animation on how to thread the bobbin thread is displayed.

Laser

The **Laser**  icon shows the status of the laser.


- White: Laser off.
- Yellow: Laser on.

By tapping the icon, you can switch the laser on and off.

The laser indicates the next stitch point in sewing mode and the exact needle position in embroidery mode.

Depending on the presser foot and needle position, the entry point may be concealed by the presser foot. To avoid the deflection of the laser with transparent presser feet, you can lower the presser foot before the sewing start, e.g. with the Knee Lifter.

11.2 Layer Bar




1 Level Up/Down 2 Add Design 3 Embroidery Design Layers 4 Embroidery Designs Combined

In the layer bar, the individually added embroidery designs or elements of an embroidery design are displayed as layers. The most recently added embroidery design is shown at the top. The lowest layer shows all added embroidery designs combined. The order of the layers affects the embroidery.

The following functions are available in the layer bar:

- **Add Design**  : To add an embroidery designs from the selection area. [▶ see page 74]
- Select all layers for editing. To do this, select the bottom layer in the layer bar.
- Delete layers by dragging them out.

11.3 Embroidery Design Selection



1 Navigation Bar 2 Selection Area

Navigation Bar

The Navigation Bar shows the path to the selected folder.

Machine/USB Stick

With the **Machine**  /**USB Stick**  functions, you can switch between the machine and the USB stick in the selection area.

Search

With the **Search**  function, you can search for embroidery designs by number in the currently selected folder.

Selection Area

In the Selection Area, you can navigate through the folders and load an embroidery design. Each embroidery design is displayed with a preview image including details of the file format.

Lettering

In the **Lettering** **ABC** folder, you will find alphabets which you can use to create your own texts. [▶ see page 79]

Embroidery Designs

In the **Embroidery Designs**  folder, you will find all embroidery designs that are supplied with the machine. The embroidery designs are collated into folders by subjects. [▶ see page 107]

11 Embroidery Screen

Personal Folder


In the folder **Personal Folder** ♥ , you can save and load your own embroidery designs. The stitch pattern last used in the sewing mode is displayed in the My Folder and can be uploaded for embroidering.

12.1 Loading the Embroidery Design



1 File 2 New Design

1. Tap the tab **File** .
2. Tap the **New Design**  icon.
⇒ The selection area appears.
3. Tap the embroidery design category in the selection area.



4. Search for the desired embroidery design and select it.
⇒ The embroidery design is displayed in a hoop in the design preview that is closest to the size of the design.


12.2 Embroidery Design Editing

Embroidery  ► Edit 

With the **Edit**  function, you can view the editing functions.

The results of editing are shown in real time in the design preview in the selected hoop.

Editing Functions



Move

Embroidery  ► Edit  ► Move 

With the **Move**  function, you can move the selected layers. With the **Center**  function, you can position the layers in the center of the hoop.

Rotate

Embroidery  ► Edit  ► Rotate 

With the **Rotate**  function, you can rotate the selected layers.

Resize

Embroidery  ► Edit  ► Resize 

With the **Resize**  function, you can modify the size of the selected layers. In the default setting, the length and width is changed proportionally. With the **Proportional**  function, you can unlink the length and width, enabling you to set the values separately.

TIP

For best results, do not enlarge or reduce the layers by more than 20 %.

Mirror Left/Right

Embroidery  ► Edit  ► Mirror Left/Right 

With the **Mirror Left/Right**  function, you can mirror the selected layers along the vertical axis.

Mirror Up/Down

Embroidery  ► Edit  ► Mirror Up/Down 

With the **Mirror Up/Down**  function, you can mirror the selected layers along the horizontal axis.

Duplicate

Embroidery  ► Edit  ► Duplicate 

With the **Duplicate**  function, you can duplicate the selected layers.

DeleteEmbroidery  ► Edit  ► Delete 

With the **Delete**  function, you can delete the selected layers.

TIP

You can also drag and drop selected layers out of the layer bar to the left to remove them.

Stitch TypeEmbroidery  ► Edit  ► Stitch Type 

With the **Stitch Type**  function, you can change the stitch type and the embroidery density.

- **Stitch Type**  :
 - **Off:** The embroidery design is embroidered with satin stitches as standard.
 - **On:** Satin stitches that are too long are converted to backstitches. The length of the backstitches can be changed. If the satin stitches have been converted to backstitches, the setting cannot be reset. You must reload the embroidery design.
- **Embroidery Density**  : To change the density of the stitches.

Arranging Functions**Arrange**Embroidery  ► Edit  ► Arrange 

With the **Arrange**  function, you can move the selected layer in the layer bar down/up step by step. Moving layers downward will cause them to be stitched earlier. The bottom layer is stitched first.

GroupEmbroidery  ► Edit  ► Group 

With the **Group**  function, you can merge the selected layers with the layer directly above them to form a group. The group is displayed in place of the lowest selected layer in the layer bar.


UngroupEmbroidery  ► Edit  ► Group 
► Ungroup 

Previously grouped embroidery designs can be ungrouped using the function **Ungroup**  . Multi-colored embroidery designs are saved as a single group, where each color forms its own layer. With the **Ungroup**  function, you can split up an

embroidery design into its color layers and up to its connecting stitches. The layers are displayed separately in the layer bar and can be edited separately.

AlignEmbroidery  ► Edit  ► Align 

With the **Align**  function, you can align multiple selected layers with each other, center multiple selected layers together, or distribute multiple selected layers evenly.

**Grid**Embroidery  ► Hoop  ► Grid 

With the **Grid**  function, you can display the center point of the embroidery hoop, show a grid and hide the center point and the grid.

Positioning Functions**Pinpoint Placement**Embroidery  ► Edit  ► Pinpoint Placement 

With the **Pinpoint Placement**  function, you can position an embroidery design at a specific position in the hoop. You can also rotate and modify the size of the embroidery design while doing so in order to ensure that it is correctly stitched, even if the fabric is not clamped straight. [► see page 77]

Check DesignEmbroidery  ► Edit  ► Check Design 

With the **Check Design**  function, you can check the four corners and the center of the selected layer and move the embroidery design if necessary. [► see page 76]

Virtual Positioning

Embroidery ► Hoop ► Virtual Positioning

With the **Virtual Positioning** function, you can move the hoop such that the needle is at the selected position in the design preview. This function allows you to check the position of the embroidery design stitch by stitch.

This function is only active if a hoop is attached.

TIP

You can use the laser to precisely check the virtual positioning.

Center Design

Embroidery ► Hoop ► Center Design

With the **Center Design** function, the needle position is moved to the center of the embroidery design.

This function is only active if a hoop is attached.


Endless Embroidery

Embroidery ► Edit ► Endless Embroidery

With the **Endless Embroidery** function, you can embroider combinations that are longer than the hoop. Reference markings can be programmed and stitched, which are useful for repositioning the hoop after re-hooping. You can also create combinations of designs and stitch patterns, duplicate them and use them to fill the area of the hoop, e.g. as a patterned background for an embroidery project. [► see page 78]

Changing the Colors

Embroidery ► Colors



- 1 Color Up/Down 2 Color 3 Embroidery Sequence
4 Color Number 5 Thread Brand 6 Change Brand
7 Change Color

There are the following options available for changing a color in an embroidery design:

- **Change Color** : Select a color from a color palette.
- **Search Q** : Use the **Search Q** function to search for a color by color number.

Change Thread Brand


Embroidery ► Colors

The embroidery designs are programmed with the Isacord 40 thread brand. If you would rather work with embroidery threads from other brands, you can change the thread brand.

1. To change the thread brand for all threads in the layer, tap the icon **Change Color** .
2. Select the desired brand from the list by scrolling left/right.
3. Tap the **Change Brand** icon.
4. To change the thread marker for an individual color, select the color, tap the **Change Color** icon, select the thread marker from the list and tap the desired color.
5. To return to the color overview, tap the icon **Colors** in the path.

Check Design

Embroidery ► Edit ► Check Design



- 1 Move Hoop to Position 2 Center Design 3 Moving the Embroidery Design Horizontally 4 Moving the Embroidery Design Vertically

With the **Check Design** function, you can check the intended position of your embroidery design in the hoop before you start stitching out.

Prerequisite:

- A hoop with the hooped project is attached.

1. Tap an arrow in the **Move Hoop to Position** area.
 - ⇒ The hoop moves until the needle is located at the selected point of the embroidery design, as long as the point is within the area to be embroidered.
2. Check whether the position is correct.
3. If necessary, move the embroidery design horizontally and vertically.
4. If necessary, check other positions.
4. Position the needle at the corresponding marking on the fabric using the multifunction knobs and confirm with the **Pin SET** button. You can activate the laser to assist with exact positioning of the needle.
5. Select a second grid point. Position the needle at the second marking on the fabric and confirm with the **Pin SET** button.

Pinpoint Placement

Embroidery  ► Edit  ► Pinpoint Placement 

With the **Pinpoint Placement**  function, you can position the embroidery design with the following options:


- **Two Points** 
- **Four Point** 

TIP

Using the Laser function, you can position the point precisely at the desired location on the fabric.

Positioning the Embroidery Design by 2 Grid Points

In the mode **Grid**  you can position embroidery designs precisely on the fabric using 2 freely positioned points.




Prerequisite:

- The desired position of the embroidery design is marked on the fabric with two points and is clearly visible.
 - A hoop with the hooped project is attached.
1. Tap the **Grid**  icon.
 2. To maintain the size of the embroidery design, activate the **Retain Size**  function.
 3. Select any point on the grid as the rotation point.

Positioning the Embroidery Design by means of 2 Freely Positioned Points

With the **Free Point**  option, you can position embroidery designs precisely on the fabric using 2 freely positioned points.




Prerequisite:

- The desired position of the embroidery design is marked on the fabric with two points and is clearly visible.
 - A hoop with the hooped project is attached.
1. Tap the **Free Point**  icon.
 2. To maintain the size of the embroidery design, activate the **Retain Size**  function.
 3. Select any point on the embroidery design as the rotation point.
 4. Position the needle at the corresponding marking on the fabric using the multifunction knobs and confirm with the **Pin SET** button. You can activate the laser to assist with exact positioning of the needle.
 5. Select the second point of the embroidery design. Position the needle at the second marking on the fabric and confirm with the **Pin SET** button.

Positioning the Embroidery Design in a Square

With the **Four Point**  option, you can position the embroidery design in a square using four points, e.g. in a quilt block. The following options can be used to place the design:

- **Morph** : To fit the morphed embroidery design in the bounding box.
- **Fit** : To fit the embroidery design proportionally and centered in the bounding box.




Prerequisite:

- The desired position of the embroidery design is marked on the fabric with four points and is clearly visible.
- A hoop with the hooped project is attached.

1. Tap the **Four Point**  icon.
 - ⇒ The design is placed inside a rectangular bounding box.
2. Select one of the corner points and position the needle over the corresponding marking on the fabric with the multifunction knobs. You can activate the laser to assist with exact positioning of the needle.
3. Select all corner points one after the other and position the needle.
4. Select the **Morph**  or **Fit**  option.
 - ⇒ The design is placed inside a bounding box.
5. To maintain the size of the embroidery design, activate the **Retain Size**   function.
6. If necessary, set a margin spacing from the grid.

Borders

Embroidery  ► Edit  ► Endless Embroidery 



- 1 Item Count
- 2 Spacing
- 3 Modify to Fit Hoop
- 4 Reference Marker

With the **Endless Embroidery**  function, you can stitch combinations that are longer than the hoop.

TIP

- Using a larger hoop will require less re-hooping.
- To help keep the designs straight, draw guide lines on the fabric and use the template for clamping and re-hooping. Make sure that the guide lines run parallel to the lines of the template. You can also reposition the embroidery design using the **Pinpoint Placement**  function.

Creating Borders


Prerequisite:

- A hoop with the hooped project is attached.
1. Select an embroidery design.
 2. Select the **Endless Embroidery**  function.
 - ⇒ The embroidery design is multiplied to match the hoop.
 - ⇒ Marker positions are inserted.
 3. If necessary, insert additional marker positions. The reference markings are also embroidered and help to align the project when rehooping and positioning.
 4. If necessary, enter the number of repetitions of the embroidery design.
 5. If necessary, adjust the size of the embroidery design so that it fits into the hoop.
 6. If necessary, adjust the spacing between the embroidery designs.
 7. Confirm settings.

Endless Embroidery

Prerequisite:

- A hoop with the hooped project is attached.
- 1. Call up **Stitchout** | in the tab.
- 2. Use the **Start/Stop** ○● button to start stitching out.
- 3. Once the embroidery design has been fully stitched out, remove the hoop and re-hoop the fabric so that the stitched-out marker positions are located in the upper embroidery area of the hoop.
- 4. Attach the embroidery hoop and confirm it on the screen.
 - ⇒ The icon «**AUTO**» is active and the embroidery hoop moves automatically close to the last reference point.



- 5. Use the arrow fields to determine which reference point should be approached to continue the design.
- 6. Use the multifunction knobs to position the embroidery hoop. You can activate the laser to assist with exact positioning of the embroidery hoop. Align the laser dot to the tip of the reference point using the multifunction knobs.
- 7. Confirm the changes.
- 8. Continue stitchout.
- 9. Repeat these steps until the required length of the trim has been achieved.

TIP

The function **Endless Embroidery** allows you to continue embroidering borders that have already been started, even if the machine has been switched off and on. For this, the embroidery design must be saved in the folder **Personal Folder**. The reference points must be included in the embroidery design.

12.3 Lettering

Lettering

Embroidery ► New Design ► Lettering ABC

Font	Name
<i>ABC</i>	Anniversary
ABC	Bamboo
ABC	Condensed Sans
<i>ABC</i>	Curly
ABC	Deco Block
ABC	Happy Times
<i>ABC</i>	Lisa
ABC	Quilt Block
ABC	Rounded Sans
<i>ABC</i>	Zuerich

Creating Lettering



1 Text Preview 2 Keyboard

You can design single-line or multi-line lettering.

- 1. Tap the tab **File**.
- 2. Tap the **New Design** icon.
 - ⇒ The selection area appears.
- 3. Tap the folder **Lettering ABC** in the selection area and select a font.

4. Type in the text using the on-screen keyboard.
Customize line breaks as desired.
5. Confirm the completed text.

Editing Functions

Embroidery  ▶ Edit *i* ▶ Lettering 

With the **Lettering**  function, you can edit a lettering with special functions.

- **Arch**  : To bend single-line horizontal text.
- **Spacing**  : To set the character spacing.
- **Line Spacing**  : With multi-line lettering, change the spacing between the lines..
- **Aligning Text**: To align multi-line text centered, left or right.

12.4 Saving Embroidery Designs


Embroidery  ▶ File  ▶ Save 

With the **Save**  function, you can save modified embroidery designs in your own folder or on a USB stick.

1. Tap the **Save**  icon.
⇒ The folder **Personal Folder**  appears.
2. Select **USB Stick**  if necessary.
3. Confirm saving.
⇒ The embroidery design is saved in the Personal Folder or on the USB stick.

13.1 Stitchout Summary

Embroidery  ▶ Stitchout .



- 1 Current Color 2 Design Preview 3 Color Up/Down
 4 Basting 5 Move Hoop 6 Go to Stitch 7 Quilt Settings
 8 Reduce Thread Changes 9 Single Color
 10 Endless Embroidery

In the **Stitchout Summary** screen, you can modify the most common settings for optimal stitchout quality before entering the Stitchout. Additional settings can be modified in Embroidery Settings. [▶ see page 43]

Basting

With the **Basting**  function, you can secure materials in the hoop that cannot be hooped, e.g., felt, organza and silk. The basting can also be used to prevent top stabilizers from moving or as a guide for trimming after embroidery. The following functions are available:

- Deactivated: No basting seam sewn.
- **Around Design** : To sew the basting seam around the embroidery design.
- **Around Hoop** : To sew the basting seam along the inside edge of the embroidery hoop.

TIP

The basting seam has no sew-on stitches. Pull the bobbin thread to the top of the fabric before stitching the basting seam and hold both threads for the first stitches.

Move Hoop

With the **Move Hoop**  function, you can correct the position of the embroidery hoop if, for example, a border or lettering is not stitched out cleanly.

After rehooping the fabric, you can align the position of the embroidery hoop with the stitch that was embroidered last.

Go to Stitch

With the **Go to Stitch**  function, you can return to a specific point in the embroidery after a thread break or other interruption in the embroidery process in order to continue stitching from that point. The machine displays the needle position at the time the process was canceled.

You can move stitch by stitch or use the lower multi-function knob to move across larger sections of the design. The laser makes it easier to recognize the current stitch.

If you wish to return to a specific stitch, you can enter the number of the stitch.

Quilt Settings

With the **Quilt Settings**  function, you can switch on and off special quilt settings for thread cutting and securing. The following options are available:

- **On**: Activate quilt settings.
 - Quilt Securing Stitches.
 - Thread Cut Disabled.
 - Thread Away Disabled.
- **Off**: Adopt the thread cut settings from the embroidery settings.

Reduce Thread Changes

With the **Reduce Thread Changes**  function, you can regroup the embroidery design so that there is a minimum of thread changes.

Use this function when embroidering customizable quilt designs to avoid multiple starts and stops.

If this function is activated, the colors are also regrouped in edit mode.

Single Color


The setting **Single Color**  allows you to embroider the design without any thread change using the thread that is threaded.

Endless Embroidery

With the **Endless Embroidery**  function, you can select the reference point after you have rehooped the fabric. This determines the new position of the embroidery hoop. You can then position the embroidery hoop precisely.

13.2 Stitchout

Embroidery  ▶ Stitchout 



1 Embroidery Information 2 Design Preview 3 High Speed 4 Single Color

The **Stitchout** screen appears when the embroidery design is ready for stitching out. You can start stitching with the **Start/Stop**  button.

High Speed

Embroidery designs are stitched out at the optimum speed for an even embroidery pattern. The optimum embroidery speed depends on the hoop used. With the **High Speed**  function, you can increase the embroidery speed up to the saved maximum speed. Depending on the type of stitch, e.g. triple stitch, the function may result in an irregular stitch pattern. This function is only available once you have started stitching out using the **Start/Stop**  button.

Embroidery Information

The following information about the embroidery process is displayed in the Embroidery Information area:

- **Total Time:** Estimated embroidery time for the complete embroidery design.
- **Color Time:** Estimated embroidery time for the current color.
- **Stitch:** Current stitch number/stitches in total for the complete embroidery design and for the current color.

Single Color

The setting **Single Color**  allows you to embroider the design without any thread change using the thread that is threaded.

Once the embroidery design has been embroidered, you can choose from the following options:

- **Finishing Embroidering** : To finish embroidering and return to the embroidery screen.
- **Endless Embroidery** : To continue the embroidery design as a border. [▶ see page 79]

14.1 Software

Update Firmware

Settings  ▶ Machine  ▶ Maintenance 
▶ Firmware Update  ▶ Update Firmware 

Use the **Update Firmware**  function to install the latest version of the firmware on your machine.

You can update the current firmware of the machine and download detailed step-by-step instructions for the update process at www.bernina.com/770qepro-support.

Prerequisite:

- The latest firmware data has been downloaded and copied to the USB stick according to the update instructions.
1. Insert the USB stick with the current firmware data.
 2. Tap the **Update Firmware**  icon.
⇒ The firmware update is installed.

Delete Own Stitch Patterns

Settings  ▶ Machine  ▶ Factory Setting 
▶ Delete Own Stitch Patterns 

You can use the function **Delete Own Stitch Patterns**  to delete all personal stitch patterns saved on the machine.

Delete personal embroidery designs

Settings  ▶ Machine  ▶ Factory Setting 
▶ Delete personal embroidery designs 

You can use the function **Delete personal embroidery designs**  to delete all personal embroidery designs saved on the machine.

Deleting USB Stick

Settings  ▶ Machine  ▶ Factory Setting 
▶ Deleting USB Stick 

You can use the function **Deleting USB Stick**  to delete all stitch patterns and embroidery designs saved on the USB stick.

Reset Sewing Settings

Settings  ▶ Machine  ▶ Factory Setting 
▶ Reset Sewing Settings  

You can use the function **Reset Sewing Settings**  to reset all personal sewing settings saved on the machine to the factory settings.

Reset Embroidery Settings

Settings  ▶ Machine  ▶ Factory Setting 
▶ Reset Embroidery Settings  

You can use the function **Reset Embroidery Settings**  to reset all personal embroidery settings saved on the machine to the factory settings.

Reset Settings

Settings  ▶ Machine  ▶ Factory Setting 
▶ Reset Settings  

You can use the function **Reset Settings**  to reset all settings to the factory settings.

Save and Transfer Data

Settings  ▶ Machine  ▶ Maintenance 
▶ Firmware Update  ▶ Save and Transfer Data

With the **Save and Transfer Data** functions, you can save your personal data, e.g. settings and your own stitch and embroidery designs, to a USB stick and transfer them back to the machine.

14.2 Machine

Buttonhole Foot Calibration

Settings  ▶ Machine  ▶ Maintenance 
▶ Buttonhole Foot Calibration  ^{3A}

The Buttonhole Foot with Slide #3A is calibrated to the machine and they should always be used together. A new buttonhole foot must be calibrated with the machine in the sewing settings before its first use.

Prerequisite:

- The needle is not threaded.
1. Open the **Buttonhole Foot Calibration**  ^{3A} setting.
 2. Attach and lower the Buttonhole Foot with Slide #3A.

3. Push the **Start/Stop**  button.
- ⇒ The machine moves the buttonhole foot with slide forward and backward and displays successful calibration.

The maintenance intervals depend largely on the following factors:

- Frequency of use of the machine
- Nature of the fabric used
- Number of stitches
- Nature of the thread used

BERNINA recommends maintaining the machine after every 3 – 4 full bobbins have been used.

Maintenance Intervals

To ensure that your machine remains in proper working order for many years to come, BERNINA recommends regular maintenance and care of your machine.

Task	Maintenance Interval	Measures
Cleaning the Machine	Regularly, depending on usage of the machine.	▶ Wipe down the surface of the machine and screen with a soft, slightly damp microfiber cloth.
Checking the Machine	Regularly, depending on usage of the machine.	<ol style="list-style-type: none"> 1. Check the machine for external damage. 2. In case of damage, contact your BERNINA dealer.
Cleaning the Feed Dog and the Stitch Plate	Regularly, depending on usage of the machine.	▶ Clean the feed dog. [▶ see page 86]
Cleaning the Hook	Regularly, depending on usage of the machine.	▶ Clean the hook. [▶ see page 86]
Cleaning the Needle Threader and Thread Clamp	Regularly, depending on usage of the machine.	▶ Cleaning the needle threader and thread clamp [▶ see page 86]
Replacing the Needle	Regularly, depending on usage of the machine.	▶ Replace the needle. [▶ see page 29]
Updating Firmware	As soon as a new version is available.	▶ Updating Firmware. [▶ see page 83]

Task	Maintenance Interval	Measures
Lubricating the Hook	<ul style="list-style-type: none"> ■ Before using the machine for the first time. ■ After a longer downtime of the machine. ■ Before every new project. Now and then during a project, depending on the scope of the project. ■ Regularly, depending on usage of the machine. ■ If the relevant message is displayed. ■ In case of unusual noises in the bobbin area. 	<ul style="list-style-type: none"> ▶ Lubricate the hook. [▶ see page 87]
Adjusting, cleaning and lubricating machine components inside the machine	<ul style="list-style-type: none"> ■ With intensive use: annually ■ With normal use: 2-yearly ■ If the relevant message is displayed. 	<ul style="list-style-type: none"> ▶ Contact your BERNINA dealer.

Maintenance Information

Settings  ▶ Machine  ▶ Information 
▶ Machine Data 

Number of Stitches

The notification **Total Number of Stitches** shows the number of stitches sewn with the machine.

Service Prediction / Service Interval

The notification **Service Prediction / Service Interval** shows which part of the maintenance interval has elapsed. If the maintenance forecast reaches 100 %, a corresponding message is displayed when the machine is started and the machine must be serviced.

Lubrication Prediction / Lubrication Interval

The notification **Lubrication Prediction / Lubrication Interval** shows how much of the lubrication interval has elapsed. If the maintenance forecast reaches 100 %, a corresponding message is displayed when the machine is started and the machine must be lubricated. [▶ see page 87]

Number of Thread Cuts / Next Cleaning

The display **Total number of cut cycles since cleaning** shows the number of thread cuts that the machine has performed.

Cleaning the Screen

1. Lock the screen.
2. Wipe down the screen with a soft, slightly damp microfiber cloth.


Calibrating the Screen

Calibrating the Screen

Settings  ▶ Machine  ▶ Calibrating the Screen 

With the **Calibrating the Screen**  function, you can calibrate the screen if it no longer responds properly to touch. Calibration ensures that the screen responds precisely to inputs.

- ▶ Tap the crosses displayed on the screen with the touchscreen pen.



Cleaning the Feed Dog

Thread residue accumulates under the stitch plate over time. Remove the thread residue on a regular basis.

1. Raise the needle and presser foot.
2. Lower feed dog.

CAUTION

Electronically Driven Components

Risk of injury near the needle and the hook.

- ▶ Switch off the machine and disconnect it from the power supply.

3. Remove the needle and presser foot.
4. Remove the stitch plate.

NOTICE

Dust and thread remnants inside the machine

Damage to mechanical and electronic components.

- ▶ Use a brush or a soft cloth.
- ▶ Do not use compressed air spray.

5. Clean the feed dog with the brush.

Cleaning the Needle Threader and Thread Clamp

- Settings  ▶ Machine  ▶ Maintenance 
 ▶ Cleaning the Needle Threader/Thread Catcher 
 ▶ Cleaning the Needle Threader and Thread Clamp 

Lint can accumulate on the needle threader and prevent proper performance. It is recommended to clean the threader head regularly.

1. You can open the **Cleaning the Needle Threader and Thread Clamp**  function in the settings.
2. Clean the thread catcher and the thread clamp according to the instructions on the screen.

Cleaning the Thread Catcher

- Settings  ▶ Machine  ▶ Maintenance 
 ▶ Cleaning the Needle Threader/Thread Catcher 
 ▶ Cleaning the Thread Catcher 

Thread remnants accumulate in the thread catcher over time. Clean the thread catcher when the corresponding message is displayed.

1. You can open the function in the settings.
2. Clean the thread catcher according to the instructions on the screen.

Cleaning the Hook


CAUTION

Electronically Driven Components

Risk of injury near the needle and the hook.

- ▶ Switch off the machine and disconnect it from the power supply.

1. Open the bobbin cover.
2. Remove the bobbin case.
3. Push the release lever to the left.



4. Fold down the bobbin case holder with the black bobbin cover.
5. Remove the hook.


NOTICE

Dust and thread remnants inside the machine

Damage to mechanical and electronic components.

- ▶ Use a brush or a soft cloth.
- ▶ Do not use compressed air spray.

6. Clean the hook race area with a brush and a soft cloth. Never use any sharp instruments.
7. Hold the hook at the pin in the center with two fingers.



8. Guide the hook with the lower edge diagonally from the top to the bottom behind the bobbin cover.

14 Care and Maintenance

9. Position the hook with the two lugs on the hook driver meeting the corresponding openings in the hook. The gray marking on the hook driver must be visible in the hole of the hook.
10. Insert the hook.
 - ⇒ The shuttle is magnetic and therefore pulled into the correct position.
11. Close the bobbin cover and the fastening bracket until the release bracket engages.
12. Turn the handwheel to check.
 - ⇒ The hook will rotate.
13. Insert a bobbin case and close the bobbin cover.

Lubricating the Hook

Lubricating the hook keeps the machine running smoothly and quietly.


⚠ CAUTION

Electronically Driven Components

Risk of injury near the needle and the hook.


- ▶ Switch off the machine and disconnect it from the power supply.

1. Open the bobbin cover.
2. Remove the bobbin case.
3. Push the release lever to the left.
4. Fold down the bobbin case holder with the black bobbin cover.
5. Remove the hook.




6. Clean the hook race area with a brush and a soft cloth. Never use any sharp instruments.


7. Add a drop of BERNINA sewing machine oil to the bottom of the hook race.



8. Add one drop of BERNINA sewing machine oil into each of the two oil depots so the felt is damp. Make sure that the surface of the hook sleeve remains free of oil.



9. Hold the hook at the pin in the center with two fingers.



10. Guide the hook with the lower edge diagonally from the top to the bottom behind the bobbin cover.
11. Position the hook with the two lugs on the hook driver meeting the corresponding openings in the hook. The gray marking on the hook driver must be visible in the hole of the hook.
12. Insert the hook.
 - ⇒ The shuttle is magnetic and therefore pulled into the correct position.

13. Close the bobbin cover and the fastening bracket until the release bracket engages.
14. Turn the handwheel to check.
 - ⇒ The hook will rotate.
15. Insert a bobbin case and close the bobbin cover.
16. To absorb excess oil, sew or embroider on a test fabric.

Export the Log File

Settings  ► Machine  ► Information 
► Service Data 

Log files help service personnel to find errors in the firmware. If you are requested to do so by BERNINA Service, you can export a log file.

1. Insert the USB stick into the machine.
2. Confirm saving the log file and wait until the export is complete.
3. Close the window.



15.1 Storing the Machine

BERNINA recommends that you store the machine in its original packaging. If the machine is stored in a cold room, place the machine in a warm room for one hour before use.






1. Switch off the machine and disconnect it from the power supply.
2. Clean the machine.
3. Don't store the machine outdoors.
4. Protect the machine against climatic influences.

15.2 Dispose of the Machine


1. Delete personal data on the machine.
2. Sort components by material and dispose of in accordance with local laws and regulations.

Message	Cause	Solution
	The feed dog is not lowered.	▶ To lower the feed dog, push the button Feed Dog Up/Down .
	The selected needle and stitch plate cannot be used in combination.	<ol style="list-style-type: none"> 1. Replace the needle. 2. Replace the stitch plate.
	The selected presser foot does not match with the attached presser foot.	▶ Select the attached presser foot in the presser foot selection or change the presser foot.
	The needle is not at its top end.	▶ Adjust the needle position via the handwheel.
	The upper thread is used up.	▶ Rethread.
	The upper thread is broken.	▶ Rethread.
	The bobbin thread is used up.	▶ Rethread.
	The bobbin thread is broken.	<ol style="list-style-type: none"> 1. Clean the hook. 2. Rethread.
	The bobbin cover is open.	▶ Close the bobbin cover.
	The main motor is not running.	<ol style="list-style-type: none"> 1. Turn the handwheel clockwise until the needle is at its top position. 2. Remove the stitch plate. 3. Remove the thread remnants. 4. Clean the hook. 5. Remove the hook and make sure that there are no pieces of broken needle points on the magnetic back of the hook. 6. Insert the hook correctly.
	Incorrect presser foot for the BERNINA Dual Feed.	▶ Fit a presser foot with the designation «D».

16 Error messages

Message	Cause	Solution
	The fabric under the presser foot is too thick.	<ol style="list-style-type: none"> 1. Reduce the fabric thickness. 2. If the message does not appear at the sewing start but in the middle of a seam, increase the presser foot pressure. [▶ see page 36]
	The contact between the machine and the embroidery module is interrupted as a result of vibrations.	<ol style="list-style-type: none"> 1. Make sure that the embroidery module and the machine are standing on a stable, even surface. 2. Connect the embroidery module to the machine.
	The needle position doesn't correspond with the center of the hoop.	▶ Calibrate the hoop.
	The embroidery module is not attached.	<ol style="list-style-type: none"> 1. Connect the embroidery module to the machine. 2. Contact the specialized BERNINA dealer to have the machine checked.
	The hoop is not attached.	▶ Attach the hoop.
	The hoop is attached.	▶ Remove the embroidery hoop.
	The movement of the hoop follows.	▶ Tap Confirm .
	The embroidery design is partly outside the hoop.	▶ Reposition the embroidery design and start embroidering it again.
	The embroidery design is too large.	<ol style="list-style-type: none"> 1. Reduce the size of the embroidery design. 2. Attach a larger hoop.

Message	Cause	Solution
Insufficient free space on the BERNINA USB stick (optional accessory).	Not enough free space on the USB stick.	<ul style="list-style-type: none"> ▶ Delete data from the USB stick.
No personal data on the BERNINA USB stick (optional accessory).	No personal data for recovery available on the USB stick.	<ul style="list-style-type: none"> ▶ Make sure that the data and settings have been saved on the USB stick.
The recovery of personal data has failed.	The firmware update has been successful but the personal data could not be recovered.	<ol style="list-style-type: none"> 1. Make sure that the data and settings have been saved on the USB stick. 2. Transfer saved data to the machine.
No BERNINA USB stick is inserted. Make sure that the same BERNINA USB stick remains connected during the entire automatic update process.	USB stick is not inserted.	<ul style="list-style-type: none"> ▶ Use a BERNINA USB stick with enough free memory.
The firmware update has failed.	The latest firmware version cannot be found on the USB stick.	<ol style="list-style-type: none"> 1. Make sure that the compressed zip file has been unzipped for the firmware update. 2. Check whether the data for the software update is saved directly on the data medium and not in a file on the USB stick. 3. Updating Firmware.
	The machine must be cleaned/lubricated.	<ol style="list-style-type: none"> 1. Clean the machine. 2. Lubricate the hook. <p>Important information on oiling: too much oil can stain the fabric and thread.</p> <ul style="list-style-type: none"> ▶ After lubricating, always embroider on a test piece.
The automatic thread cutter (at the thread catcher) needs cleaning.	The automatic thread cutter needs cleaning. The message appears every time when the machine is started as soon as 1000 cutting cycles have been carried out.	<ol style="list-style-type: none"> 1. Tap Confirm. <ul style="list-style-type: none"> ⇒ The machine calls up the function Cleaning the Thread Catcher. 2. Clean the thread catcher according to the instructions on the screen. 3. The counter for the cutting cycles is reset.

Message	Cause	Solution
<p>Service interval reached: To ensure that your machine remains in proper working order in the long term, it is needed to service the machine by your BERNINA dealer.</p>	<p>The machine needs maintenance. The message appears once the programmed service interval has been reached.</p>	<ol style="list-style-type: none"> 1. Close the message. 2. Contact your BERNINA dealer. <p>After the third closing, the message is not displayed until the next service interval has been reached.</p> <p>Important information: When cleaning and maintenance work is carried out as instructed, the functionality and long service life of the machine is ensured. In case of non-compliance, the service life may be negatively affected and the warranty service may possibly become limited. The cost allocation for maintenance work is regulated nationally. Consult your authorized BERNINA dealer or your service center for more details.</p>
	<p>The calibration of the Buttonhole Foot with Slide #3A has failed.</p>	<ol style="list-style-type: none"> 1. Check the presser foot for ease of movement. If necessary, remove lint, dust and fabric remnants. 2. Clean the reflector with a soft, slightly damp microfiber cloth. 3. Check the position of the reflector. If necessary, correct the position of the reflector or replace the presser foot. 4. Check the plastic on the underside of the presser foot for signs of wear. If necessary, replace the presser foot. 5. Clean the feed dog. 6. Contact your BERNINA dealer.
	<p>The Internet connection is interrupted. It is not possible to receive messages.</p>	<ol style="list-style-type: none"> 1. Check the connection of the router to the Internet. 2. Switch the WiFi on the machine off and on again. 3. If the error still occurs, contact your authorized BERNINA dealer.
<p><i>Connection Failed</i></p>	<p>The connection to the WiFi network could not be established.</p>	<ol style="list-style-type: none"> 1. Select the WiFi network again and enter the network name (SSID) or the password correctly. 2. Check the router, e.g. that it is switched on.
<p>#1001</p>	<p>The button Thread Cutter  is stuck or defective.</p>	<ol style="list-style-type: none"> 1. Make sure that the button can be operated without restriction. 2. If the error still occurs, contact your BERNINA dealer.

Message	Cause	Solution
#1002	The button Needle Position Up/Down  is stuck or defective.	<ol style="list-style-type: none"> 1. Make sure that the button can be operated without restriction. 2. If the error still occurs, contact your BERNINA dealer.
#1003	The button Start/Stop  is stuck or defective.	<ol style="list-style-type: none"> 1. Make sure that the button can be operated without restriction. 2. If the error still occurs, contact your BERNINA dealer.
#1004 #1005 #1010	The exact cause of the malfunction cannot be determined.	<ol style="list-style-type: none"> 1. Restart the machine. 2. If the error still occurs, contact your BERNINA dealer.
#1103	The threader mechanism is not in the correct position.	<ol style="list-style-type: none"> 1. Confirm the message and press the Automatic Needle Threader  button. 2. Check the position of the threader mechanism. 3. If the needle threader is at the front, turn the needle threader slightly to the left until it is perpendicular to the machine head. If necessary, confirm the error message. Rethread the needle. 4. If the needle threader is not at the front, place your finger below the needle threader and gently press the needle threader upward. Rethread the needle.

The Automatic Needle Threader does not thread the needle

The needle selected in the needle selection cannot be automatically threaded, e.g. twin needle.

- ▶ Single Needle: Select the needle in the needle selection to match the attached needle. [▶ see page 30]
- ▶ Double and triple needles: Thread the needle by hand.

Automatic threading is not possible with the selected presser foot.

- ▶ Attach the appropriate presser foot and select it in the presser foot selection. [▶ see page 35]

The needle is bent.

- ▶ Replace the needle, make sure that a new BERNINA quality needle is used. [▶ see page 29]

The needle is incorrectly inserted.

- ▶ Insert the needle with the flat side to the back as far up as it will go into the needle holder and tighten the screw.

The automatic needle threader is dirty.

- ▶ Clean the needle threader. [▶ see page 86]

The threader mechanism is not in the correct position.

- ▶ Check the position of the threader mechanism.
- ▶ If the needle threader is at the front, turn the needle threader slightly to the left until it is perpendicular to the machine head. If necessary, confirm the error message. Rethread the needle.
- ▶ If the needle threader is not at the front, place your finger below the needle threader and gently press the needle threader upward. Rethread the needle.

The threader head is defective.

- ▶ Contact your BERNINA dealer.

BSR not detected

BSR cable not inserted correctly.

- ▶ Insert the BSR connector properly and ensure it is clicked into place.

The screen does not respond

Incorrect calibration data.

- ▶ Recalibrate the screen [▶ see page 85]
- ▶ If the calibration cannot be selected in the Setup Program, switch the machine on again while simultaneously pushing and holding the buttons **Needle Position Left/Right** .

The eco Mode is active.

- ▶ Tap **eco-mode** .

Error during Firmware Update

USB stick is not recognised.

- ▶ Use a BERNINA USB stick.

Error during Firmware Update

The update process is blocked and the animation on the screen is inactive.

- ▶ Remove the USB stick.
- ▶ Switch the machine off.
- ▶ Switch the machine on.
- ▶ Follow the instruction on the screen.
- ▶ Contact your BERNINA dealer.

Firmware update files are not found.

- ▶ Unpack the compressed ZIP file according to the update instructions.
- ▶ Store data for the firmware update directly on the data medium and not in a folder on the USB stick.

Skipped Stitches

Incorrect needle.

- ▶ Use the needle system 130/705H.

Needle blunt or bent.

- ▶ Replace the needle.

Poor quality needle.

- ▶ Use a new BERNINA quality needle.

The needle is incorrectly inserted.

- ▶ Insert the needle with the flat side to the back as far up as it will go into the needle holder and tighten the screw.

Incorrect needle point.

- ▶ Match the needle point with the textile structure of the project.

Incorrect needle/thread combination.

- ▶ Use a needle with a suitable needle size. [▶ see page 27]

Speed too low

Room temperature is too warm or too cold.

- ▶ Place the machine in a warm room one hour before use.

Reduced maximum speed.

- ▶ Move the speed control to the right.
- ▶ Modify the maximum sewing speed in the Settings. [▶ see page 41]
- ▶ Modify the maximum embroidery speed in the Settings. [▶ see page 43]

The Laser Dot is not visible or is at the wrong position

The laser is concealed or deflected by the presser foot or the needle.

- ▶ Raise the needle.
- ▶ Fit another presser foot.
- ▶ Lower the presser foot before starting sewing.
- ▶ Contact your BERNINA dealer.

The Light of the button "Start-/Stop" doesn't light up

Light is defective. ▶ Contact your BERNINA dealer.

The Machine doesn't start

The machine is not connected to the power supply. ▶ Insert the mains plug into the socket and into the machine.
▶ Check the socket for power.

Room temperature is too warm or too cold. ▶ Place the machine in a warm room one hour before use.
▶ Connect the machine and switch it on.

The machine is damaged. ▶ Contact your BERNINA dealer.

Needle Breaks

The needle is incorrectly inserted. ▶ Insert the needle with the flat side to the back as far up as it will go into the needle holder and tighten the screw.

Fabric was pulled. ▶ Feed the fabric evenly.

Thick fabric has been pushed. ▶ Use a suitable presser foot for thick fabric, e.g. Jeans Foot #8.
▶ Use the height compensation tool when sewing over a thick seam.

Knotted thread. ▶ Use quality thread.

The Sewing Light Does Not Light Up

The sewing light is not switched on. ▶ Switch on the sewing light in the settings. [▶ see page 39]

The sewing light is defect. ▶ Contact your BERNINA dealer.

Faulty Stitching

Thread remnants between the thread tension discs. ▶ Fold a piece of thin material and slide the folded edge (not the raw edges) between the thread tension discs.

Incorrectly threaded. ▶ Rethread the upper and lower thread.

Thread remnants below the bobbin case spring. ▶ Remove the bobbin case.
▶ Remove the thread remnants under the spring.

Upper Thread Breaks

Incorrect needle/thread combination.	▶ Match the needle with the thread size.
Upper thread is too tight.	▶ Reduce the upper thread tension.
Incorrectly threaded.	▶ Rethread the upper thread.
Poor quality thread.	▶ Use quality thread.
The stitch plate or the hook tip is damaged.	▶ Contact your BERNINA dealer to have the damages repaired. ▶ Replace the stitch plate.
The thread is caught in the area of the thread take-up lever.	▶ Remove the screw (1) on the head cover with the angular Torx screwdriver.  ▶ Pull the head cover at the bottom slightly forward. ▶ Tilt the head cover upward slightly and remove it. ▶ Remove the thread remnants. ▶ Attach the head cover and retighten the screw.

Upper Thread Indicator fails to respond

The upper thread indicator is not switched on.	▶ Switch on the upper thread indicator in the Settings. [▶ see page 40]
The upper thread indicator is defective.	▶ Contact your BERNINA dealer.

Upper Thread Indicator reacts too frequently

Upper thread not threaded correctly.	▶ Thread the upper thread correctly. [▶ see page 30]
Upper thread tension too low.	▶ Adjust the upper thread tension. [▶ see page 46], [▶ see page 71]
The upper thread indicator is defective.	▶ Contact your BERNINA dealer.

Buttonholes are repeatedly not sewn properly

The Buttonhole Foot with Slide #3A is not calibrated with the machine.	▶ Calibrate Buttonhole Foot with Slide #3A. [▶ see page 83]
Lens on the presser foot is dirty.	▶ Clean the lens with a soft, slightly damp cloth.

Stitch Width Not Adjustable

The selected needle and stitch plate cannot be used in combination.

- ▶ Replace the needle. [▶ see page 29]
- ▶ Replace the stitch plate. [▶ see page 27]

The presser foot selection prevents the adjustment of the stitch width.

- ▶ Attach and select a suitable presser foot. [▶ see page 36]

Uneven Stitch Formation

Upper thread too tight or too loose.

- ▶ Adjust the upper thread tension. [▶ see page 46]
- ▶ Check the thread feed from the thread spool.

Needle blunt or bent.

- ▶ Replace the needle, make sure that a new BERNINA quality needle is used. [▶ see page 29]

Poor quality needle.

- ▶ Use a new BERNINA quality needle.

Poor quality thread.

- ▶ Use quality thread.

Incorrect needle/thread combination.

- ▶ Match the needle with the thread size.

Incorrectly threaded.

- ▶ Rethread the upper thread. [▶ see page 30]
- ▶ Rehtread the bobbin thread. [▶ see page 34]

Fabric was pulled.

- ▶ Feed the fabric evenly.

Incorrect bobbin case is used.

- ▶ Use supplied bobbin case.

Lower thread too tight or too loose.

- ▶ Contact your BERNINA dealer.

Lower Thread Breaks

The bobbin case is damaged.

- ▶ Replace the bobbin case.

The stitch hole in the stitch plate is damaged.

- ▶ Contact your BERNINA dealer to have the damages repaired.
- ▶ Replace the stitch plate. [▶ see page 27]

Needle blunt or bent.

- ▶ Replace the needle. [▶ see page 29]

Bobbin Thread Indicator doesn't react

The bobbin door cover is opened.

- ▶ Close the bobbin cover.

The bobbin thread indicator is not switched on.

- ▶ Switch on the bobbin thread indicator in the Settings. [▶ see page 40]

The bobbin thread indicator is defective.

- ▶ Contact your BERNINA dealer.


USB stick is not detected

USB stick is incompatible.


- ▶ Use a BERNINA USB stick or compatible USB stick.

USB stick not with correct file system.


- ▶ Use a USB stick with the FAT32 file system.
-

Term	Value	Unit
Maximum Speed	1000	Stitches per Minute
Needle System	130/705	
Measurements without the Spool Pin (W × H × D)	520 × 355 × 215 (20.5 × 14.0 × 8.5)	mm (in)
Measurements incl. Embroidery Module without Spool Pin (W × H × D)	950 × 355 × 630 (37.4 × 14.0 × 24.8)	mm (in)
Weight of the Machine	14 (30.9)	kg (lb)
Weight of the Embroidery Module	6.4 14.1	kg (lb)
Energy Consumption	140	W
Input Voltage	100 – 240 50/60	V Hz
WiFi Frequency Band	2.4	GHz
WiFi Protocol	802.11 b/g/n	
Power Output (802.11 b)	19.19	dBm
Power Output (802.11 g)	19.68	dBm
Power Output (802.11 n)	19.53	dBm
Laser Class (according to IEC 60825-1:2014)		
Protection Class (Electrical Engineering)	II	


19 Stitch Patterns




Satin




Geometric




19 Stitch Patterns




Heirloom




Children




19 Stitch Patterns




Special




International



Seasons




Sport and Hobbies




19 Stitch Patterns


2234 2235



19.3 Buttonholes



19.4 Quilting Stitches



19.5 BSR Stitches



20 Embroidery Designs



Let your creativity run free. A large selection of embroidery designs is included with your machine.

After registering your machine, the included embroidery designs are available as downloads in an editable format at the BERNINA Customer Portal.

If you see one of the following pictograms below a number of the embroidery design, you can find additional information at

<https://www.bernina.com/specialeffects>.



Freestanding
Lace



PunchWork



Basic CutWork



Couching



Fringe
Embroidery



Projects in the
Hoop



Appliqué



Puffy Fonts



CutWork



Quilting



PaintWork



Trapunto



CrystalWork

20.1 Projects

You can find the detailed embroidery instructions at <https://www.bernina.com/pro-designs>.

51327-01



102 x 135 mm
4 x 5.3 inch



15.549

1. Isacord 40 1032
2. Isacord 40 1032
3. Isacord 40 1032
4. Isacord 40 1346
5. Isacord 40 0020
6. Isacord 40 0010
7. Isacord 40 0622
8. Isacord 40 1032
9. Isacord 40 1032
10. Isacord 40 0622



51327-02



131 x 103 mm
5.2 x 4.1 inch



15.314

1. Isacord 40 1032
2. Isacord 40 1032
3. Isacord 40 1032
4. Isacord 40 1346
5. Isacord 40 0020
6. Isacord 40 0010
7. Isacord 40 0622
8. Isacord 40 1032
9. Isacord 40 1032
10. Isacord 40 0622



51327-03




130 x 100 mm
5.1 x 3.9 inch



13.300

1. Isacord 40 1032
2. Isacord 40 1032
3. Isacord 40 1032
4. Isacord 40 1346
5. Isacord 40 0660
6. Isacord 40 1342
7. Isacord 40 0660
8. Isacord 40 0660
9. Isacord 40 1032
10. Isacord 40 0622



11. Isacord 40 1342

51327-04



97 x 132 mm
3.8 x 5.2 inch



11.958

1. Isacord 40 1032
2. Isacord 40 1032
3. Isacord 40 1032
4. Isacord 40 1346
5. Isacord 40 0660
6. Isacord 40 1342
7. Isacord 40 0660
8. Isacord 40 0660
9. Isacord 40 1032
10. Isacord 40 0622



11. Isacord 40 1342

12751-03




100 x 192 mm
3.9 x 7.6 inch



5.132

1. Isacord 40 2550
2. Isacord 40 2550
3. Isacord 40 2550
4. Isacord 40 2550
5. Isacord 40 2550
6. Isacord 40 2550
7. Isacord 40 2550
8. Isacord 40 2550



12888-05




125 x 190 mm
4.9 x 7.5 inch



13.411

1. Isacord 40 4032
2. Isacord 40 4032
3. Isacord 40 4032
4. Isacord 40 4032
5. Isacord 40 0010




20 Embroidery Designs

12888-06

98 x 113 mm
3.9 x 4.4 inch

4.457

1.  Isacord 40 4032
2.  Isacord 40 4032
3.  Isacord 40 4032
4.  Isacord 40 4032




51240-28

76 x 130 mm
3 x 5.1 inch

6.028

1.  Isacord 40 1332
2.  Isacord 40 0811
3.  Isacord 40 3963
4.  Isacord 40 3910
5.  Isacord 40 3810
6.  Isacord 40 0010
7.  Isacord 40 0131
8.  Isacord 40 1913
9.  Isacord 40 1521
10.  Isacord 40 2123
11.  Isacord 40 1322
12.  Isacord 40 0020
13.  Isacord 40 0020




51240-32

76 x 142 mm
3 x 5.6 inch

3.835

1.  Isacord 40 0010
2.  Isacord 40 0811
3.  Isacord 40 5450
4.  Isacord 40 4752
5.  Isacord 40 1725
6.  Isacord 40 0010
7.  Isacord 40 3743
8.  Isacord 40 1725
9.  Isacord 40 0020
10.  Isacord 40 0020



51240-27

87 x 80 mm
3.4 x 3.2 inch

4.258

1.  Isacord 40 0630
2.  Isacord 40 0630
3.  Isacord 40 0630
4.  Isacord 40 1332
5.  Isacord 40 0811
6.  Isacord 40 1322
7.  Isacord 40 0020



51298-02

99 x 129 mm
3.9 x 5.1 inch

9.279

1.  Isacord 40 0630
2.  Isacord 40 0630
3.  Isacord 40 0630
4.  Isacord 40 6051




51298-03

83 x 82 mm
3.3 x 3.2 inch

5.081

1.  Isacord 40 0870
2.  Isacord 40 0870
3.  Isacord 40 0870
4.  Isacord 40 1565



51298-04

38 x 230 mm
1.5 x 9.1 inch

17.556

1.  Isacord 40 0630
2.  Isacord 40 0630
3.  Isacord 40 0630
4.  Isacord 40 1220
5.  Isacord 40 1565
6.  Isacord 40 0870



51298-05

83 x 82 mm
3.3 x 3.2 inch

4.439

1.  Isacord 40 1565
2.  Isacord 40 1565
3.  Isacord 40 1565



51298-06

110 x 199 mm
4.3 x 7.8 inch

34.440

1.  Isacord 40 0630
2.  Isacord 40 1220
3.  Isacord 40 1860



51298-01

88 x 129 mm
3.4 x 5.1 inch

9.306


1.  Isacord 40 6051
2.  Isacord 40 6051
3.  Isacord 40 6051




20.2 Quilting

 LA12999-05

1. ■ Isacord 40 0020


 LA12999-03


1. ■ Isacord 40 0020


 LA12999-07


1. ■ Isacord 40 0020


 LA12999-06


1. ■ Isacord 40 0020


 LA12911-09


1. ■ Isacord 40 0020


 12416-03q


1. ■ Isacord 40 0020


 12416-04q

1. ■ Isacord 40 0020


 12416-24q


1. ■ Isacord 40 0020


 12416-26q

1. ■ Isacord 40 0020



 12416-48q

1. ■ Isacord 40 0020




 12607-16q

1. ■ Isacord 40 0020


 12607-20q


1. ■ Isacord 40 0020


 12607-21q


1. ■ Isacord 40 0020


 12616-16q


1. ■ Isacord 40 0020


 12736-11q


1. ■ Isacord 40 0020


 12736-12q


1. ■ Isacord 40 0020


 12736-13q


1. ■ Isacord 40 0020


 12736-14q


1. ■ Isacord 40 0020


 12736-15q

1. ■ Isacord 40 0020



 12736-16q

1. ■ Isacord 40 0020




 12736-17q


1. ■ Isacord 40 0020

 12736-18q


1. ■ Isacord 40 0020

 BD364q

1. ■ Isacord 40 0020

 BD367q

1. ■ Isacord 40 0020

 BD370q


1. ■ Isacord 40 0020

 BD373q


1. ■ Isacord 40 0020

 Basics_01


1. ■ Isacord 40 0020

 Basics_02


1. ■ Isacord 40 0020

 Basics_03

1. ■ Isacord 40 0020


 Basics_04

1. ■ Isacord 40 0020



 Basics_04_corner

1. ■ Isacord 40 0020


 Basics_05

1. ■ Isacord 40 0020


 12380-04q


1. ■ Isacord 40 0020


 12380-08q


1. ■ Isacord 40 0020


 12380-09q


1. ■ Isacord 40 0020


 32196-01


1. ■ Isacord 40 0020


 32196-02

1. ■ Isacord 40 0020


 32196-03


1. ■ Isacord 40 0020


 32196-04

1. ■ Isacord 40 0020



 32196-05

1. ■ Isacord 40 0020



 32196-06

1. ■ Isacord 40 0020


 32196-07


1. ■ Isacord 40 0020


 32196-08


1. ■ Isacord 40 0020


 32196-09


1. ■ Isacord 40 0020


 32196-10


1. ■ Isacord 40 0020


 32196-11


1. ■ Isacord 40 0020


 32196-12

1. ■ Isacord 40 0020


 32196-13


1. ■ Isacord 40 0020


 32196-14

1. ■ Isacord 40 0020



 32196-15

1. ■ Isacord 40 0020




 32196-16


1. ■ Isacord 40 0020


 32196-17


1. ■ Isacord 40 0020


 32196-18


1. ■ Isacord 40 0020


 32196-19


1. ■ Isacord 40 0020


 32196-20

1. ■ Isacord 40 0020


 32196-21


1. ■ Isacord 40 0020


 32196-22


1. ■ Isacord 40 0020


 32196-23


1. ■ Isacord 40 0020


 32196-24

1. ■ Isacord 40 0020



 32196-25

1. ■ Isacord 40 0020



 **32196-26**


1. ■ Isacord 40 0020


 **32196-27**

1. ■ Isacord 40 0020


 **32196-28**


1. ■ Isacord 40 0020


 **32196-29**


1. ■ Isacord 40 0020


 **32196-30**


1. ■ Isacord 40 0020


 **BD285q**


1. ■ Isacord 40 0020


 **BD288q**


1. ■ Isacord 40 0020


 **BD289q**


1. ■ Isacord 40 0020


 **BD292q**

1. ■ Isacord 40 0020



 **BD299q**

1. ■ Isacord 40 0020




BD308q

1. ■ Isacord 40 0020

**BD394**


1. ■ Isacord 40 0020

**BD412**


1. ■ Isacord 40 0020

**BD413**


1. ■ Isacord 40 0020

**BD513**


1. ■ Isacord 40 0020

**BD514**


1. ■ Isacord 40 0020

**BD553**

1. ■ Isacord 40 0020

**BD554**

1. ■ Isacord 40 0020

**BD567**

1. ■ Isacord 40 0020


**BD659**

1. ■ Isacord 40 0020




BD665


1. ■ Isacord 40 0020

**BD800**


1. ■ Isacord 40 0020

**BD801**


1. ■ Isacord 40 0020

**BD804**


1. ■ Isacord 40 0020

**BD837**

1. ■ Isacord 40 0020

**HE959**


1. ■ Isacord 40 0020

**QS101**


1. ■ Isacord 40 0020

**QS102**


1. ■ Isacord 40 0020

**QS103**

1. ■ Isacord 40 0020


**QS104**

1. ■ Isacord 40 0020




QS105

1. ■ Isacord 40 0020




QS106

1. ■ Isacord 40 0020




QS107

1. ■ Isacord 40 0020




QS108

1. ■ Isacord 40 0020




QS109

1. ■ Isacord 40 0020




QS110

1. ■ Isacord 40 0020




QS111

1. ■ Isacord 40 0020




QS112

1. ■ Isacord 40 0020



QS113

1. ■ Isacord 40 0020



20.3 Children

12435-16

48 x 93 mm
1.9 x 3.7 inch

8.239

1. Isacord 40 0721
2. Isacord 40 0015
3. Isacord 40 2250
4. Isacord 40 1060
5. Isacord 40 1755
6. Isacord 40 4174
7. Isacord 40 0721
8. Isacord 40 0630
9. Isacord 40 3241
10. Yenmet 7025
11. Isacord 40 0015
12. Isacord 40 1840
13. Isacord 40 1904
14. Yenmet 7024



12435-05

123 x 141 mm
4.9 x 5.6 inch

16.145

1. Isacord 40 4220
2. Isacord 40 0105
3. Isacord 40 0150
4. Isacord 40 5912
5. Isacord 40 5411
6. Isacord 40 0015
7. Isacord 40 0105
8. Isacord 40 3241
9. Isacord 40 5050
10. Isacord 40 1840
11. Isacord 40 4220
12. Isacord 40 1904
13. Isacord 40 0622
14. Isacord 40 0776
15. Isacord 40 0015
16. Isacord 40 5912
17. Isacord 40 5740
18. Isacord 40 0015
19. Isacord 40 3241



12435-15

69 x 26 mm
2.7 x 1 inch

1.847

1. Isacord 40 4220
2. Isacord 40 3241
3. Isacord 40 0015



12435-07

115 x 104 mm
4.5 x 4.1 inch

10.218

1. Isacord 40 3241
2. Yenmet 7033
3. Isacord 40 0015
4. Yenmet 7029
5. Isacord 40 5050
6. Yenmet 7029
7. Isacord 40 4220
8. Yenmet 7037
9. Yenmet 7033
10. Isacord 40 3241



12663-01

92 x 92 mm
3.6 x 3.6 inch

10.992

1. Isacord 40 5650
2. Isacord 40 5650
3. Isacord 40 5650
4. Isacord 40 5650
5. Isacord 40 5730
6. Isacord 40 0640
7. Isacord 40 5650
8. Isacord 40 5650
9. Isacord 40 5650



12663-02

92 x 92 mm
3.6 x 3.6 inch

12.657

1. Isacord 40 1140
2. Isacord 40 1140
3. Isacord 40 1140
4. Isacord 40 1140
5. Isacord 40 1800
6. Isacord 40 1521
7. Isacord 40 1140
8. Isacord 40 1140
9. Isacord 40 1140



12663-03

92 x 92 mm
3.6 x 3.6 inch

12.683

1. Isacord 40 4250
2. Isacord 40 4250
3. Isacord 40 4250
4. Isacord 40 4250
5. Isacord 40 4620
6. Isacord 40 4531
7. Isacord 40 4250
8. Isacord 40 4250
9. Isacord 40 4250



12663-04

92 x 92 mm
3.6 x 3.6 inch

12.366

1. Isacord 40 5650
2. Isacord 40 5650
3. Isacord 40 5650
4. Isacord 40 5650
5. Isacord 40 5730
6. Isacord 40 0640
7. Isacord 40 5650
8. Isacord 40 5650
9. Isacord 40 5650



20 Embroidery Designs

12663-05  92 x 92 mm
3.6 x 3.6 inch  12.754

- 1.  Isacord 40 1140
- 2.  Isacord 40 1140
- 3.  Isacord 40 1140
- 4.  Isacord 40 1140
- 5.  Isacord 40 1800
- 6.  Isacord 40 1521
- 7.  Isacord 40 1140
- 8.  Isacord 40 1140
- 9.  Isacord 40 1140



12663-06  92 x 92 mm
3.6 x 3.6 inch  12.674

- 1.  Isacord 40 4250
- 2.  Isacord 40 4250
- 3.  Isacord 40 4250
- 4.  Isacord 40 4250
- 5.  Isacord 40 4620
- 6.  Isacord 40 4531
- 7.  Isacord 40 4250
- 8.  Isacord 40 4250
- 9.  Isacord 40 4250



12663-07  92 x 92 mm
3.6 x 3.6 inch  11.750

- 1.  Isacord 40 5650
- 2.  Isacord 40 5650
- 3.  Isacord 40 5650
- 4.  Isacord 40 5650
- 5.  Isacord 40 5730
- 6.  Isacord 40 0640
- 7.  Isacord 40 5650
- 8.  Isacord 40 5650
- 9.  Isacord 40 5650



12663-08  92 x 92 mm
3.6 x 3.6 inch  12.849

- 1.  Isacord 40 1140
- 2.  Isacord 40 1140
- 3.  Isacord 40 1140
- 4.  Isacord 40 1140
- 5.  Isacord 40 1800
- 6.  Isacord 40 1521
- 7.  Isacord 40 1140
- 8.  Isacord 40 1140
- 9.  Isacord 40 1140



12663-09  92 x 92 mm
3.6 x 3.6 inch  12.553

- 1.  Isacord 40 4250
- 2.  Isacord 40 4250
- 3.  Isacord 40 4250
- 4.  Isacord 40 4250
- 5.  Isacord 40 4620
- 6.  Isacord 40 4531
- 7.  Isacord 40 4250
- 8.  Isacord 40 4250
- 9.  Isacord 40 4250



12663-10  92 x 92 mm
3.6 x 3.6 inch  13.976

- 1.  Isacord 40 5650
- 2.  Isacord 40 5650
- 3.  Isacord 40 5650
- 4.  Isacord 40 5650
- 5.  Isacord 40 5730
- 6.  Isacord 40 0640
- 7.  Isacord 40 5650
- 8.  Isacord 40 5650
- 9.  Isacord 40 5650



12663-11  92 x 92 mm
3.6 x 3.6 inch  12.649

- 1.  Isacord 40 1140
- 2.  Isacord 40 1140
- 3.  Isacord 40 1140
- 4.  Isacord 40 1140
- 5.  Isacord 40 1800
- 6.  Isacord 40 1521
- 7.  Isacord 40 1140
- 8.  Isacord 40 1140
- 9.  Isacord 40 1140



12663-12  92 x 92 mm
3.6 x 3.6 inch  10.863

- 1.  Isacord 40 4250
- 2.  Isacord 40 4250
- 3.  Isacord 40 4250
- 4.  Isacord 40 4250
- 5.  Isacord 40 4620
- 6.  Isacord 40 4531
- 7.  Isacord 40 4250
- 8.  Isacord 40 4250
- 9.  Isacord 40 4250



51325-02  124 x 147 mm
4.9 x 5.8 inch  22.405

- 1.  Isacord 40 2530
- 2.  Isacord 40 2300
- 3.  Isacord 40 2530
- 4.  Isacord 40 0015
- 5.  Isacord 40 1060
- 6.  Isacord 40 4114
- 7.  Isacord 40 4430
- 8.  Isacord 40 2910
- 9.  Isacord 40 2300
- 10.  Isacord 40 3622
- 11.  Isacord 40 0015
- 12.  Yenmet 7003
- 13.  Isacord 40 3710
- 14.  Isacord 40 2910
- 15.  Isacord 40 4430
- 16.  Isacord 40 5510
- 17.  Isacord 40 3622
- 18.  Isacord 40 2530
- 19.  Yenmet 7003



51325-06  111 x 122 mm
4.4 x 4.8 inch  14.919

- 1.  Isacord 40 4430
- 2.  Isacord 40 3710
- 3.  Isacord 40 0015
- 4.  Yenmet 7003
- 5.  Isacord 40 0015



20 Embroidery Designs

51325-01  **100 x 154 mm**
3.9 x 6.1 inch  20.577




1.  Isacord 40 1200
2.  Isacord 40 2300
3.  Isacord 40 0600
4.  Yenmet 7003
5.  Isacord 40 1060
6.  Isacord 40 2300
7.  Isacord 40 4430
8.  Isacord 40 4230
9.  Isacord 40 4114
10.  Isacord 40 5510
11.  Isacord 40 4114
12.  Isacord 40 3622
13.  Isacord 40 0015
14.  Yenmet 7003
15.  Isacord 40 2530
16.  Isacord 40 5830
17.  Isacord 40 3710
18.  Isacord 40 3622

51272-05  **117 x 153 mm**
4.6 x 6 inch  24.126



1.  Isacord 40 4250
2.  Isacord 40 0184
3.  Isacord 40 4174
4.  Isacord 40 0713
5.  Isacord 40 0660
6.  Isacord 40 0015
7.  Isacord 40 1351
8.  Isacord 40 0184
9.  Isacord 40 5552
10.  Isacord 40 0015
11.  Isacord 40 0713
12.  Isacord 40 4174

 **12590-03**  **135 x 147 mm**
5.3 x 5.8 inch  22.117



1.  Applique 1
2.  Applique 2
3.  Applique 1
4.  Applique 2
5.  Applique 1
6.  Applique 2
7.  Applique 1
8.  Applique 2
9.  Isacord 40 0015
10.  Isacord 40 0020
11.  Isacord 40 5510
12.  Isacord 40 5650
13.  Isacord 40 4230
14.  Isacord 40 4116
15.  Isacord 40 0132
16.  Isacord 40 0112
17.  Isacord 40 0015

 **Ck867**  **122 x 133 mm**
4.8 x 5.2 inch  28.880



1.  Applique 1
2.  Applique 2
3.  Applique 3
4.  Isacord 40 5730
5.  Isacord 40 2761
6.  Isacord 40 0630
7.  Isacord 40 3910
8.  Isacord 40 0015
9.  Isacord 40 0811
10.  Isacord 40 2830
11.  Isacord 40 4174
12.  Isacord 40 1701
13.  Isacord 40 3722
14.  Isacord 40 0015
15.  Isacord 40 1430

Cm031_48  **86 x 64 mm**
3.4 x 2.5 inch  6.433



1.  Isacord 40 5730
2.  Isacord 40 1352
3.  Isacord 40 1755
4.  Isacord 40 1730
5.  Isacord 40 3820
6.  Isacord 40 3040

12401-17  **99 x 55 mm**
3.9 x 2.2 inch  1.345



1.  Isacord 40 0731
2.  Isacord 40 0630
3.  Isacord 40 5934
4.  Isacord 40 0111
5.  Isacord 40 4240
6.  Isacord 40 1342

Nb198_48  **94 x 72 mm**
3.7 x 2.8 inch  9.711



1.  Isacord 40 2650
2.  Isacord 40 0713
3.  Isacord 40 2166
4.  Isacord 40 1755
5.  Isacord 40 3251
6.  Isacord 40 1600
7.  Isacord 40 2153
8.  Isacord 40 2152
9.  Isacord 40 2761

 **Cm226_48**  **63 x 63 mm**
2.5 x 2.5 inch  6.214



1.  Isacord 40 0101
2.  Isacord 40 0131
3.  Isacord 40 0152
4.  Isacord 40 0020
5.  Isacord 40 1755

20 Embroidery Designs

Be790307142 x 127 mm
5.6 x 5 inch

19.667

1. Applique 1
2. Applique 3
3. Isacord 40 3130
4. Applique 1
5. Applique 3
6. Isacord 40 0003
7. Isacord 40 1720
8. Isacord 40 0020
9. Isacord 40 0520
10. Isacord 40 3541

**Be790311**114 x 152 mm
4.5 x 6 inch

12.320

1. Applique 1
2. Applique 3
3. Isacord 40 0933
4. Applique 1
5. Applique 3
6. Applique 1
7. Applique 3
8. Isacord 40 0776
9. Applique 1
10. Applique 3
11. Isacord 40 1900
12. Isacord 40 0176
13. Isacord 40 0015
14. Isacord 40 0020

**Be790306**132 x 151 mm
5.2 x 6 inch

18.399

1. Isacord 40 0003
2. Applique 1
3. Applique 2
4. Isacord 40 0003
5. Isacord 40 3910
6. Isacord 40 0230
7. Isacord 40 2723
8. Isacord 40 1301
9. Isacord 40 2640
10. Isacord 40 0003
11. Isacord 40 3332

**Be790308**155 x 178 mm
6.1 x 7 inch

25.448

1. Isacord 40 0020
2. Applique 1
3. Applique 2
4. Isacord 40 1720

**Be790309**87 x 150 mm
3.4 x 5.9 inch

13.252

1. Applique 1
2. Applique 3
3. Isacord 40 0015
4. Isacord 40 1900
5. Isacord 40 0020
6. Isacord 40 4116
7. Isacord 40 0176
8. Isacord 40 0015
9. Isacord 40 0310

**Be790310**138 x 136 mm
5.4 x 5.4 inch

16.278

1. Applique 1
2. Applique 3
3. Applique 1
4. Applique 3
5. Isacord 40 1161
6. Isacord 40 1141
7. Isacord 40 1161
8. Isacord 40 3654
9. Isacord 40 0176
10. Isacord 40 1141
11. Isacord 40 0020
12. Isacord 40 0015
13. Isacord 40 1900

**Be790312**122 x 133 mm
4.8 x 5.2 inch

22.489

1. Applique 1
2. Applique 3
3. Applique 1
4. Applique 3
5. Isacord 40 0015
6. Isacord 40 1600
7. Isacord 40 0108
8. Isacord 40 2912
9. Isacord 40 3600
10. Isacord 40 1141
11. Isacord 40 0020

**Be790313**99 x 102 mm
3.9 x 4 inch

8.788

1. Applique 1
2. Applique 3
3. Isacord 40 3750
4. Isacord 40 1114
5. Isacord 40 1900
6. Isacord 40 3620
7. Isacord 40 2510
8. Isacord 40 5324
9. Isacord 40 1114
10. Isacord 40 1060
11. Isacord 40 4114
12. Isacord 40 0020
13. Isacord 40 0015



51266-06  70 x 166 mm
2.7 x 6.5 inch  13.036

1.  Isacord 40 0622
2.  Isacord 40 0622
3.  Isacord 40 0622
4.  Isacord 40 0520



20.4 Embellishment

12445-11  124 x 124 mm
4.9 x 4.9 inch  11.385

1.  Isacord 40 2520
2.  Isacord 40 2550
3.  Isacord 40 2504
4.  Isacord 40 2520
5.  Isacord 40 2715



12931-04  89 x 176 mm
3.5 x 6.9 inch  16.702

1.  Isacord 40 0660
2.  Isacord 40 0731
3.  Isacord 40 0660
4.  Isacord 40 0721
5.  Isacord 40 0741
6.  Isacord 40 0721
7.  Yenmet 7011



12931-01  150 x 150 mm
5.9 x 5.9 inch  25.245

1.  Isacord 40 0721
2.  Isacord 40 0731
3.  Isacord 40 0660
4.  Isacord 40 0721
5.  Isacord 40 0741
6.  Isacord 40 0660
7.  Yenmet 7011



51259-04  110 x 184 mm
4.3 x 7.3 inch  7.194

1.  Isacord 40 3743
2.  Isacord 40 1600



12879-07L  155 x 151 mm
6.1 x 5.9 inch  5.437

1.  Isacord 40 5740
2.  Isacord 40 5440
3.  Isacord 40 5210



21021-14  122 x 122 mm
4.8 x 4.8 inch  18.063

1.  Isacord 40 1252
2.  Isacord 40 1161
3.  Isacord 40 1565



Nb843_48  87 x 121 mm
3.4 x 4.8 inch  8.976

1.  Isacord 40 9971
2.  Isacord 40 9937
3.  Isacord 40 9925
4.  Isacord 40 9975
5.  Isacord 40 9978
6.  Isacord 40 9973
7.  Isacord 40 9982
8.  Isacord 40 1972



Nb826_48  135 x 133 mm
5.3 x 5.2 inch  11.154

1.  Isacord 40 9971
2.  Isacord 40 9978
3.  Isacord 40 9973
4.  Isacord 40 1972



20 Embroidery Designs

12633-06

120 x 120 mm
4.7 x 4.7 inch

18.023

1. Isacord 40 0015



12473-04

94 x 184 mm
3.7 x 7.3 inch

11.531

1. Isacord 40 5552
2. Isacord 40 5374



12675-05

110 x 156 mm
4.3 x 6.1 inch

15.012

1. Isacord 40 0703
2. Isacord 40 5832



12473-06

133 x 120 mm
5.3 x 4.7 inch

11.358

1. Isacord 40 4610
2. Isacord 40 5633



80090-06

84 x 37 mm
3.3 x 1.4 inch

3.766

1. Applique 1
2. Applique 2
3. Isacord 40 4103



80090-07

128 x 36 mm
5 x 1.4 inch

5.450

1. Applique 1
2. Applique 2
3. Isacord 40 5440



19999-002

125 x 136 mm
4.9 x 5.4 inch

10.184

1. Isacord 40 0015
2. Isacord 40 0015
3. Isacord 40 0015



51259-07

126 x 150 mm
4.9 x 5.9 inch

7.750

1. Isacord 40 3743
2. Isacord 40 1600



Nb934_48

132 x 165 mm
5.2 x 6.5 inch

9.168

1. Isacord 40 2241
2. Isacord 40 1154
3. Isacord 40 1346
4. Isacord 40 1161
5. Isacord 40 2222
6. Isacord 40 5833
7. Isacord 40 1154
8. Isacord 40 2241



Nb935_48

104 x 169 mm
4.1 x 6.6 inch

10.171

1. Isacord 40 2222
2. Isacord 40 1346
3. Isacord 40 0232
4. Isacord 40 1154
5. Isacord 40 5833
6. Isacord 40 2241



20 Embroidery Designs

12508-24

122 x 122 mm
4.8 x 4.8 inch

15.870

1. Isacord 40 0352
2. Isacord 40 6133
3. Isacord 40 4752
4. Isacord 40 5552



12508-26

44 x 152 mm
1.7 x 6 inch

8.761

1. Isacord 40 0352
2. Isacord 40 6133
3. Isacord 40 4752
4. Isacord 40 5552



12508-27

78 x 77 mm
3.1 x 3 inch

6.600

1. Isacord 40 0352
2. Isacord 40 6133
3. Isacord 40 4752
4. Isacord 40 5552



12490-03

118 x 113 mm
4.6 x 4.5 inch

6.669

1. Isacord 40 0108
2. Isacord 40 3641
3. Isacord 40 3652



12490-04

146 x 122 mm
5.8 x 4.8 inch

8.724

1. Isacord 40 0108
2. Isacord 40 3641
3. Isacord 40 3652



12490-05

126 x 104 mm
4.9 x 4.1 inch

6.148

1. Isacord 40 0108
2. Isacord 40 3641
3. Isacord 40 3652



Fp887

135 x 187 mm
5.3 x 7.4 inch

12.658

1. Isacord 40 2504



12528-12

124 x 124 mm
4.9 x 4.9 inch

39.751

1. Isacord 40 0931
2. Isacord 40 0824
3. Isacord 40 0851



12528-03

76 x 130 mm
3 x 5.1 inch

16.171

1. Isacord 40 0851
2. Isacord 40 0824
3. Isacord 40 0931



Oc07207

106 x 138 mm
4.2 x 5.4 inch

17.807

1. Yenmet 7012
2. Isacord 40 0670
3. Yenmet 7012



82007-11

 112 x 94 mm
4.4 x 3.7 inch

 13.622

1.  Applique 1
2.  Applique 3
3.  Applique 1
4.  Applique 3
5.  Applique 1
6.  Isacord 40 1805
7.  Isacord 40 2152
8.  Isacord 40 2520
9.  Isacord 40 2500
10.  Isacord 40 2115
11.  Isacord 40 0761

**82007-44**

 114 x 115 mm
4.5 x 4.5 inch

 9.467

1.  Isacord 40 2152
2.  Isacord 40 2520

**82006-30**

 100 x 174 mm
3.9 x 6.9 inch

 21.584

1.  Isacord 40 0020
2.  Isacord 40 4174
3.  Isacord 40 0020
4.  Isacord 40 4174
5.  Isacord 40 0771
6.  Isacord 40 0832
7.  Isacord 40 0108
8.  Isacord 40 4174
9.  Isacord 40 0660
10.  Isacord 40 1526

**Nb251_48**

 72 x 103 mm
2.8 x 4.1 inch

 8.612

1.  Isacord 40 2155
2.  Isacord 40 2504
3.  Isacord 40 0020
4.  Isacord 40 0020

**Be790405**

 126 x 185 mm
4.9 x 7.3 inch

 7.734

1.  Isacord 40 3102

**Fb126**

 87 x 102 mm
3.4 x 4 inch

 2.668

1.  Isacord 40 1220
2.  Isacord 40 1805

**Be790407**

 200 x 271 mm
7.9 x 10.7 inch

 19.455

1.  Isacord 40 2510

**Be790502**

 60 x 58 mm
2.4 x 2.3 inch

 1.814

1.  Isacord 40 3541



20.5 Flowers

21005-13


 165 x 132 mm
6.5 x 5.2 inch

 30.036

1.  Isacord 40 0015
2.  Isacord 40 1902
3.  Isacord 40 2721
4.  Isacord 40 2506
5.  Isacord 40 1010
6.  Isacord 40 4122
7.  Isacord 40 5912
8.  Isacord 40 5833
9.  Isacord 40 1366
10.  Isacord 40 2830



11.  Isacord 40 2506
12.  Isacord 40 0015

Pk50012-03


 151 x 151 mm
5.9 x 5.9 inch

 10.859

1.  Isacord 40 5830
2.  Isacord 40 2732
3.  Isacord 40 2810
4.  Isacord 40 2300
5.  Isacord 40 1030
6.  Isacord 40 5100
7.  Isacord 40 2650
8.  Isacord 40 4111



Pk50012-02


 142 x 142 mm
5.6 x 5.6 inch

 12.960

1.  Isacord 40 5830
2.  Isacord 40 2810
3.  Isacord 40 2300
4.  Isacord 40 5100
5.  Isacord 40 2732
6.  Isacord 40 1030
7.  Isacord 40 2650
8.  Isacord 40 4111



Pk50012-04


 78 x 205 mm
3.1 x 8.1 inch

 9.480

1.  Isacord 40 5830
2.  Isacord 40 2810
3.  Isacord 40 2732
4.  Isacord 40 2300
5.  Isacord 40 5100
6.  Isacord 40 1030
7.  Isacord 40 2650
8.  Isacord 40 4111



Fs332_48


 95 x 174 mm
3.8 x 6.8 inch

 12.081

1.  Isacord 40 1725



Fs337_48


 69 x 136 mm
2.7 x 5.4 inch

 7.998

1.  Isacord 40 1730



51227-08


 124 x 136 mm
4.9 x 5.4 inch

 26.077

1.  Isacord 40 4430
2.  Isacord 40 0010
3.  Isacord 40 4610
4.  Isacord 40 4515
5.  Isacord 40 0702
6.  Isacord 40 1521
7.  Isacord 40 1840
8.  Isacord 40 1860
9.  Isacord 40 4174
10.  Isacord 40 1704
11.  Isacord 40 1521
12.  Isacord 40 0010
13.  Isacord 40 1755
14.  Isacord 40 4174



51227-10


 90 x 136 mm
3.5 x 5.4 inch

 20.095

1.  Isacord 40 4515
2.  Isacord 40 0702
3.  Isacord 40 4610
4.  Isacord 40 0010
5.  Isacord 40 1840
6.  Isacord 40 1860
7.  Isacord 40 4531
8.  Isacord 40 4515
9.  Isacord 40 1521
10.  Isacord 40 1840
11.  Isacord 40 4174
12.  Isacord 40 0010
13.  Isacord 40 1840



20 Embroidery Designs

Fq987_48  **119 x 160 mm**
4.7 x 6.3 inch  32.494

1.  Isacord 40 5650
2.  Isacord 40 5833
3.  Isacord 40 0352
4.  Isacord 40 5934
5.  Isacord 40 0465
6.  Isacord 40 0015
7.  Isacord 40 0781
8.  Isacord 40 0170
9.  Isacord 40 0731
10.  Isacord 40 0640
11.  Isacord 40 0352
12.  Isacord 40 6133



12505-03  **108 x 162 mm**
4.3 x 6.4 inch  8.606

1.  Isacord 40 0442
2.  Isacord 40 5822
3.  Isacord 40 5822
4.  Isacord 40 6031
5.  Isacord 40 5633
6.  Isacord 40 2810
7.  Isacord 40 2530
8.  Isacord 40 2530
9.  Isacord 40 2155
10.  Isacord 40 0811
11.  Isacord 40 0811
12.  Isacord 40 2830
13.  Isacord 40 2830
14.  Isacord 40 2504
15.  Isacord 40 4103
16.  Isacord 40 0311
17.  Isacord 40 0931
18.  Isacord 40 0020



12505-11  **104 x 174 mm**
4.1 x 6.9 inch  11.419

1.  Isacord 40 0442
2.  Isacord 40 5822
3.  Isacord 40 5822
4.  Isacord 40 6031
5.  Isacord 40 5633
6.  Isacord 40 2810
7.  Isacord 40 2810
8.  Isacord 40 0811
9.  Isacord 40 0811
10.  Isacord 40 1800
11.  Isacord 40 1800
12.  Isacord 40 0504
13.  Isacord 40 0931
14.  Isacord 40 2900
15.  Isacord 40 2530
16.  Isacord 40 1912
17.  Isacord 40 1543
18.  Isacord 40 0020



12505-04  **124 x 176 mm**
4.9 x 6.9 inch  11.861

1.  Isacord 40 3840
2.  Isacord 40 3840
3.  Isacord 40 3815
4.  Isacord 40 0311
5.  Isacord 40 5822
6.  Isacord 40 5822
7.  Isacord 40 6031
8.  Isacord 40 5633
9.  Isacord 40 0811
10.  Isacord 40 0811
11.  Isacord 40 2530
12.  Isacord 40 2530
13.  Isacord 40 2300
14.  Isacord 40 2155
15.  Isacord 40 0931
16.  Isacord 40 0504
17.  Isacord 40 0020
18.  Isacord 40 0442



12505-10  **102 x 134 mm**
4 x 5.3 inch  5.685

1.  Isacord 40 4103
2.  Isacord 40 0442
3.  Isacord 40 5822
4.  Isacord 40 5822
5.  Isacord 40 6031
6.  Isacord 40 5633
7.  Isacord 40 1800
8.  Isacord 40 1800
9.  Isacord 40 2504
10.  Isacord 40 0504
11.  Isacord 40 0020



Fq472_48  **123 x 123 mm**
4.8 x 4.8 inch  4.361

1.  Isacord 40 5610
2.  Isacord 40 2830
3.  Isacord 40 5822
4.  Isacord 40 5664
5.  Isacord 40 5643
6.  Isacord 40 0015
7.  Isacord 40 0811
8.  Isacord 40 5633
9.  Isacord 40 1725



Fq464_48  **110 x 104 mm**
4.3 x 4.1 inch  7.122

1.  Isacord 40 5822
2.  Isacord 40 5552
3.  Isacord 40 5650
4.  Isacord 40 1913
5.  Isacord 40 1725
6.  Isacord 40 2115



21027-01  **123 x 122 mm**
4.8 x 4.8 inch  6.211

1.  Isacord 40 1805
2.  Isacord 40 2721
3.  Isacord 40 2520
4.  Isacord 40 5100
5.  Isacord 40 4114
6.  Isacord 40 4103
7.  Isacord 40 0506
8.  Isacord 40 5115



21027-14

121 x 121 mm
4.8 x 4.8 inch

7.316

1. Isacord 40 5115
2. Isacord 40 2721
3. Isacord 40 4114
4. Isacord 40 2520
5. Isacord 40 0506
6. Isacord 40 5100
7. Isacord 40 1805
8. Isacord 40 5115
9. Isacord 40 1805



21027-16

57 x 152 mm
2.3 x 6 inch

4.222

1. Isacord 40 1805
2. Isacord 40 2520
3. Isacord 40 2721
4. Isacord 40 5100
5. Isacord 40 0506
6. Isacord 40 5115
7. Isacord 40 4114
8. Isacord 40 5115
9. Isacord 40 1805



21027-17

57 x 152 mm
2.3 x 6 inch

4.179

1. Isacord 40 1805
2. Isacord 40 2723
3. Isacord 40 2520
4. Isacord 40 5100
5. Isacord 40 0506
6. Isacord 40 4103
7. Isacord 40 4114
8. Isacord 40 5115
9. Isacord 40 1805



21017-01

104 x 158 mm
4.1 x 6.2 inch

11.928

1. Isacord 40 0453
2. Isacord 40 0442
3. Isacord 40 0345
4. Isacord 40 1301
5. Isacord 40 0702
6. Isacord 40 1102
7. Isacord 40 0761
8. Isacord 40 0640



Fl135

88 x 87 mm
3.5 x 3.4 inch

12.688

1. Isacord 40 5633
2. Isacord 40 5822
3. Isacord 40 5326
4. Isacord 40 0870
5. Isacord 40 3241



Fl136

85 x 89 mm
3.3 x 3.5 inch

8.501

1. Isacord 40 0311
2. Isacord 40 5326
3. Isacord 40 5374
4. Isacord 40 0101
5. Isacord 40 3951



Fl138

85 x 75 mm
3.3 x 3 inch

6.321

1. Isacord 40 5934
2. Isacord 40 5633
3. Isacord 40 3331
4. Isacord 40 3211
5. Isacord 40 5326



Fl142

79 x 86 mm
3.1 x 3.4 inch

10.298

1. Isacord 40 2830
2. Isacord 40 3541
3. Isacord 40 2830
4. Isacord 40 1912
5. Isacord 40 0108
6. Isacord 40 3842
7. Isacord 40 0453
8. Isacord 40 5326



Fl230

78 x 72 mm
3.1 x 2.9 inch

6.959

1. Isacord 40 0600
2. Isacord 40 5933
3. Isacord 40 5944



Fl171

70 x 89 mm
2.7 x 3.5 inch

11.783

1. Isacord 40 5100
2. Isacord 40 5100
3. Isacord 40 5326
4. Isacord 40 2600
5. Isacord 40 3040



82006-07

 124 x 166 mm
4.9 x 6.5 inch

 22.673

1.  Isacord 40 4174
2.  Isacord 40 0108
3.  Isacord 40 0643
4.  Isacord 40 0660
5.  Isacord 40 0643
6.  Isacord 40 4421
7.  Isacord 40 1526
8.  Isacord 40 0660
9.  Isacord 40 4174



21006-02

 114 x 135 mm
4.5 x 5.3 inch

 9.132

1.  Isacord 40 3910
2.  Isacord 40 3900
3.  Isacord 40 0015
4.  Isacord 40 3962
5.  Isacord 40 3900
6.  Isacord 40 0015



12457-06

 106 x 172 mm
4.2 x 6.8 inch

 12.636

1.  Isacord 40 3150
2.  Isacord 40 3210
3.  Isacord 40 0311
4.  Isacord 40 3331
5.  Isacord 40 3711
6.  Isacord 40 2250
7.  Isacord 40 2241
8.  Isacord 40 2051



12457-13

 113 x 130 mm
4.4 x 5.1 inch

 6.676

1.  Isacord 40 6051
2.  Isacord 40 5730
3.  Isacord 40 5722
4.  Isacord 40 2905
5.  Isacord 40 0311
6.  Isacord 40 5115
7.  Isacord 40 5220
8.  Isacord 40 5100



21009-21

 65 x 108 mm
2.6 x 4.2 inch

 4.343

1.  Isacord 40 5220
2.  Isacord 40 5210



Be790408

 58 x 90 mm
2.3 x 3.5 inch

 2.045

1.  Isacord 40 3541



Be790401

 206 x 242 mm
8.1 x 9.5 inch

 11.593

1.  Isacord 40 1900




20.6 Frames

 12383-09

 113 x 77 mm
4.4 x 3 inch

 4.757


1.  Isacord 40 0020
2.  Isacord 40 4174
3.  Isacord 40 0608
4.  Isacord 40 2101
5.  Isacord 40 1600
6.  Isacord 40 0015
7.  Isacord 40 4174


 12621-19

 155 x 104 mm
6.1 x 4.1 inch

 8.360


1.  Isacord 40 0015
2.  Isacord 40 0015
3.  Isacord 40 0721
4.  Isacord 40 4620
5.  Isacord 40 0352
6.  Isacord 40 0152
7.  Isacord 40 0672
8.  Isacord 40 4620
9.  Isacord 40 0015




20 Embroidery Designs

12621-04  155 x 104 mm
6.1 x 4.1 inch  3.803


1. Isacord 40 0015
2. Isacord 40 0015
3.  Isacord 40 0020
4.  Isacord 40 2051
5. Isacord 40 0015
6.  Isacord 40 4174
7.  Isacord 40 2051
8. Isacord 40 0015


12621-05  155 x 104 mm
6.1 x 4.1 inch  5.811


1. Isacord 40 0015
2. Isacord 40 0015
3.  Isacord 40 0933
4.  Isacord 40 1252
5.  Isacord 40 1252
6. Isacord 40 0015


12621-09  155 x 104 mm
6.1 x 4.1 inch  5.520

1. Isacord 40 0015
2. Isacord 40 0015
3.  Isacord 40 0504
4.  Isacord 40 0542
5.  Isacord 40 0542
6. Isacord 40 0015


12621-02  155 x 104 mm
6.1 x 4.1 inch  5.558


1.  Isacord 40 0020
2.  Isacord 40 0020
3.  Isacord 40 0811
4.  Isacord 40 4952
5.  Isacord 40 1921
6.  Isacord 40 4952
7.  Isacord 40 0020


80090-26  124 x 129 mm
4.9 x 5.1 inch  6.087


1.  Applique 1
2.  Applique 2
3.  Applique 1
4.  Applique 2
5.  Isacord 40 4103
6.  Isacord 40 2508


12611-27  137 x 137 mm
5.4 x 5.4 inch  3.961

1.  Applique 1
2.  Applique 2
3.  Isacord 40 5440


12611-28  140 x 140 mm
5.5 x 5.5 inch  3.649

1.  Applique 1
2.  Applique 2
3.  Isacord 40 0703


12649-05  91 x 88 mm
3.6 x 3.5 inch  9.087

1.  Applique 1
2.  Applique 2
3.  Isacord 40 1840
4.  Isacord 40 1860
5. Isacord 40 0015


12606-26  139 x 139 mm
5.5 x 5.5 inch  5.211

1.  Isacord 40 0670
2.  Isacord 40 0670
3.  Isacord 40 0670


12606-33  43 x 70 mm
1.7 x 2.8 inch  2.376

1.  Isacord 40 0670
2.  Isacord 40 0670
3.  Isacord 40 0670



20 Embroidery Designs

12606-37  46 x 78 mm
1.8 x 3.1 inch  2.692

- 1.  Isacord 40 0670
- 2.  Isacord 40 0670
- 3.  Isacord 40 0670



12611-21  72 x 156 mm
2.8 x 6.1 inch  11.513

- 1.  Applique 1
- 2.  Applique 2
- 3.  Isacord 40 1703



12611-23  72 x 156 mm
2.8 x 6.1 inch  12.817

- 1.  Applique 1
- 2.  Applique 2
- 3.  Isacord 40 1902



12611-22  72 x 156 mm
2.8 x 6.1 inch  12.504

- 1.  Applique 1
- 2.  Applique 2
- 3.  Isacord 40 1703



12611-24  72 x 156 mm
2.8 x 6.1 inch  12.613

- 1.  Applique 1
- 2.  Applique 2
- 3.  Isacord 40 1902



20.7 Seasons

Pk10056-01  142 x 135 mm
5.6 x 5.3 inch  14.255

- 1.  Isacord 40 0842
- 2.  Isacord 40 3644
- 3.  Isacord 40 0945
- 4.  Isacord 40 3730
- 5.  Isacord 40 3730
- 6.  Isacord 40 0945
- 7.  Isacord 40 0101
- 8.  Isacord 40 0132



Pk10056-02  109 x 198 mm
4.3 x 7.8 inch  17.105

- 1.  Isacord 40 0128
- 2.  Isacord 40 0945
- 3.  Isacord 40 0842
- 4.  Isacord 40 3644
- 5.  Isacord 40 0870
- 6.  Isacord 40 1860
- 7.  Isacord 40 3951
- 8.  Isacord 40 0132



Pk10056-03  103 x 137 mm
4 x 5.4 inch  16.597

- 1.  Isacord 40 3951
- 2.  Isacord 40 0842
- 3.  Isacord 40 0945
- 4.  Isacord 40 0670
- 5.  Isacord 40 0670
- 6.  Isacord 40 0842
- 7.  Isacord 40 0945
- 8.  Isacord 40 1860
- 9.  Isacord 40 1860
- 10.  Isacord 40 1860
- 11.  Isacord 40 0101
- 12.  Isacord 40 0128
- 13.  Isacord 40 3644



Pk10056-04  98 x 167 mm
3.9 x 6.6 inch  15.801

- 1.  Isacord 40 3730
- 2.  Isacord 40 3730
- 3.  Isacord 40 1860
- 4.  Isacord 40 1860
- 5.  Isacord 40 0842
- 6.  Isacord 40 0128
- 7.  Isacord 40 0101
- 8.  Isacord 40 0945
- 9.  Isacord 40 3644



20 Embroidery Designs

Pk10056-05

 63 x 126 mm
2.5 x 4.9 inch

 9.472

1.  Isacord 40 0842
2.  Isacord 40 0101
3.  Isacord 40 0945
4.  Isacord 40 3644
5.  Isacord 40 0128
6.  Isacord 40 3910
7.  Isacord 40 1140
8.  Isacord 40 1140
9.  Isacord 40 0945



51260-04

 117 x 147 mm
4.6 x 5.8 inch

 19.740

1.  Isacord 40 3710
2.  Isacord 40 0010
3.  Isacord 40 1260
4.  Isacord 40 0311
5.  Isacord 40 4332
6.  Isacord 40 3644
7.  Isacord 40 1260
8.  Isacord 40 1346



51260-05

 121 x 132 mm
4.8 x 5.2 inch

 16.058

1.  Isacord 40 1260
2.  Isacord 40 4332
3.  Isacord 40 1346
4.  Isacord 40 2222
5.  Isacord 40 3644
6.  Isacord 40 0311
7.  Isacord 40 1260



Pk10001-031

 127 x 178 mm
5 x 7 inch

 4.406

1.  Isacord 40 2830
2.  Isacord 40 2830
3.  Isacord 40 2152
4.  Isacord 40 4430
5.  Isacord 40 2830



Pk10019-06

 36 x 190 mm
1.4 x 7.5 inch

 14.430

1.  Isacord 40 0670
2.  Isacord 40 5740
3.  Isacord 40 1730
4.  Isacord 40 0670
5.  Isacord 40 2530
6.  Isacord 40 0832
7.  Isacord 40 2508
8.  Isacord 40 0134
9.  Isacord 40 0904



D90004

 199 x 326 mm
7.8 x 12.8 inch

 59.413

1.  Isacord 40 0520
2.  Isacord 40 0811
3.  Isacord 40 2830
4.  Isacord 40 2704
5.  Isacord 40 0520
6.  Isacord 40 2830
7.  Yenmet 7032
8.  Isacord 40 2704
9.  Isacord 40 0811
10.  Isacord 40 0630
11.  Isacord 40 0731
12.  Isacord 40 2830
13.  Isacord 40 3040
14.  Isacord 40 2704
15.  Isacord 40 2830
16.  Isacord 40 0811
17.  Yenmet 7032
18.  Isacord 40 2704
19.  Isacord 40 2830
20.  Yenmet 7032
21.  Isacord 40 0010



Pk10057-04

 140 x 236 mm
5.5 x 9.3 inch

 15.097

1.  Isacord 40 2721
2.  Isacord 40 2905
3.  Isacord 40 2830
4.  Isacord 40 3611
5.  Isacord 40 4122
6.  Isacord 40 5722
7.  Isacord 40 5730
8.  Isacord 40 6011
9.  Isacord 40 2520
10.  Isacord 40 2152
11.  Isacord 40 1260



12695-04

 122 x 146 mm
4.8 x 5.7 inch

 29.640

1.  Isacord 40 6051
2.  Isacord 40 6051
3.  Isacord 40 6051
4.  Isacord 40 0015
5.  Isacord 40 0015
6.  Isacord 40 0015
7.  Yenmet 7034
8.  Isacord 40 0542
9.  Isacord 40 5531
10.  Isacord 40 0741
11.  Isacord 40 5400
12.  Isacord 40 1805
13.  Isacord 40 1902



20 Embroidery Designs

82023-14

119 x 123 mm
4.7 x 4.8 inch

14.989

1. Isacord 40 1753
2. Isacord 40 1753
3. Isacord 40 1753
4. Isacord 40 0010
5. Isacord 40 5100
6. Isacord 40 5210
7. Isacord 40 5220
8. Isacord 40 2101
9. Isacord 40 1753



82023-15

124 x 152 mm
4.9 x 6 inch

9.577

1. Isacord 40 5210
2. Isacord 40 5220
3. Isacord 40 5100
4. Isacord 40 1805
5. Isacord 40 2101
6. Isacord 40 1753



82023-13

106 x 156 mm
4.2 x 6.1 inch

11.315

1. Isacord 40 5220
2. Isacord 40 1753
3. Isacord 40 1805
4. Isacord 40 2101
5. Isacord 40 5210
6. Isacord 40 5100



Hg795_48

89 x 164 mm
3.5 x 6.5 inch

3.453

1. Isacord 40 5730
2. Isacord 40 5513
3. Isacord 40 4430
4. Isacord 40 1032
5. Isacord 40 1900
6. Isacord 40 4113



12597-16

88 x 85 mm
3.5 x 3.3 inch

15.862

1. Isacord 40 0904
2. Isacord 40 0940



12858-04

159 x 164 mm
6.3 x 6.4 inch

16.385

1. Isacord 40 0015
2. Isacord 40 0015



80009-17

86 x 130 mm
3.4 x 5.1 inch

6.582

1. Isacord 40 5934
2. Isacord 40 5866
3. Isacord 40 5934



He255

133 x 127 mm
5.2 x 5 inch

17.198

1. Isacord 40 0111
2. Isacord 40 1701
3. Isacord 40 1800
4. Isacord 40 1701
5. Isacord 40 1800
6. Isacord 40 2640
7. Isacord 40 5650
8. Isacord 40 5610
9. Isacord 40 0015
10. Isacord 40 0111
11. Isacord 40 1060
12. Isacord 40 3910
13. Isacord 40 0800
14. Isacord 40 0940
15. Isacord 40 0651
16. Isacord 40 0832
17. Isacord 40 0651
18. Isacord 40 0832
19. Isacord 40 3650
20. Isacord 40 1351
21. Isacord 40 0108



20 Embroidery Designs

He252  **88 x 145 mm**
3.5 x 5.7 inch  12.251

1.  Isacord 40 1902
2.  Isacord 40 1701
3.  Isacord 40 1902
4.  Isacord 40 0532
5.  Isacord 40 0842
6.  Isacord 40 0532
7.  Isacord 40 0842
8.  Isacord 40 1902
9.  Isacord 40 0651
10.  Isacord 40 1123
11.  Isacord 40 5220
12.  Isacord 40 5210
13.  Isacord 40 5422
14.  Isacord 40 0101
15.  Isacord 40 1430
16.  Isacord 40 1725
17.  Isacord 40 0520
18.  Isacord 40 0824
19.  Isacord 40 3910
20.  Isacord 40 3650
21.  Isacord 40 3910
22.  Isacord 40 1902
23.  Isacord 40 3650
24.  Isacord 40 1123
25.  Isacord 40 5324
26.  Isacord 40 1154



Hg746_48  **112 x 138 mm**
4.4 x 5.4 inch  17.815

1.  Isacord 40 3040
2.  Applique 1
3.  Applique 2
4.  Isacord 40 0221
5.  Applique 1
6.  Applique 2
7.  Isacord 40 0142
8.  Isacord 40 0108
9.  Applique 1
10.  Applique 2
11.  Isacord 40 0800
12.  Isacord 40 0020
13.  Isacord 40 1200
14.  Isacord 40 0020
15.  Isacord 40 0670
16.  Isacord 40 0142



Rc514  **74 x 99 mm**
2.9 x 3.9 inch  15.603

1.  Isacord 40 1172
2.  Isacord 40 0842
3.  Isacord 40 0651
4.  Isacord 40 0821
5.  Isacord 40 0941
6.  Isacord 40 0101
7.  Isacord 40 0640
8.  Isacord 40 3910
9.  Isacord 40 4103
10.  Isacord 40 3522
11.  Isacord 40 0842




Hg747_48  **124 x 147 mm**
4.9 x 5.8 inch  18.378

1.  Isacord 40 0970
2.  Isacord 40 3770
3.  Isacord 40 5912
4.  Isacord 40 0520
5.  Isacord 40 0811
6.  Isacord 40 3350
7.  Isacord 40 3040
8.  Applique 1
9.  Applique 2
10.  Applique 1
11.  Applique 2
12.  Applique 1
13.  Applique 2
14.  Isacord 40 4073
15.  Isacord 40 0020
16.  Isacord 40 1200
17.  Isacord 40 0101




Nb754_48  **114 x 128 mm**
4.5 x 5 inch  13.084

1.  Yenmet 7037
2.  Isacord 40 2155
3.  Isacord 40 0651
4.  Isacord 40 0101
5.  Isacord 40 2532
6.  Isacord 40 0640
7.  Isacord 40 1352
8.  Yenmet 7030
9.  Isacord 40 0232
10.  Isacord 40 1123



Nb759_48  **99 x 62 mm**
3.9 x 2.4 inch  4.937

1.  Yenmet 7037
2.  Isacord 40 0640
3.  Isacord 40 1352
4.  Isacord 40 0232
5.  Isacord 40 1123



Hd976  **101 x 108 mm**
4 x 4.3 inch  18.674

1.  Isacord 40 3962
2.  Yenmet 7029
3.  Isacord 40 0640
4.  Isacord 40 0824
5.  Isacord 40 0015
6.  Isacord 40 0020
7.  Isacord 40 0142
8.  Isacord 40 3962
9.  Isacord 40 0020
10.  Isacord 40 0934
11.  Isacord 40 0640
12.  Isacord 40 0824
13.  Isacord 40 5650
14.  Isacord 40 5531
15.  Isacord 40 1220
16.  Isacord 40 5822
17.  Isacord 40 5531
18.  Isacord 40 0015
19.  Isacord 40 5822



Hg806_48  **28 x 170 mm**
1.1 x 6.7 inch  4.988

1.  Isacord 40 2530
2.  Isacord 40 1900
3.  Isacord 40 5730
4.  Isacord 40 1114
5.  Isacord 40 4430
6.  Isacord 40 4113



20 Embroidery Designs

12415-32

 80 x 191 mm
3.1 x 7.5 inch

 10.937

1.  YLI variations 8019



12415-29

 108 x 172 mm
4.3 x 6.8 inch

 4.814

1.  YLI variations 8019



12655-14

 164 x 110 mm
6.4 x 4.4 inch

 16.122

1.  Isacord 40 1115
2.  Isacord 40 1055



12433-05

 83 x 124 mm
3.3 x 4.9 inch

 15.348

1.  Isacord 40 1725
2.  Isacord 40 5934
3.  Isacord 40 0442
4.  Isacord 40 2115
5.  Isacord 40 2711



12417-04

 84 x 97 mm
3.3 x 3.8 inch

 8.085

1.  Isacord 40 1010
2.  Isacord 40 0811
3.  Isacord 40 1311
4.  Isacord 40 1543



Be790303

 70 x 70 mm
2.7 x 2.8 inch

 5.764

1.  Isacord 40 0532
2.  Isacord 40 1300
3.  Isacord 40 0020
4.  Isacord 40 0015



Be790301

 127 x 89 mm
5 x 3.5 inch

 10.153

1.  Isacord 40 1161
2.  Isacord 40 1860
3.  Isacord 40 1805
4.  Isacord 40 4116
5.  Isacord 40 1114
6.  Isacord 40 0532
7.  Isacord 40 0731
8.  Isacord 40 1322
9.  Isacord 40 1141
10.  Isacord 40 0020



12421-11

 40 x 43 mm
1.6 x 1.7 inch

 3.965

1.  Isacord 40 0800
2.  Isacord 40 0904
3.  Isacord 40 0020
4.  Isacord 40 0015




12421-37

 67 x 61 mm
2.6 x 2.4 inch

 1.320

1.  Isacord 40 0020



20.8 Hobbies

51255-01

118 x 134 mm
4.6 x 5.3 inch

15.568

1. Isacord 40 0702
2. Isacord 40 0020
3. Isacord 40 0702
4. Isacord 40 0020
5. Isacord 40 0660
6. Isacord 40 0506
7. Isacord 40 4174
8. Isacord 40 0702
9. Isacord 40 0660



Pk10036-01

152 x 142 mm
6 x 5.6 inch

23.529

1. Isacord 40 0670
2. Isacord 40 0670
3. Isacord 40 0670
4. Isacord 40 0670
5. Isacord 40 0670
6. Isacord 40 0670
7. Isacord 40 0670
8. Isacord 40 0822
9. Isacord 40 2152
10. Isacord 40 2241
11. Isacord 40 2224
12. Isacord 40 0941
13. Isacord 40 0651
14. Isacord 40 0822
15. Isacord 40 0670



Pk10036-02

126 x 133 mm
5 x 5.2 inch

20.563

1. Isacord 40 0670
2. Isacord 40 0670
3. Isacord 40 0670
4. Isacord 40 0670
5. Isacord 40 0670
6. Isacord 40 2152
7. Isacord 40 2241
8. Isacord 40 0822
9. Isacord 40 2224
10. Isacord 40 0941
11. Isacord 40 0651
12. Isacord 40 0822
13. Isacord 40 0670



51303-07

121 x 140 mm
4.8 x 5.5 inch

14.327

1. Isacord 40 1055
2. Isacord 40 1055
3. Isacord 40 1055
4. Isacord 40 0010
5. Isacord 40 0941
6. Isacord 40 0651
7. Isacord 40 0941
8. Isacord 40 1055




12611-02

119 x 151 mm
4.7 x 5.9 inch

6.224

1. Isacord 40 0151
2. Isacord 40 5440
3. Isacord 40 5440
4. Isacord 40 5440



82014-28

142 x 117 mm
5.6 x 4.6 inch

26.582

1. Applique 1
2. Applique 2
3. Isacord 40 0105
4. Isacord 40 0020
5. Isacord 40 4073
6. Isacord 40 1902



12796-03L

194 x 278 mm
7.6 x 10.9 inch

31.215

1. Isacord 40 1904



12932-07

127 x 178 mm
5 x 7 inch

13.885

1. Isacord 40 1010
2. Isacord 40 1010
3. Isacord 40 0101
4. Isacord 40 1921
5. Isacord 40 1921
6. Isacord 40 0101



20 Embroidery Designs

51217-05L

159 x 210 mm
6.3 x 8.3 inch

28.887

1. Isacord 40 3040
2. Isacord 40 0842
3. Isacord 40 0660
4. Isacord 40 0853
5. Isacord 40 0138
6. Isacord 40 3971
7. Isacord 40 2250
8. Isacord 40 0020



12611-08

80 x 120 mm
3.1 x 4.7 inch

5.770

1. Applique 1
2. Applique 2
3. Applique 1
4. Applique 2
5. Isacord 40 1154
6. Isacord 40 5440
7. Isacord 40 1902




12611-18

130 x 158 mm
5.1 x 6.2 inch

8.045

1. Applique 1
2. Applique 2
3. Isacord 40 0151
4. Isacord 40 5440




Nx737

72 x 99 mm
2.8 x 3.9 inch

10.793

1. Isacord 40 0015
2. Yenmet 7005
3. Isacord 40 3962
4. Isacord 40 0020



Nx741

80 x 78 mm
3.1 x 3.1 inch

11.206

1. Isacord 40 0131
2. Isacord 40 0111
3. Isacord 40 0970
4. Isacord 40 0015
5. Isacord 40 3971
6. Yenmet 7009
7. Yenmet 7003
8. Isacord 40 4230
9. Isacord 40 4174



12383-18

91 x 171 mm
3.6 x 6.7 inch

5.182

1. Isacord 40 4174



12472-01

138 x 142 mm
5.4 x 5.6 inch

23.233

1. Isacord 40 2504
2. Isacord 40 3901
3. Isacord 40 5610
4. Isacord 40 4240
5. Isacord 40 0015
6. Isacord 40 0015
7. Isacord 40 1123
8. Isacord 40 0761
9. Isacord 40 1902
10. Isacord 40 2504
11. Isacord 40 3901
12. Isacord 40 5610
13. Isacord 40 4240
14. Isacord 40 1300



Be790606

100 x 86 mm
3.9 x 3.4 inch

7.445

1. Isacord 40 0020
2. Isacord 40 1306



Be790608

80 x 80 mm
3.2 x 3.1 inch

7.937

1. Isacord 40 0020



Be790603

80 x 75 mm
3.2 x 2.9 inch

11.824

1. Isacord 40 0015
2. Isacord 40 3654



20 Embroidery Designs

Be790602

80 x 75 mm
3.1 x 3 inch

10.169

1. Isacord 40 5643
2. Isacord 40 5912
3. Isacord 40 0015



12675-05

110 x 156 mm
4.3 x 6.1 inch

15.012

1. Isacord 40 0703
2. Isacord 40 5832



12704-01

137 x 168 mm
5.4 x 6.6 inch

23.027

1. Isacord 40 0250
2. Isacord 40 0546
3. Isacord 40 1701
4. Isacord 40 1902
5. Isacord 40 0020
6. Isacord 40 0184
7. Isacord 40 1701



Pk10035-03

138 x 214 mm
5.4 x 8.4 inch

33.825

1. Isacord 40 1906
2. Isacord 40 1805
3. Isacord 40 0731
4. Isacord 40 0842
5. Isacord 40 0660
6. Isacord 40 0453
7. Isacord 40 5743
8. Isacord 40 0010
9. Isacord 40 0781
10. Isacord 40 0874
13. Isacord 40 0922



11. Isacord 40 0221
12. Isacord 40 1375
14. Isacord 40 0941
15. Isacord 40 0941

Pk10035-02

140 x 217 mm
5.5 x 8.6 inch

29.153

1. Isacord 40 0842
2. Isacord 40 0853
3. Isacord 40 1055
4. Isacord 40 1375
5. Isacord 40 0010
6. Isacord 40 0640
7. Isacord 40 0781
8. Isacord 40 0941
9. Isacord 40 0874
10. Isacord 40 1375
13. Isacord 40 0941




11. Isacord 40 0922
12. Isacord 40 0941

90003-10

136 x 200 mm
5.4 x 7.9 inch

38.385

1. Isacord 40 0010
2. Isacord 40 1141
3. Isacord 40 1332
4. Isacord 40 1233
5. Isacord 40 6011
6. Isacord 40 6051
7. Isacord 40 5531
8. Isacord 40 0020
9. Isacord 40 6051
10. Isacord 40 0020



11. Isacord 40 0020

20.9 Animals

12600-04

94 x 78 mm
3.7 x 3.1 inch

16.093

1. Isacord 40 0020
2. Isacord 40 0020
3. Yenmet 7029
4. Isacord 40 4410
5. Isacord 40 5115
6. Yenmet 7003
7. Isacord 40 4643
8. Isacord 40 0020
9. Yenmet 7013
10. Yenmet 7009



12418-21

74 x 96 mm
2.9 x 3.8 inch

3.616

1. Isacord 40 0020




12383-03

 57 x 39 mm
2.2 x 1.5 inch

 5.542

1.  Isacord 40 0020
2.  Isacord 40 4174
3.  Isacord 40 3730
4.  Isacord 40 3630
5.  Isacord 40 3654
6.  Isacord 40 4174
7.  Isacord 40 0184




12418-13

 93 x 55 mm
3.6 x 2.2 inch

 9.066

1.  Isacord 40 6141
2.  Isacord 40 5822
3.  Isacord 40 0970
4.  Isacord 40 1123
5.  Isacord 40 0853
6.  Isacord 40 2250
7.  Isacord 40 1055
8.  Isacord 40 0020
9.  Isacord 40 0945



51303-04

 81 x 154 mm
3.2 x 6.1 inch

 9.641

1. Isacord 40 0010
2. Isacord 40 0010
3. Isacord 40 0010
4.  Isacord 40 0941
5.  Isacord 40 0941
6.  Isacord 40 0941
7.  Isacord 40 0020
8.  Isacord 40 1600
9.  Isacord 40 1600
10.  Isacord 40 1600
11.  Isacord 40 1010
12.  Isacord 40 0310



12676-01

 81 x 148 mm
3.2 x 5.8 inch

 15.344

1.  Isacord 40 2171
2.  Isacord 40 2530
3.  Isacord 40 2155
4.  Isacord 40 2520
5.  Isacord 40 2500



Cm263_48

 116 x 192 mm
4.6 x 7.6 inch

 14.402

1.  Isacord 40 3151
2.  Isacord 40 0532
3.  Isacord 40 1755
4.  Isacord 40 2171
5.  Isacord 40 2761
6. Isacord 40 0015
7.  Isacord 40 0020
8.  Isacord 40 2155



12389-10

 53 x 45 mm
2.1 x 1.8 inch

 2.784

1.  Isacord 40 0020
2.  Yenmet 7003
3.  Isacord 40 0170
4.  Isacord 40 0811
5.  Isacord 40 0940
6.  Isacord 40 0800
7.  Isacord 40 0713
8.  Isacord 40 0933
9.  Isacord 40 0020




12760-02

 122 x 171 mm
4.8 x 6.7 inch

 21.512

1.  Isacord 40 0020



Wp415_48

 132 x 148 mm
5.2 x 5.8 inch

 25.110

1.  Isacord 40 0941
2.  Isacord 40 0532
3.  Isacord 40 0945
4.  Isacord 40 0020


 Cm216_48

 47 x 67 mm
1.9 x 2.6 inch

 5.046

1.  Isacord 40 1010
2.  Isacord 40 0101
3.  Isacord 40 0132
4.  Isacord 40 0020
5.  Isacord 40 0124
6.  Isacord 40 1010
7.  YLI variations 8012


 Cm213_48

 58 x 102 mm
2.3 x 4 inch

 7.866

1.  Isacord 40 1840
2.  Isacord 40 1055
3.  Isacord 40 1252
4.  Isacord 40 0651
5.  Isacord 40 0660
6.  Isacord 40 0020
7.  Isacord 40 1055



20 Embroidery Designs

Wp421_48

 96 x 137 mm
3.8 x 5.4 inch

 14.219

1.  Isacord 40 1161
2.  Isacord 40 1876
3.  Isacord 40 1154



Na248

 78 x 73 mm
3.1 x 2.9 inch

 10.132

1.  Isacord 40 0101
2.  Isacord 40 3971
3.  Isacord 40 2220
4.  Isacord 40 0132
5.  Isacord 40 2051
6.  Isacord 40 2155
7.  Isacord 40 2320
8.  Isacord 40 2220
9.  Yenmet 7023



Hd977

 98 x 98 mm
3.8 x 3.9 inch

 13.738

1.  Isacord 40 3962
2.  Isacord 40 0015
3.  Isacord 40 0640
4.  Isacord 40 0824
5.  Isacord 40 2650
6.  Isacord 40 0020
7.  Isacord 40 0142
8.  Isacord 40 0640
9.  Isacord 40 0824
10.  Isacord 40 2650
11.  Isacord 40 2830
12.  Isacord 40 1352
13.  Yenmet 7029



Lj598

 106 x 81 mm
4.2 x 3.2 inch

 15.746

1.  Isacord 40 0101
2.  Isacord 40 0131
3.  Isacord 40 0132
4.  Isacord 40 4174
5.  Isacord 40 0108
6.  Isacord 40 0020
7.  Isacord 40 5933
8.  Isacord 40 0453



20.10 Mini

12819-04

 30 x 37 mm
1.2 x 1.5 inch

 1.396

1.  Isacord 40 0020
2.  Isacord 40 2530
3.  Isacord 40 0800
4.  Isacord 40 0131



12418-27

 13 x 25 mm
0.5 x 1 inch

 339

1.  Isacord 40 5822
2.  Isacord 40 2250




12508-12

 44 x 34 mm
1.8 x 1.3 inch

 1.789

1.  Isacord 40 4752
2.  Isacord 40 0352
3.  Isacord 40 5552



12508-21

 46 x 60 mm
1.8 x 2.4 inch

 2.629

1.  Isacord 40 6133
2.  Isacord 40 4752
3.  Isacord 40 5552



12558-01

41 x 40 mm
1.6 x 1.6 inch

6.713

1. Isacord 40 0184
2. Isacord 40 0015
3. Isacord 40 5555
4. Isacord 40 0220
5. Isacord 40 5912
6. Isacord 40 1521
7. Isacord 40 1352




12558-02

59 x 34 mm
2.3 x 1.3 inch

6.274

1. Isacord 40 0184
2. Isacord 40 0015
3. Isacord 40 1352
4. Isacord 40 1521
5. Isacord 40 5555
6. Isacord 40 5722



12558-03

46 x 44 mm
1.8 x 1.7 inch

7.540

1. Isacord 40 0184
2. Isacord 40 5555
3. Isacord 40 0015
4. Isacord 40 1311
5. Isacord 40 1521
6. Isacord 40 5722
7. Isacord 40 5912
8. Isacord 40 1352
9. Isacord 40 0731
10. Isacord 40 0630



12558-04

42 x 96 mm
1.7 x 3.8 inch

8.089

1. Isacord 40 6156
2. Isacord 40 0184
3. Isacord 40 5912
4. Isacord 40 1352
5. Isacord 40 1521
6. Isacord 40 0015
7. Isacord 40 5555
8. Isacord 40 5722



12558-05

43 x 50 mm
1.7 x 2 inch

8.013

1. Isacord 40 0184
2. Isacord 40 5555
3. Isacord 40 0015
4. Isacord 40 5912
5. Isacord 40 5722
6. Isacord 40 1102
7. Isacord 40 1301
8. Isacord 40 1311
9. Isacord 40 1352



12819-02

33 x 30 mm
1.3 x 1.2 inch

1.588

1. Isacord 40 4071
2. Isacord 40 0015
3. Isacord 40 0800
4. Isacord 40 0020



12373-08

16 x 16 mm
0.6 x 0.6 inch

232

1. Isacord 40 0776



12819-06

34 x 25 mm
1.4 x 1 inch

914

1. Isacord 40 0970
2. Isacord 40 0771
3. Isacord 40 0945
4. Isacord 40 1725



12819-17

32 x 34 mm
1.3 x 1.4 inch

1.277

1. Isacord 40 3830
2. Isacord 40 3730
3. Isacord 40 5531



12903-05

31 x 48 mm
1.2 x 1.9 inch

1.471

1. Isacord 40 1860
2. Isacord 40 1840
3. Isacord 40 0660
4. Isacord 40 3150



20 Embroidery Designs

12903-06

 30 x 46 mm
1.2 x 1.8 inch

 1.358

1.  Isacord 40 5115
2.  Isacord 40 4740
3.  Isacord 40 3150



12903-07

 21 x 45 mm
0.8 x 1.8 inch

 741

1.  Isacord 40 4740
2.  Isacord 40 5115
3.  Isacord 40 3150



12903-08

 25 x 45 mm
1 x 1.8 inch

 1.984

1.  Isacord 40 0660
2.  Isacord 40 4740
3.  Isacord 40 1840
4.  Isacord 40 0741
5.  Isacord 40 3150



51215-20

 28 x 28 mm
1.1 x 1.1 inch

 805

1.  Isacord 40 0811
2.  Isacord 40 1252
3.  Isacord 40 1904
4.  Isacord 40 0020



51253-01

 28 x 48 mm
1.1 x 1.9 inch

 1.356

1.  Isacord 40 0506
2.  Isacord 40 0670
3.  Isacord 40 2520
4.  Isacord 40 2530
5.  Isacord 40 4174



51253-07

 24 x 42 mm
0.9 x 1.7 inch

 1.008

1.  Isacord 40 0506
2.  Isacord 40 2160
3.  Isacord 40 2530
4.  Isacord 40 2520



51329-01

 34 x 32 mm
1.4 x 1.3 inch

 1.406

1.  Isacord 40 1220
2.  Isacord 40 0672
3.  Isacord 40 1055



51329-02

 32 x 39 mm
1.3 x 1.5 inch

 1.920

1.  Isacord 40 1055
2.  Isacord 40 0672
3.  Isacord 40 1055
4.  Isacord 40 1220



51329-03

 35 x 35 mm
1.4 x 1.4 inch

 1.474

1.  Isacord 40 2504
2.  Isacord 40 0672
3.  Isacord 40 1055




51329-07

 30 x 37 mm
1.2 x 1.5 inch

 1.248

1.  Isacord 40 1220
2.  Isacord 40 2715
3.  Isacord 40 0672



20 Embroidery Designs

51215-18

30 x 29 mm
1.2 x 1.1 inch

994

1. Isacord 40 6011
2. Isacord 40 1904
3. Isacord 40 5912
4. Isacord 40 5633



CJ587

24 x 33 mm
0.9 x 1.3 inch

1.919

1. Isacord 40 2171
2. Isacord 40 1840
3. Isacord 40 5610



20.11 Lace

12896-04

114 x 116 mm
4.5 x 4.6 inch

29.153

1. Isacord 40 0442



12896-03

117 x 117 mm
4.6 x 4.6 inch

29.923

1. Isacord 40 1032



12889-09

133 x 224 mm
5.3 x 8.8 inch

51.499

1. Isacord 40 0017
2. Isacord 40 3652
3. Isacord 40 2650
4. Isacord 40 3030



82011-28

134 x 99 mm
5.3 x 3.9 inch

22.201

1. Isacord 40 0660
2. Yenmet 7013



12742-01

137 x 133 mm
5.4 x 5.2 inch

41.668

1. Isacord 40 1911



82018-13

177 x 223 mm
7 x 8.8 inch

71.896

1. Isacord 40 0010



12410-08

80 x 168 mm
3.2 x 6.6 inch

22.500

1. Isacord 40 1874



12896-05

116 x 117 mm
4.6 x 4.6 inch

32.525

1. Isacord 40 0781



20 Embroidery Designs

82011-30

11 x 13 mm
0.4 x 0.5 inch

17.293

1. Isacord 40 0660
2. Yenmet 7013



Nb952_48

108 x 119 mm
4.3 x 4.7 inch

22.514

1. Isacord 40 0020
2. Isacord 40 4174
3. Isacord 40 0020
4. Isacord 40 4174
5. Isacord 40 0761



12659-01

45 x 58 mm
1.8 x 2.3 inch

6.790

1. Isacord 40 1352
2. Isacord 40 1430



12659-06

37 x 59 mm
1.4 x 2.3 inch

6.465

1. Isacord 40 4625
2. Isacord 40 4515



21021-25

34 x 71 mm
1.3 x 2.8 inch

4.748

1. Isacord 40 1252




Oc00303

101 x 110 mm
4 x 4.4 inch

35.018

1. Isacord 40 0015



12633-20

34 x 170 mm
1.4 x 6.7 inch

12.897

1. Isacord 40 0015



12508-08

40 x 151 mm
1.6 x 5.9 inch

7.102

1. Isacord 40 0352
2. Isacord 40 4752
3. Isacord 40 0124



12508-17

42 x 152 mm
1.6 x 6 inch

7.962

1. Isacord 40 0352
2. Isacord 40 4752
3. Isacord 40 5552



Oc33411

24 x 177 mm
0.9 x 7 inch

15.868

1. Isacord 40 0015



20 Embroidery Designs

Oc33416
 36 x 128 mm
1.4 x 5 inch

 16.090

1.  Isacord 40 1902
2.  Isacord 40 0015

**12485-12**
 41 x 139 mm
1.6 x 5.5 inch

 3.391

1.  Isacord 40 1134
2.  Isacord 40 0520
3.  Isacord 40 4240
4.  Isacord 40 4111
5.  Isacord 40 0702
6.  Isacord 40 1430

**12485-31**
 46 x 225 mm
1.8 x 8.9 inch

 2.174

1.  Isacord 40 0702
2.  Isacord 40 0520

**21013-29**
 40 x 152 mm
1.6 x 6 inch

 7.569

1.  Isacord 40 4332

**Be110415**
 44 x 172 mm
1.7 x 6.8 inch

 6.436

1.  Isacord 40 6051
2.  Isacord 40 0811
3.  Isacord 40 1921

**Fa981**
 35 x 142 mm
1.4 x 5.6 inch

 3.709

1.  Isacord 40 1055

**21002-21**
 21 x 151 mm
0.8 x 5.9 inch

 3.176

1.  Isacord 40 1252

**21009-29**
 32 x 152 mm
1.3 x 6 inch

 4.649

1.  Isacord 40 5210

**82005-40**
 26 x 240 mm
1 x 9.4 inch

 8.256

1.  Isacord 40 0851

**Be790702**
 73 x 190 mm
2.9 x 7.5 inch

 9.135

1.  Isacord 40 0442



20 Embroidery Designs

Na914_48

19 x 120 mm
0.7 x 4.7 inch

4.691

1. ■ Isacord 40 3151
2. ■ Isacord 40 3251
3. ■ Isacord 40 3150



Cm473_48

32 x 209 mm
1.2 x 8.2 inch

8.963

1. ■ Isacord 40 3920
2. ■ Isacord 40 3962



Fb436_48

29 x 133 mm
1.1 x 5.2 inch

4.735

1. ■ Isacord 40 3130
2. ■ Isacord 40 3150
3. ■ Isacord 40 4240




20.12 Modern Monograms

12863-01

113 x 119 mm
4.4 x 4.7 inch

10.297

1. ■ Isacord 40 0020
2. ■ Isacord 40 0020
3. ■ Isacord 40 0020




12863-02

113 x 119 mm
4.4 x 4.7 inch

10.441

1. ■ Isacord 40 0020
2. ■ Isacord 40 0020
3. ■ Isacord 40 0020




12863-03

113 x 119 mm
4.4 x 4.7 inch

10.224

1. ■ Isacord 40 0020
2. ■ Isacord 40 0020
3. ■ Isacord 40 0020



12863-04

113 x 119 mm
4.4 x 4.7 inch

10.360

1. ■ Isacord 40 0020
2. ■ Isacord 40 0020
3. ■ Isacord 40 0020




12863-05

113 x 119 mm
4.4 x 4.7 inch

10.658

1. ■ Isacord 40 0020
2. ■ Isacord 40 0020
3. ■ Isacord 40 0020



12863-06

113 x 119 mm
4.4 x 4.7 inch

10.414

1. ■ Isacord 40 0020
2. ■ Isacord 40 0020
3. ■ Isacord 40 0020



20 Embroidery Designs

12863-07

113 x 119 mm
4.4 x 4.7 inch

10.430

1. ■ Isacord 40 0020
2. ■ Isacord 40 0020
3. ■ Isacord 40 0020



12863-08

113 x 119 mm
4.4 x 4.7 inch

10.741

1. ■ Isacord 40 0020
2. ■ Isacord 40 0020
3. ■ Isacord 40 0020



12863-09

113 x 119 mm
4.4 x 4.7 inch

9.720

1. ■ Isacord 40 0020
2. ■ Isacord 40 0020
3. ■ Isacord 40 0020




12863-10

113 x 119 mm
4.4 x 4.7 inch

9.836

1. ■ Isacord 40 0020
2. ■ Isacord 40 0020
3. ■ Isacord 40 0020




12863-11

113 x 119 mm
4.4 x 4.7 inch

10.644

1. ■ Isacord 40 0020
2. ■ Isacord 40 0020
3. ■ Isacord 40 0020



12863-12

113 x 119 mm
4.4 x 4.7 inch

10.019

1. ■ Isacord 40 0020
2. ■ Isacord 40 0020
3. ■ Isacord 40 0020



12863-13

113 x 119 mm
4.4 x 4.7 inch

10.896

1. ■ Isacord 40 0020
2. ■ Isacord 40 0020
3. ■ Isacord 40 0020



12863-14

113 x 119 mm
4.4 x 4.7 inch

10.622

1. ■ Isacord 40 0020
2. ■ Isacord 40 0020
3. ■ Isacord 40 0020




12863-15

113 x 119 mm
4.4 x 4.7 inch

10.168

1. ■ Isacord 40 0020
2. ■ Isacord 40 0020
3. ■ Isacord 40 0020



12863-16

113 x 119 mm
4.4 x 4.7 inch

10.539

1. ■ Isacord 40 0020
2. ■ Isacord 40 0020
3. ■ Isacord 40 0020



20 Embroidery Designs

12863-17

113 x 119 mm
4.4 x 4.7 inch

10.476

1. ■ Isacord 40 0020
2. ■ Isacord 40 0020
3. ■ Isacord 40 0020



12863-18

113 x 119 mm
4.4 x 4.7 inch

10.769

1. ■ Isacord 40 0020
2. ■ Isacord 40 0020
3. ■ Isacord 40 0020



12863-19

113 x 119 mm
4.4 x 4.7 inch

10.410

1. ■ Isacord 40 0020
2. ■ Isacord 40 0020
3. ■ Isacord 40 0020




12863-20

113 x 119 mm
4.4 x 4.7 inch

10.167

1. ■ Isacord 40 0020
2. ■ Isacord 40 0020
3. ■ Isacord 40 0020



12863-21

113 x 119 mm
4.4 x 4.7 inch

10.410

1. ■ Isacord 40 0020
2. ■ Isacord 40 0020
3. ■ Isacord 40 0020



12863-22

113 x 119 mm
4.4 x 4.7 inch

10.169

1. ■ Isacord 40 0020
2. ■ Isacord 40 0020
3. ■ Isacord 40 0020



12863-23

113 x 119 mm
4.4 x 4.7 inch

10.738

1. ■ Isacord 40 0020
2. ■ Isacord 40 0020
3. ■ Isacord 40 0020



12863-24

113 x 119 mm
4.4 x 4.7 inch

10.728

1. ■ Isacord 40 0020
2. ■ Isacord 40 0020
3. ■ Isacord 40 0020



12863-25

113 x 119 mm
4.4 x 4.7 inch

10.206

1. ■ Isacord 40 0020
2. ■ Isacord 40 0020
3. ■ Isacord 40 0020



12863-26

113 x 119 mm
4.4 x 4.7 inch

10.367

1. ■ Isacord 40 0020
2. ■ Isacord 40 0020
3. ■ Isacord 40 0020




20 Embroidery Designs

12863-27

113 x 119 mm
4.4 x 4.7 inch

11.934

1. ■ Isacord 40 0020
2. ■ Isacord 40 0020
3. ■ Isacord 40 0020



12863-28

113 x 119 mm
4.4 x 4.7 inch

9.231

1. ■ Isacord 40 0020
2. ■ Isacord 40 0020
3. ■ Isacord 40 0020



12863-29

113 x 119 mm
4.4 x 4.7 inch

9.850

1. ■ Isacord 40 0020
2. ■ Isacord 40 0020
3. ■ Isacord 40 0020



12863-30

113 x 119 mm
4.4 x 4.7 inch

10.148

1. ■ Isacord 40 0020
2. ■ Isacord 40 0020
3. ■ Isacord 40 0020



A	
Accessories Box.....	24
Adjust	
Alphabet Font Size.....	57
Presser Foot Pressure	36
Seam Guide.....	26
Stitch Length	55
Stitch Preview	45
Stitch Width	55
Adjust Stitch Length.....	55
Adjusting	
Sewing Light Brightness.....	39
Stitch Length	45
Stitch Width	45
Aligning Width	62
Alphabet Font Size.....	57
Alphabets	51
Embroidery	72
Sewing	47
Attach	
Knee Lifter.....	26
Seam Guide.....	26
Attaching	
BSR Presser Foot	36
Hoop	38
Needle.....	29
Presser Foot.....	35
Stitch Plate	27
Automatic Needle Threader	
Button	14
B	
Back Kick.....	42
Backstepping	
Precise	57
Basting	81
BERNINA Dual Feed.....	37
BERNINA Stitch Regulator (BSR).....	65
Bobbin Thread	33
Spooling	33
Threading	34
Bobbin Thread Indicator.....	40
Border	
Embroidering.....	81
Brightness	
Screen	39
Sewing Light.....	39
BSR.....	65
Attach Presser Foot.....	36
Setting Functions.....	65
Button	
Automatic Needle Threader	14
CLR	20
Consultant.....	20
Needle Position Left/Right.....	14
Needle Position Up/Down.....	14
Pattern End	14
Presser Foot Up/Down.....	13
Quick Help	20
Quick Reverse	13
Securing.....	14
Start Page	20
Start/Stop.....	13
Thread Cutter	13
Buttonholes	47, 52
Editing	57
C	
Calibrating the Buttonhole Foot with Slide	83
Calibration	
Screen.....	85
Change Stitch Type	
Embroidery Design	75
Changing	
Needle	29
Presser Foot	35
Stitch Plate.....	27
Cleaning	
Feed Dog	86
Needle Threader.....	86
Screen.....	85
Thread Catcher	86
Cleaning the Needle Threader	86
Cleaning the Thread Catcher.....	86
Cleaning the Thread Clamp.....	86
CLR.....	20
Color Change	
Reduce.....	81
Combi Mode.....	61
Combination	
Needle-Thread	28
Combination at Cursor Position\	
Editing	62
Combining	
Stitch Pattern	61
Connecting	
Embroidery Module.....	38
Foot Control	24
Consultant	21
Button	20
Controls.....	13
Creating	
Stitch Pattern Combination	61
D	
Darning Program	
Editing	60
Data	
Save.....	83
Dealer Data	39

- Decorative Stitches..... 47, 51
 - Delete
 - Embroidery Design..... 75
 - Personal Embroidery Designs 83
 - Personal Stitch Patterns..... 83
 - Stitch Pattern..... 61
 - Stitch Pattern Combination..... 63
 - Stitch Patterns in Editing Functions 62
 - Stitch Patterns in Stitch Pattern Combination 62
 - USB Stick..... 83
 - Display
 - Feed Dog Up/Down 46, 71
 - Fill Level Bobbin Thread 46, 71
 - Hoop..... 71
 - Needle..... 46, 71
 - Needle Stop Up/Down 45
 - Presser Foot..... 46, 71
 - Presser Foot Pressure 46
 - Recommended Hoop..... 71
 - Stitch Plate 46, 71
 - Storage Space..... 20
 - Upper Thread Tension Sewing 46
 - Upper Thread Tension Stitching 71
 - WiFi Signal Strength 46, 71
 - Dispose of the machine..... 89
 - Distance
 - Thread..... 43
 - Dual Feed 37
 - Switching On/Off..... 37
 - Duplicate
 - Embroider Design 74
- E**
- Edit
 - Stitch Pattern..... 45, 56
 - Stitch Pattern Combination..... 61
 - Editing
 - Buttonholes..... 57
 - Darning Program 60
 - Embroidery Design..... 70, 74
 - Lettering..... 80
 - Text..... 80
 - Editing\
 - Combination at Cursor Position 62
 - Embroidering
 - Border 81
 - Unicolored..... 81, 82
 - Embroidering Position
 - Move..... 70
 - Embroidery Alphabets..... 72
 - Embroidery Density
 - Embroidery Design..... 75
 - Embroidery Design..... 72
 - Align 75
 - Arrange 75
 - Center 76
 - Change Color 76
 - Change Stitch Type 75
 - Change Thread Brand 76
 - Check 75
 - Check Position 76
 - Delete 75
 - Duplicate 74
 - Edit Colors 71
 - Editing 70, 74
 - Embroidery Density 75
 - Endless..... 76
 - Endless Embroidery 78
 - Group..... 75
 - Information..... 70
 - Loading..... 74
 - Mirror 74
 - Move 74
 - Personal Folder..... 73
 - Pinpoint Placement 75, 77
 - Position..... 75
 - Resize 74
 - Rotate..... 74
 - Select..... 74
 - Selection Area..... 72
 - Standard Positioning 44
 - Stitchout..... 81
 - Ungroup 75
 - Virtual Positioning 76
 - Embroidery Design Preview
 - Zooming in/out 70
 - Embroidery Designs
 - Saving..... 80
 - Embroidery Hoop
 - Move 39
 - Embroidery Module
 - Connecting..... 38
 - Removing..... 38
 - Embroidery Screen 70
 - Embroidery Settings
 - Reset..... 83
 - Embroidery Speed 14
 - Settings..... 43
 - Embroidery Test 69
 - Endless..... 78
 - Environmental Protection 8
 - Error Messages..... 90
 - Explanation of Symbols 9
 - External Buttons..... 13
- F**
- Fabric Thickness 44
 - Feed Dog 37
 - Cleaning..... 86
 - Raise/Lower..... 37

- Feed Dog Up/Down
 - Display..... 46, 71
 - Setting..... 71
 - File Format..... 68
 - File Manager
 - Sewing Mode Quick Access Bar 47
 - File Manger
 - Stitch Pattern 47
 - Fill Level Bobbin Thread..... 46, 71
 - Firmware and Hardware
 - Information 40
 - Font..... 72, 79
 - Embroidery 72
 - Foot Control 24
 - Connecting..... 24
 - Programming the Back Kick Function 42
 - Full Screen Display 47
- H**
- Help..... 21
 - Home Screen 19
 - Hook
 - Cleaning..... 86
 - Lubricating 87
 - Hoop 38
 - Attaching 38
 - Calibrating..... 43
 - Display..... 71
 - Removing 38
 - Setting..... 71
 - Hover Function, Presser Foot
 - Settings 42
- I**
- Icon Bar
 - File Manager..... 47
 - Information
 - Machine Data 40
 - IP Address..... 39
- K**
- Knee Lifter 26
 - Attach 26
 - Lower Presser Foot..... 26
 - Raise Presser Foot 26
- L**
- Language..... 39
 - Laser
 - Switching On/Off..... 46, 72
 - Length
 - Stitch Pattern 56
 - Lettering
 - Create..... 79
 - Editing 80
 - Letters..... 47
 - Loading
 - Embroidery Design 74
 - Own Stitch Pattern..... 47
 - Saved Stitch Patterns..... 47
 - Stitch Pattern 55
 - Log File 88
 - Long Stitch..... 57
- M**
- MAC Address..... 39
 - Machine
 - Switching On/Off 23
 - Machine ID 39
 - Machine Name..... 39
 - Maintenance Information 85
 - Mirror
 - Embroidery Design 74
 - Stitch Pattern 56
 - Stitch Pattern Combination 62
 - Move
 - Embroidering Position 70
 - Embroidery Design 74
 - Embroidery Hoop 39
- N**
- Navigation Bar
 - Stitch Selection 47
 - Needle
 - Attaching..... 29
 - Changing..... 29
 - Display 46, 71
 - Selecting..... 30
 - Setting 46, 71
 - Size..... 27
 - Needle Minder 30
 - Needle Overview 28
 - Needle Position Left/Right..... 30
 - Button 14
 - Needle Position Up/Down..... 30
 - Button 14
 - Needle Stop
 - Display 45
 - Setting 45
 - Up/Down 30
 - Needle Threader..... 30
 - Needle-Thread
 - Combination..... 28

O

Optimize Balance	56
Own Embroidery Designs	
Personal Folder	73
Own Stitch Pattern.....	47

P

Pattern End	
Button	14
Pattern Repeat	56, 62
Personal Embroidery Designs	
Delete.....	83
Personal Stitch Patterns	
Delete.....	83
Power Cable	23
Power Switch.....	23
Practical Stitches	47, 48
Preparation	
Embroidery	23
Preparing the Machine	
Sewing	23
Presser Foot	
Attaching	35
Changing	35
Display.....	46, 71
Raise, with Knee Lifter	26
Selection.....	36
Setting.....	46, 71
Presser Foot Hover	
Settings	42
Presser Foot Pressure	
Adjust.....	36
Display.....	46
Setting.....	46
Presser Foot Up/Down	
Button	13
Presser Feet	
Lower, with Knee Lifter.....	26
Programming	
Foot Control	42
Pattern End.....	42
Presser Foot Up/Down	41
Quick Reverse	41
Securing Stitches	42
Programming External Buttons.....	41
Programming the Button	
Pattern End.....	42
Presser Foot Up/Down	41
Quick Reverse	41
Securing Stitches	42
Thread Cutter	41

Q

Quick Help	21
Button	20
Quick Reverse	
Button	13
Quilt Design	
Stitch Length.....	44
Quilt Stitches.....	47, 54

R

Reduce	
Color Change	81
Reset	
Embroidery Settings	83
Settings.....	20, 83
Sewing Settings	83
Stitch Settings	57
Reset Settings	83

S

Safety Instructions	5
Save	
Personal Data.....	83
Stitch Pattern	61
Stitch Pattern Combination	63
Stitch Setting	57
Saved Embroidery Designs	
Personal Folder.....	73
Saved Stitch Patterns	
Personal Folder.....	47
Saving	
Embroidery Designs.....	80
Screen	
Adjusting the Brightness	39
Calibration	85
Cleaning	85
Setting the Background.....	40
Setting the Color Scheme.....	40
Seam Guide	
Adjust	26
Attach.....	26
Remove.....	26
Securing.....	64
Button	14
Stitch Pattern Combination	63
Securing Stitches	
Settings.....	41
Securing Stitches at Sewing End	44
Securing Stitches at Sewing Start.....	44
Select	
Alphabets	47
Buttonholes	47
Decorative Stitches.....	47
Embroidery Alphabets	72

- Embroidery Design..... 72, 74
- Font..... 72
- Letters 47
- Own Embroidery Designs..... 73
- Own Stitch Pattern 47
- Practical Stitches 47
- Quilt Stitches 47
- Saved Embroidery Designs 73
- Saved Stitch Patterns 47
- Stitch Pattern..... 55
- Selecting
 - Needle..... 30
 - Stitch Plate 30
- Selection
 - Presser Foot..... 36
- Selection Area
 - Embroidery Design..... 72
- Set Unit 44
- Set Unit of Measurement..... 44
- Setting
 - Acoustic Signals..... 40
 - BSR Functions..... 65
 - Fabric Thickness..... 44
 - Feed Dog Up/Down 71
 - Hoop 71
 - Language 39
 - Needle..... 46, 71
 - Needle Stop Up/Down 45
 - Presser Foot..... 46, 71
 - Presser Foot Pressure 46
 - Screen Colors 40
 - Securing Stitches at Sewing End 44
 - Securing Stitches at Sewing Start..... 44
 - Sounds 40
 - Stitch Plate 46, 71
 - Stitch Regulation 65
- Setting Acoustic Signals 40
- Setting Sounds..... 40
- Settings
 - Background..... 40
 - Embroidery Speed..... 43
 - Hover Function, Presser Foot..... 42
 - Presser Foot Hover 42
 - Screen Brightness 39
 - Securing Stitches 41
 - Sewing Speed..... 41
 - Upper Thread Tension, Embroidery 43
 - Upper Thread Tension, Sewing 40
 - Welcome Message..... 40
- Sewing in Reverse
 - permanent..... 57
- Sewing Light
 - Adjusting the Brightness..... 39
 - Switching On/Off..... 39
- Sewing Screen 45
- Sewing Settings
 - Reset..... 83
- Sewing Speed 14
 - Settings..... 41
- Sewing Techniques 67
- Size
 - Needle 27
- Slide-on Table 25
- Speed Control..... 14
- Start Page
 - Button 20
- Start/Stop
 - Button 13
- Stitch Counter..... 56
 - Using 57
- Stitch Density
 - Stitch Pattern 56
- Stitch Length
 - Adjusting 45
 - Quilt Design 44
- Stitch Pattern
 - Combi Mode..... 61
 - Combining..... 61
 - Delete 61
 - Edit..... 45, 56
 - File Manager 47
 - Length 56
 - Loading..... 55
 - Long Stitch..... 57
 - Mirror 56
 - Optimize Balance 56
 - Pattern Repeat 56, 62
 - Personal Folder..... 47
 - Save..... 61
 - Select..... 55
 - Stitch Counter..... 56, 57
 - Stitch Density 56
 - Triple Stitch..... 56
 - Upload..... 61
- Stitch Pattern Combination
 - Creating..... 61
 - Delete 63
 - Edit..... 61
 - Mirror 62
 - Save..... 63
 - Securing..... 63
 - Upload..... 63
- Stitch Plate..... 27
 - Attaching..... 27
 - Changing..... 27
 - Display 46, 71
 - Selecting..... 30
 - Setting 46, 71
- Stitch Preview
 - Adjust..... 45

Stitch Regulation		
Setting.....	65	
Stitch Selection		
Navigation Bar.....	47	
Stitch Setting		
Save.....	57	
Stitch Settings		
Reset.....	57	
Stitch Width		
Adjust.....	55	
Adjusting.....	45	
Stitchout.....	82	
Storage Space.....	20	
Storing Accessories.....	24	
Storing the Machine.....	89	
Switching On/Off		
Bobbin Thread Indicator.....	40	
Dual Feed.....	37	
Laser.....	46, 72	
Machine.....	23	
Sewing Light.....	39	
Thread Cut.....	43	
Upper Thread Indicator.....	40	
WiFi.....	40, 46, 71	
T		
Technical Specifications.....	101	
Text		
Create.....	79	
Editing.....	80	
Thread		
Distance.....	43	
Thread Cut.....	43	
Thread Cutter		
Button.....	13	
Threading		
Bobbin Thread.....	34	
Single Needle.....	30	
Triple Needle.....	33	
Twin Needle.....	32	
Threading the Triple Needle.....	33	
Threading the Twin Needle.....	32	
Touch Gestures.....	19	
Triple Stitch.....	56	
Troubleshooting.....	95	
Tutorial.....	22	
U		
Unicolored		
Embroidering.....	81, 82	
Update Firmware.....	83	
Update Software.....	83	
Upload		
Stitch Pattern.....	61	
Stitch Pattern Combination.....	63	
Upper Thread		
Threading.....	30	
Threading the Single Needle.....	30	
Threading the Triple Needle.....	33	
Threading the Twin Needle.....	32	
Upper Thread Indicator.....	40	
Upper Thread Tension		
Display, Sewing.....	46	
Display, Stitching.....	71	
Settings, Embroidery.....	43	
Settings, Sewing.....	40	
USB Stick		
Delete.....	83	
Use of Data.....	39	
User Interface Operation		
Touch Gestures.....	19	
W		
WiFi		
Connecting to a Network.....	40	
Signal Strength.....	46, 71	
Switching On/Off.....	40, 46, 71	
WiFi Network.....	40	
Z		
Zooming in/out		
Embroidery Design Preview.....	70	



BERNINA
made to create

BERNINA recommends threads from

Mettler[®]